SIEMENS



Operating instructions

Integrators

BW500 and BW500/L

Edition

10/2021

www.siemens.com/processautomation

SIEMENS

Milltronics

Integrators BW500 and BW500/L

Operating Instructions

7MH7152 (BW500)

Introduction	1
Safety Notes	2
Description	3
Installing/mounting	4
Commissioning	5
Recalibration	6
Operating	7
PID Control	8
Batching	9
Communications	10
Parameter assignment	11
Diagnostics and troubleshooting	12
Technical specifications	13
Certificates	14
Appendix	Α
Product documentation and support	В

Legal information

Warning notice system

This manual contains notices you have to observe in order to ensure your personal safety, as well as to prevent damage to property. The notices referring to your personal safety are highlighted in the manual by a safety alert symbol, notices referring only to property damage have no safety alert symbol. These notices shown below are graded according to the degree of danger.

DANGER

indicates that death or severe personal injury will result if proper precautions are not taken.

AWARNING

indicates that death or severe personal injury may result if proper precautions are not taken.

ACAUTION

indicates that minor personal injury can result if proper precautions are not taken.

NOTICE

indicates that property damage can result if proper precautions are not taken.

If more than one degree of danger is present, the warning notice representing the highest degree of danger will be used. A notice warning of injury to persons with a safety alert symbol may also include a warning relating to property damage.

Qualified Personnel

The product/system described in this documentation may be operated only by **personnel qualified** for the specific task in accordance with the relevant documentation, in particular its warning notices and safety instructions. Qualified personnel are those who, based on their training and experience, are capable of identifying risks and avoiding potential hazards when working with these products/systems.

Proper use of Siemens products

Note the following:

AWARNING

Siemens products may only be used for the applications described in the catalog and in the relevant technical documentation. If products and components from other manufacturers are used, these must be recommended or approved by Siemens. Proper transport, storage, installation, assembly, commissioning, operation and maintenance are required to ensure that the products operate safely and without any problems. The permissible ambient conditions must be complied with. The information in the relevant documentation must be observed.

Trademarks

All names identified by [®] are registered trademarks of Siemens AG. The remaining trademarks in this publication may be trademarks whose use by third parties for their own purposes could violate the rights of the owner.

Disclaimer of Liability

We have reviewed the contents of this publication to ensure consistency with the hardware and software described. Since variance cannot be precluded entirely, we cannot guarantee full consistency. However, the information in this publication is reviewed regularly and any necessary corrections are included in subsequent editions.

Table of contents

1	Introduct	ion 10	0
2	Safety No	otes1	1
3	Description	on1	2
4	Installing	/mounting14	4
	4.1	Dimensions	4
	4.2	Layout	6
	4.3 4.3.1 4.3.2 4.3.3 4.3.4	Optional Plug-ins	8 9 0
	4.4 4.4.1 4.4.2 4.4.3 4.4.4 4.4.5 4.4.6	Interconnection 22 System Diagram 23 Scale - One Load Cell 24 Scale - Two Load Cells 25 Scale - Four Load Cells 26 Scale - Six Load Cells 27 Scale - LVDT 28	3 4 5 6 7
	4.5 4.5.1 4.5.2 4.5.3	Speed 29 Constant Speed (No Sensor) 29 Main Speed Sensor 30 Auxiliary Speed Sensor 31	9
	4.6	Auxiliary Inputs	2
	4.7	Auto Zero	2
	4.8 4.8.1 4.8.2	RS232 Port 1 33 Printers 33 Computers and Modems 33	3
	4.9	Remote Totalizer	4
	4.10	mA Output 134	4
	4.11	Relay Output3!	5
	4.12 4.12.1 4.12.2	RS485 Port 2 3! Daisy Chain 3! Terminal Device 36	5
	4.13	RS232 Port 3	6
	4.14	Power Connections	7
	4.15	mA I/O Board Connections38	8
	4.16	Installing/replacing the back-up battery	9

5	Commissi	sioning	40
	5.1	Keypad	41
	5.2	Program Mode	42
	5.2.1	Program Mode Display	
	5.2.2	To enter PROGRAM mode	
	5.2.3	RUN Mode	45
	5.3	Initial Start Up	
	5.3.1	Power Up	
	5.3.2	Programming	46
	5.4	Load Cell Balancing	
	5.4.1	Typical Two Load cell belt scale	
	5.4.1.1	Access P295	
	5.4.2	Balancing six load cell belt scales	
	5.4.2.1	Balancing for A and B	
	5.4.2.2	Balancing for C and D	
	5.4.3	Zero Calibration	
	5.4.4	RUN Mode	
6	Recalibra	ation	62
	6.1	Belt Speed Compensation	
	6.1.1	Access P018	63
	6.2	Material Tests	
	6.2.1	%Change	
	6.2.1.1	Access P019 and enter EDIT mode	
	6.2.2	Material Test	68
	6.3	Design Changes	69
	6.4	Recalibration	69
	6.4.1	Routine Zero	
	6.4.2	Initial Zero	
	6.4.3	Direct Zero	
	6.4.4	Auto Zero	
	6.4.5	Routine Span	
	6.4.6	Initial Span	
	6.4.7	Direct Span	
	6.4.8	Multispan	
	6.4.8.1	Programming	
	6.5	Online Calibration	
	6.5.1	Online Calibration feature	
	6.5.2	Activate Online Calibration	89
	6.6	Factoring	92
	6.7	Linearization	94

7	Operating	J	99
	7.1	Load Sensing	99
	7.2	Speed Sensing	99
	7.3	Differential Speed Detection	100
	7.4	Moisture Compensation	101
	7.5	Incline compensation	102
	7.6	Modes of Operation	103
	7.7	Damping	103
	7.8	mA I/O (0/4-20 mA)	104
	7.9	Relay Output	105
	7.10 7.10.1 7.10.2	Totalization Internal Totalizer External Totalizer	107
8	PID Contro	ol	109
	8.1	Hardware	109
	8.2 8.2.1 8.2.2 8.2.3 8.2.4	Connections	111
	8.3 8.3.1 8.3.2 8.3.3 8.3.4	Setup and Tuning	
	8.4 8.4.1	PID Setup and Tuning Initial Start-Up	
	8.5	Programming	121
9	Batching.		125
	9.1 9.1.1	ConnectionsTypical Ladder Logic	
	9.2	Programming	127
	9.3 9.3.1	Operation	128

10	Communi	ications	130
	10.1	BW500 and BW500/L and SmartLinx	130
	10.2	Connections	131
	10.2.1	Wiring Guidelines	131
	10.3	Configuring Communication Ports	132
	10.3.1	P770 Serial protocols	
	10.3.2	P771 Protocol address	
	10.3.3	P772 Baud Rate	134
	10.3.4	P773 Parity	134
	10.3.5	P774 Data bits	135
	10.3.6	P775 Stop bits	135
	10.3.7	P778 Modem attached	135
	10.3.8	P779 Modem idle time	
	10.3.9	P780 RS-232 Transmission interval	136
	10.3.10	P781 Data message	
	10.3.11	P799 Communications Control	137
	10.4	Dolphin Protocol	138
	10.5	Modbus RTU/ASCII Protocol	139
	10.5.1	How Modbus Works	139
	10.5.2	Modbus RTU vs. ASCII	140
	10.5.3	Modbus Format	140
	10.5.4	Modbus Register Map	
	10.5.5	Modbus Register Map (cont'd)	145
	10.6	Modems	155
	10.6.1	Example Setup	155
	10.7	Error Handling	158
11	Paramete	r assignment	160
	11.1	Start Up (P001 to P017)	160
	11.1.1	P001 Language	
	11.1.2	P002 Test Reference Selection	
	11.1.3	P003 Number of Load Cells	161
	11.1.4	P004 Rate Measurement System	161
	11.1.5	P005 Design Rate Units	162
	11.1.6	P008 Date	
	11.1.7	P009 Time	
	11.1.8	P011 Design Rate	
	11.1.9	P014 Design Speed	
	11.1.10	P015 Speed Constant	
	11.1.11	P016 Belt Length	
	11.1.12	P017 Test Load	
	11.1.13	P018 Speed Adjust	
	11.1.14	P019 Manual Span Adjust	
	11.1.15	P022 Minimum Speed Frequency	
	11.1.16	P080 Display Damping	
	11.1.17	P081 Display Scroll Mode	166

11.2	Relay/Alarm Function (P100 - P117)	
11.2.1	P100 Relay Function	
11.2.2	P101 High Alarm / Deviation Alarm	
11.2.3	P102 Low Alarm	
11.2.4 11.2.5	P107 Relay Alarms	
11.2.5	P117 Relay Dead Band	
11.2.6	P118 Relay LogicP119 Override	
11.2.7		
11.3	mA I/O Parameters (P200 - P220)	
11.3.1	P200 mA Output Range	
11.3.2	P201 mA Output Function	
11.3.3	P204 mA Output Average	
11.3.4	P212 mA Output Minimum	
11.3.5	P213 mA Output Maximum	
11.3.6	P214 4 mA Output Trim	
11.3.7	P215 20 mA Output Trim	
11.3.8	P220 mA Output Damping	
11.3.9	P250 mA input range	
11.3.10 11.3.11	P255 mA Input Function	
11.3.11	P261 4 mA Input TrimP262 20 mA Input Trim	
11.3.12	P270 Auxiliary Input Function	
11.4	Calibration Parameters (P295 – P360)	
11.4.1	P295 Load Cell Balancing	
11.4.2	P341 Days Of Service	
11.4.3	P350 Calibration Security	179
11.5	Online Calibration Options (P355 - P358)	179
11.5.1	P355 Online Calibration Feature	
11.5.2	P356 Online Calibration Reference Weight	179
11.5.3	P357 Online Calibration Limits	180
11.5.4	P358 Online Calibration Activation	
11.5.5	P359 Factoring	
11.5.6	P360 Calibration Duration	
11.5.7	P365 Multispan	
11.5.8	P367 Direct Zero Entry	
11.5.9	P368 Direct Span Entry	
11.5.10	P370 Zero Limit Deviation %	
11.5.11	P371 Auto Zero Initiation Upper Limit	
11.5.12	P377 Initial Zero	
11.5.13	P388 Initial Span	
11.6	Linearization Parameters (P390 - P392)	183
11.6.1	P390 Linearizer	
11.6.2	P391 Linearizer Load Points	
11.6.3	P392 Linearizer Compensation %	
11.6.4	P398-01 Moisture Content	
11.6.5	P398-02 Moisture Content	
11.6.6	P399 Incline Sensing	184
11.7	Proportional Integral Derivative (PID) Control	184
11.7.1	P400 PID System	
11.7.2	P401 PID Update Time	

11.7.3	P402 PID Process Value Source	185
11.7.4	P405 Proportional Term	186
11.7.5	P406 Integral Term	186
11.7.6	P407 Derivative Term	186
11.7.7	P408 Feed Forward Term	186
11.7.8	P410 Manual Mode Output	186
11.7.9	P414 Setpoint Configuration	187
11.7.10	P415 Local Set point Value	187
11.7.11	P416 External Setpoint	
11.7.12	P418 Remote Setpoint Ratio	188
11.7.13	P419 PID Freeze Option	
11.8	Batch Control (P560 – P568)	188
11.8.1	P560 Batch Mode Control	
11.8.2	P564 Batch Setpoint	
11.8.3	P566 Batch Pre-Warn	
11.8.4	P567 Batch Pre-Warn Setpoint	
11.8.5	P568 Batch Pre-Act	
11.8.6	P569 Manual Batch Pre-Act Amount	
11.8.7	P598 Span Adjust Percentage	
11.9	Totalization (P619 - P648)	
11.9.1	P619 Totaling Dropout	
11.9.1	P620 Display Zero Dropout	
11.9.2	P621 mA Zero Dropout	
11.9.3	P631 Totalizer Resolution	
11.9.4	P634 Communication Totalizer Resolution	
11.9.5	P635 Verification Totalizer	
11.9.0	P638 External Totalizer Resolution	
11.9.7	P643 External Contact Closure	
11.9.6	P647 Totalizer Display	
11.9.9	P648 Totalizer Reset, Internal	
11.9.10		
	P680 Test Load: Weight (Options)	
11.9.12	P681 Total Mass of Test Weights	
11.9.13	P682 Average Idler Spacing	
11.9.14	P690 Speed Constant Entry	
11.9.15	P691 Drive Pulley Diameter	
11.9.16	P692 Pulses Per Sensor Revolution	
11.10	ECal Parameters (P693 – P698)	
11.10.1	P693 Load Cell Capacity Units	
11.10.2	P694 ECal Load Cell Capacity	
11.10.3	P695 ECal Load Cell Sensitivity	
11.10.4	P696 ECal Load Cell Excitation	
11.10.5	P697 ECal Idler Spacing	
11.10.6	P698 ECal Conveyor Inclination	
11.10.7	P699 ECal mV Span	
11.10.8	P735 Back Light	
11.10.9	P739 Time Zone	200
11.11	Communication (P740 - P799)	201
11.11.1	P742 Word Order Parameter	
11.11.2	P750 – P769 SmartLinx Module Specific Parameters	201
11 11 2	P770 - P789 Local Port Parameters	201

	11.12	SmartLinx Hardware Testing	
	11.12.1	P790 Hardware Error	
	11.12.2	P791 Hardware Error Code	
	11.12.3 11.12.4	P792 Hardware Error CountP794 SmartLinx Module Type	
	11.12.4	P795 SmartLinx Protocol	
	11.12.5	P799 Communications Control	
	11.13	Test and Diagnostic (P900 - P951)	203
	11.13.1	P900 Software Revision	
	11.13.2	P901 Memory Test	
	11.13.3	P911 mA Output Test	204
	11.13.4	P914 mA Input Value	
	11.13.5	P918 Speed Input Frequency	
	11.13.6	P931 Running Totalizer	
	11.13.7 11.13.8	P940 Load Cell mV Signal Test	
	11.13.6	P948 Error Log	
	11.13.10	P950 Zero Register	
	11.13.11	P951 Span Register	
	11.13.12	P952 Design Load	
	11.13.13	P999 Master Reset	206
12	Diagnostic	cs and troubleshooting	207
	12.1	Generally	207
	12.2	Specifically	208
13	Technical	specifications	210
14	Certificate	95	215
	14.1	Certification	215
	14.2	Parameters unlocked when certification switch is set:	
	14.3	Certification Printing	
Α	Appendix.		
	A.1	Appendix I	
	A.1.1	Memory Backup	
	A.1.2	Software Updates	
	A.1.3	Calibration Criteria	
	A.2	Appendix II	219
В	Product do	ocumentation and support	224
	B.1	Product documentation	224
	B.2	Technical support	225
	Glossary		226
	Index		230

Introduction

Note

- The Milltronics BW500 and BW500/L are to be used only in the manner outlined in this instruction manual.
- These products are intended for use in industrial areas. Operation of this equipment in a residential area may cause interference to several frequency based communications.

This instruction manual covers the operation, installation, and maintenance of Milltronics BW500 and BW500/L.

Please refer to this manual for proper installation and operation of your BW500 or BW500/L belt scale integrator. As BW500 and BW500/L must be connected to a belt scale, and optionally a speed sensor, refer to their manuals as well.

The manual is designed to help you get the most out of your BW500 and BW500/L, and it provides information on the following:

- · How to install the unit
- How to program the unit
- How to operate the keypad and read the display
- How to do an initial Start Up
- How to optimize and maintain accurate operation of the unit
- Outline diagrams
- Wiring diagrams
- Parameter values
- Parameter uses
- MODBUS register mapping
 - Modem configuration

We always welcome suggestions and comments about manual content, design, and accessibility. Please direct your comments to Technical publications (<u>pi-documentation-service.industry@siemens.com</u>).

For the complete library of Siemens manuals, visit our website (www.siemens.com/weighing).

Safety Notes 2

Special attention must be paid to warnings and notes.



WARNING

It means that failure to observe the necessary precautions can result in death, serious injury, and/or considerable material damage.

Note

It means important information about the product or that part of the operating manual.

Description 3

Milltronics BW500

The Milltronics BW500 is a full-featured integrator for use with belt scales and weighfeeders. The speed and load signals from the conveyor and scale, respectively, are processed to derive rate of material flow, and totalization. The primary values of speed and load, and the derived values of rate and total are available for display on the local LCD, or as output in the form of analog mA, alarm relay and remote totalization.

Milltronics BW500/L

The Milltronics BW500/L is an integrator for use in basic belt scale or weighbelt applications. The speed and load signals from the conveyor and scale, respectively, are processed to derive rate of material flow, and totalization. The BW500/L does not include the advanced feature set for control.

Milltronics BW500 and BW500/L features

BW500 and BW500/L support Siemens Dolphin Plus and Modbus protocol on the two RS232 ports and the RS485 port for communication to customer PLC or computer. BW500 and BW500/L also support Siemens SmartLinx for popular industrial communication systems.

Reliable and robust user interface

- multi-field LCD display
- · local keypad

Instrumentation I/O

	BW500	BW500/L
Remote totalizer contacts	2	2
Programmable relays	5	2
Programmable discrete inputs	5	5
mA input	2 for PID ¹⁾ control	
mA output	3: rate, load, speed or PID ¹⁾ control	1: rate, load, speed

¹⁾ The optional mA I/O board is required for 3 outputs: PID control, moisture, and incline compensation.

Popular Windows and Industrial communications

- Two RS232 ports
- One RS485 port

Individual port configuration for

- Dolphin Plus
- Modbus ASCII
- Modbus RTU
- Printer
- SmartLinx compatible

Controls and operation functions

	BW500	BW500/L
Load linearization	✓	✓
Auto zero	✓	✓
PID control ¹⁾	✓	
Batch control	✓	
Multispan operation	✓	
Moisture compensation ¹⁾	✓	fixed
Incline compensation ¹⁾	✓	fixed
Differential speed detection	✓	
Real time clock	✓	

¹⁾ The optional mA I/O board is required for 3 outputs: PID control, moisture, and incline compensation.

Installing/mounting 4


Note

- Installation shall only be performed by qualified personnel and in accordance with local governing regulations.
- This product is susceptible to electrostatic shock. Follow proper grounding procedures.

4.1 Dimensions

Note


Non metallic enclosure does not provide grounding between connections. Use grounding type bushings and jumpers.



- ① Lid screws (6 pieces)
- 2 Customer mounting screw
- 3 Enclosure
- 4 Lid
- (5) Mounting hole (4 places)
- 6 Conduit entry area. Recommend drilling the enclosure with a hole saw and the use of suitable cable glands to maintain ingress rating.

4.2 Layout

4.2 Layout



- ① Battery, memory back up
- (2) Port 3 (RJ-11)
- ③ Fuse FU3
- Optional LVDT conditioner card⁴⁾
- (5) Optional Analog I/O board²⁾
- 6 Certification switch¹⁾
- Optional SmartLinx module³⁾
- 1) Applicable for trade approvals.
- 2) Not available for BW500/L.
- 3) To reduce communication interference, route SmartLinx cable along right side.
- 4) The LVDT card must be removed to access terminals below it.


MWARNING

- All field wiring must have insulation suitable for at least 250 V.
- DC input terminals shall be supplied from a source providing electrical isolation between the input and output, in order to meet applicable safety requirements of IEC 61010-1.
- Relay contact terminals are for use with equipment having no accessible live parts and wiring having insulation suitable for at least 250 V. The maximum allowable working voltage between adjacent relay contact shall be 250 V.
- The non-metallic enclosure does not provide grounding between conduit connections. Use grounding type bushings and jumpers.

Please note that the DC version of this layout will appear slightly differently.

Mounting the Enclosure

- 1. Remove the lid screws and open the lid to reveal the mounting holes.
- 2. Mark and drill four holes in the mounting surface for the four screws (customer supplied).
- 3. Fasten with a long screwdriver.



Note

- Recommended mounting: directly to wall or to electrical cabinet back panel with #6 screws
- If alternate mounting surface is used, it MUST be able to support four times the weight of the unit.

4.3 Optional Plug-ins

4.3.1 SmartLinx Module

BW500 and BW500/L is software/hardware ready to accept the optional Siemens SmartLinx communications module that provides an interface to one of several popular industrial communications systems.

BW500 and BW500/L may be shipped to you without a SmartLinx module, for installation at a later date.

If you are ready to install your SmartLinx module, or want to change it, please follow the instructions as outlined.

Installation

- 1. Isolate power and voltages applied to the BW500 and BW500/L
- 2. Open the lid
- 3. Install the module by mating the connectors and secure in place using the two screws provided
- 4. Route communication cable to SmartLinx module along the right side of the enclosure wall. This route will reduce communication

Note

Refer to the SmartLinx documentation for any required hardware settings prior to closing the lid.

- 5. Close the lid.
- 6. Apply power and voltage to the BW500 and BW500/L.

Refer to

- SmartLinx Module in the Technical specifications (Page 210)
- P750 P769 SmartLinx Module Specific Parameters in this manual under Parameter assignment (Page 160)
- the SmartLinx manual for wiring

4.3.2 mA I/O board

BW500 is software/hardware ready to accept the optional mA I/O board¹⁾. The mA I/O board provides 2 programmable 0/4 to 20 mA outputs, 2 programmable 0/4 to 20 mA inputs and a nominal 24 V DC supply for loop powered devices.

Note

Not available with the BW500/L

BW500 may be shipped to you without an mA I/O board, for installation at a later date.

If you are ready to install your mA I/O board, please follow the instructions as outlined.

Installation

- 1. Isolate power and voltages applied to the BW500
- 2. Open the lid
- 3. Install the board by mating the connectors and secure the card in place using the three screws provided
- 4. Close the lid
- 5. Apply power and voltage to the BW500

Refer to

- Technical specifications (Page 210)
- mA I/O Board Connections (Page 38)
- mA I/O Parameters (P200 P220) under mA I/O Parameters (P200 P220) (Page 171)
- mA I/O (0/4-20 mA) in the mA I/O (0/4-20 mA) (Page 104) section.

4.3 Optional Plug-ins

4.3.3 LVDT Conditioner Card

BW500 is software/hardware ready to accept the optional LVDT conditioner card.

BW500 may be shipped to you without an LVDT conditioner card, for installation at a later date.

If you are ready to install your card, please follow the instructions as outlined.


Installation

- 1. Isolate power and voltages applied to the BW500
- 2. Open the lid
- 3. Install the three provided standoffs into the motherboard at the locations as shown in the diagram in Layout.
- 4. Connect the wiring between the card and the motherboard according to the instructions in Scale LVDT.
- 5. Affix the card on the standoffs using the three screws provided.
- 6. Close and secure the lid.
- 7. Re-apply power and voltages to the the BW500.

Refer to

- Specifications (Page 210)
- Scale LVDT (Page 28)

4.3.4 Optional Components and their Locations



- ① SmartLinx
- 2 Route SmartLinx cable along right hand wall
- 3 LVDT conditioner card
- 4 mA I/O board


4.4 Interconnection

4.4 Interconnection

Note

- Wiring may be run via common conduit. However, these may not be run in the same conduit as high voltage contact or power wiring.
- Ground shield at one point only.
- Insulate at junctions to prevent inadvertent grounding.

4.4.1 System Diagram



- ① Belt scale, see Specifications (Page 210)
- ② Speed sensor, optional, see Technical specifications (Page 210)
- 3 mA output to customer device
- 4 mA output to customer device (optional I/O board required)
- ⑤ mA input from customer device (optional I/O board required)
- 6 Relay output, to customer device (2 for BW500/L)
- Auxiliary inputs
- 8 Customer remote totalizer
- Optional fieldbus connection (SmartLinx card required)
- © Communication ports can be configured for Siemens Milltronics Dolphin Plus, print data, or Modbus ASCII or RTU protocol
- ① Communication ports can be configured for Siemens Milltronics Dolphin Plus, print data, or Modbus ASCII or RTU protocol
- © Communication ports can be configured for Siemens Milltronics Dolphin Plus, print data, or Modbus ASCII or RTU protocol
- (13) Fieldbus communication


Note

Typical system capability. Not all components or their maximum quantity may be required.

4.4 Interconnection

4.4.2 Scale - One Load Cell

Siemens Belt Scale



- Customer junction box
- 2 Load cell excitation
- 3 Load cell inputs

Note


Color code for load cells used on Siemens weighfeeders may be different than shown. Please refer to the weighfeeder wiring diagram.

Where separation between the BW500 and BW500/L and belt scale exceeds 150 m (500 ft.), or legal for trade certification:

- 1. Remove jumpers from BW500 and BW500/L terminal 11/12 and 13/14
- 2. Run additional conductors from: BW500 and BW500/L terminal 12 to scale 'red' BW500 and BW500/L terminal 13 to scale 'blk'

If the load cell wiring colors vary from those shown, or if extra wires are provided, consult Siemens.

4.4.3 Scale - Two Load Cells



- ① Customer junction box
- 2 Integrator
- 3 Load cell excitation
- 4 Load cell inputs

Note

Color code for load cells used on Siemens weighfeeders may be different than shown. Please refer to the weighfeeder wiring diagram.


Where separation between the BW500 and BW500/L and belt scale exceeds 150 m (500 ft.), or legal for trade certification:

- 1. remove jumpers from BW500 and BW500/L terminal 11/12 and 13/14.
- 2. run additional conductors from:
 BW500 and BW500/L terminal 12 to scale 'red'
 BW500 and BW500/L terminal 13 to scale 'blk'

If the load cell wiring colors vary from those shown, or if extra wires are provided, consult Siemens.

4.4 Interconnection

4.4.4 Scale - Four Load Cells



- Customer junction box
- 2 Integrator
- 3 Load cell excitation
- 4 Load cell inputs

Where separation between the BW500 and belt scale exceeds 150 m (500 ft.), or legal for trade certification:


- 1. remove jumpers from BW500 terminal 11/12 and 13/14
- run additional conductors from: BW500 terminal 12 to scale 'red' BW500 terminal 13 to scale 'blk'

If the load cell wiring colors vary from those shown, or if extra wires are provided, consult Siemens.

Note

Not available with the BW500/L.

4.4.5 Scale - Six Load Cells



- ① Customer junction box
- 2 Integrator
- 3 Load excitation
- 4 Load cell inputs

Where separation between the BW500 and belt scale exceeds 150 m (500 ft.), or legal for trade certification:


- 1. remove jumpers from BW500 terminal 11/12 and 13/14
- 2. run additional conductors from: BW500 terminal 12 to scale 'red' BW500 terminal 13 to scale 'hlk'

If the load cell wiring colors vary from those shown, or if extra wires are provided, consult Siemens.

Note

Six Load Cells not applicable for the BW500/L.

4.4.6 Scale - LVDT



- Siemens LVDT Conditioner
- (2) Load cell excitation
- 3 Siemens BW500 and BW500/L
- 4 Load cell inputs
- (5) Maximum cable run LVDT to Conditioner 300 m (1000 ft)
- 6 Belt scale with LVDT

The LVDT Conditioner Card can be mounted on the BW500 or BW500/L Motherboard, or in a remotely located enclosure. The above wiring diagram is for a remote mounted installation.


- † For LVDT Conditioner cards that are mounted on the BW500 or BW500/L Motherboard, use 5 individual wires instead of the 4-conductor shielded cable shown above.
- ♦ Cable shields must connect to ground only through the BW500 or BW500/L Motherboard (TB15). They should not be grounded to the LVDT Conditioner Card enclosure or any other location.
- * Where separation between the BW500 or BW500/L and LVDT conditioner exceeds 150 m (500 ft):
- 1. remove jumpers from BW500 and BW500/L terminal 11/12 and 13/14
- run additional conductors from:
 BW500 terminal 12 to integrator terminal block '+EXC'
 BW500 terminal 13 to integrator terminal block '-EXC'

Note

- LCA (Terminal 2) is jumpered to SHLD (Terminal 5), which internally connects to the load cell circuit common.
- Do not connect to the Speed Sensor (Terminal 17) common, it is isolated from the load cell circuitry.

4.5 Speed

4.5.1 Constant Speed (No Sensor)




① Speed sensor

If a speed sensor is not used, a jumper or contact closure must be connected across BW500 and BW500/L terminals 17 / 18 when the conveyor is running. If a speed sensor is used, ensure that the jumper is removed.

Note: With contact closed or jumpered when the conveyor is idle, the integrator will continue totalizing.

4.5.2 Main Speed Sensor



- Speed sensor
- ② WS300 example

Note

Shields are common, but not grounded to chassis. Run cable shields through SHLD terminals and ground at BW500 and BW500/L only.

Connect BW500 and BW500/L terminal 16 to speed sensor terminal:

- '2' for clockwise speed sensor shaft rotation
- '3' for counter-clockwise speed sensor shaft rotation.

Speed sensor shaft rotation is viewed from the front cover of the speed sensor enclosure.

Input device in the form of open collector transistor or dry contact across BW500 and BW500/L terminals 16 / 17 will also serve as a suitable speed signal.


If a speed sensor other than the models shown is supplied, consult with Siemens for details.

For the Main Speed Sensor input, switch SW3 should be set to "HTL" for use with speed sensors providing 12V output logic, open-collector NPN outputs or dry contacts. This "HTL" setting provides a switching threshold of 5.5 V (nom.) with +/- 1V hysteresis and an internal pull-up of 12 V through a 3.3 kohm resistor.

To use a speed sensor with 5 V logic-level outputs, the "TTL" setting on SW3 provides a switching threshold of 2.9 V (nom.) with +l- 0.5 V hysteresis and an internal pull-up of 5V (nom.) through a 1.5 kohm resistor.

A second speed sensor input can be added using the Auxiliary inputs: the second speed input allows calculation of Differential Speed. For more information, see *Auxiliary Inputs* under Parameters (Page 160).

4.5.3 Auxiliary Speed Sensor



Note

Shields are common, but not grounded to chassis. Run cable shields through SHLD terminals and ground at BW500 only.

Connect any one of BW500 terminals 24 through 28 to speed sensor terminal:

- '2' for clockwise speed sensor shaft rotation
- '3' for counter-clockwise speed sensor shaft rotation.


Speed sensor shaft rotation is viewed from the front cover of the speed sensor enclosure.

An input device in the form of an open collector transistor, or dry contact may be connected between BW500 terminal 29 (COM) and any one of the AUX inputs (terminals 24 through 28). As per the "HTL" setting for the Main Speed Sensor input, an internal pullup of 12 V through a 3.3 kohm resistor is supplied, with a switching threshold of 5.5 V (nom.) and +/- 1 V hysteresis. If a speed sensor other than the models shown is supplied, consult with Siemens.

Note

Auxiliary speed sensor not available for BW500/L.


4.6 Auxiliary Inputs



Customer dry contacts, or open collector transistor output supplied as required.

Refer to P270 (Page 175) for programming details.

4.7 Auto Zero




Prefeed activated dry contact.

Refer to Auto Zero (Page 75).

4.8 RS232 Port 1


4.8.1 Printers



- 1) Printer
- 2 Receive
- ③ Common


4.8.2 Computers and Modems

For connection to a PC compatible computer or modem, using no flow control, typical configurations are:



4.9 Remote Totalizer

4.9 Remote Totalizer




- ① Supply, 30 V max, Remote totalizer 1
- ② Supply, 240 V max, Remote totalizer 2

Note


External power supply not required on all totalizer models.

4.10 mA Output 1



to customer instrumentation, isolated mA output, 750 Ω maximum load

4.11 Relay Output




Relays shown in de-energized state, contacts normally open, rated 5 A at 250 V noninductive.

Note

BW500/L has relay 1 and 2 only


4.12 RS485 Port 2

4.12.1 Daisy Chain




① Customer device

4.12.2 Terminal Device



4.13 RS232 Port 3




Note

Jumper pins 4-6 and 7-8 on the DB9 connector when using hardware flow control. Otherwise, leave them open.


4.14 Power Connections

The BW500 is available in AC or DC power models.

AC Version



DC Version




Note

AC power connections

- 1. The equipment must be protected by a 15 A fuse or a circuit breaker in the building installation.
- 2. A circuit breaker or switch in the building installation, marked as the disconnect switch, shall be in close proximity to the equipment and within easy reach of the operator

4.15 mA I/O Board Connections



- ① Auxiliary supply output, isolated 24 V DC at 50 mA, short circuit protected
- \bigcirc From customer instrumentation, isolated mA input, 200 Ω
- \odot From customer instrumentation, isolated mA input, 200 Ω
- \bigcirc To customer instrumentation, isolated mA output, 750 \bigcirc maximum load
- \bigcirc To customer instrumentation, isolated mA output, 750 Ω maximum load

Note

mA I/O Board connections are not available for BW500/L.

4.16 Installing/replacing the back-up battery

The battery (see Specifications (Page 210)) should be replaced every 5 years to ensure back up during lengthy power outages. An on board capacitor provides 20 minutes of charge to preserve the memory while the battery is being changed.


Note

The unit is supplied with one battery (battery P/N BR2330 or use equivalent 3 V Lithium battery). Insert the battery into the holder as described below before using the BW500 and BW500/L.



Power

Disconnect power before installing or replacing the battery.



Installation steps:

- 1. Open the enclosure lid.
- 2. Slide the battery into the holder. Be sure to align the + and terminals correctly.
- 3. Close and secure enclosure lid.

Commissioning 5

Note

For successful start up, ensure that all related system components, such as the belt scale and speed sensor, are properly installed and connected.

BW500 and BW500/L operates under two modes: **RUN** and **PROGRAM**. On initial powerup, the unit starts in the **PROGRAM** mode.

5.1 Keypad



Key	Function		
	PROGRAM mode	RUN mode	
*4 *8	In view mode: scrolls through parameter list	changes PID local setpoint values	
Z	decimal key	prints	
%	minus key	switches PID between auto and manual mode	
RUN	opens RUN mode		
PAR	opens parameter direct entry	opens PROGRAM mode	
ZERO SPAN	initiates calibration	initiates calibration	
CLEAR	clears entry		
ENTER	toggles between view and edit modes, confirms parameter values		
ALT	opens RUN mode	changes RUN mode display	
RESET		starts totalizer 1 reset sequence	

5.2 Program Mode

5.2 Program Mode

The PROGRAM parameters define the calibration and operation of the BW500 and BW500/L.

In **PROGRAM** mode, the user can view the parameter values or edit them to suit the application.

5.2.1 Program Mode Display

VIEW

```
P001 Language V
1-En 2-Fr 3-De 4-Es 5-It 6-Po 7-Ru 1

EDIT

P001 Language E
1-En 2-Fr 3-De 4-Es 5-It 6-Po 7-Ru 1
```

5.2.2 To enter PROGRAM mode

Press the following key to access the parameter:



```
P001 Language V
1-En 2-Fr 3-De 4-Es 5-It 6-Po 7-Ru 1
```

The default of previous parameter view is displayed. For example, P001 is the default parameter for initial start up

To select a parameter

Press the following key to move up:



P002 Test Reference Selection V
1-Weight, 2-Chain, 3-Ecal 1

For example, scrolls up from P001 to P002

Press the following key to move down:



P001 Language V
1-En 2-Fr 3-De 4-Es 5-It 6-Po 7-Ru 1

For example, scrolls down from P002 to P001

To access parameter directly

Press the following key to access the parameter:



View/Edit Parameter Enter Parameter Number

Press the following keys in sequence:



P011 Design Rate: V
Enter Rate 100.00 kg/h

For example: access P011, design rate

Or press the following for the direct access of parameters:



P940-2 Load Cell mV Signal Test V
mV reading for B 6.78

For example: access P940-2, load cell B mV signal

5.2 Program Mode

To change a parameter value

P011 Design Rate:

Enter Rate 100.00 kg/h

From the view mode

Press the following key:



P011 Design Rate:

Enter Rate 100.00 kg/h

If edit mode is not enabled after pressing ENTER, security is locked. Refer to SecurityLock (P000) under Parameters for instructions on disabling.

Press the following key to enter the new value



P014 Design Speed V

Enter Speed 0.08 m/s

For P001 to P017, ENTER effects the change and scrolls to the next required parameter.

To reset a parameter value

Press the following key:



P011 Design Rate:

Enter Rate 100.00 kg/h

From the edit mode

Press the following key:



P011 Design Rate: V
Enter Rate 0.00 kg/h

Value is reset to factory value. For example: 0.00 kg/h

5.2.3 RUN Mode

To operate BW500 and BW500/L in the **RUN** mode, the unit must undergo an initial programming to set up the base operating parameters.

Attempting to enter the **RUN** mode without satisfying the program requirements forces the program routine to the first missing item.

5.3 Initial Start Up

Initial start up of BW500 and BW500/L consists of several stages, and assumes that the physical and electrical installation of the belt scale and speed sensor, if used, is complete:

- power up
- programming
- · load cell balancing
- zero and span calibration

5.3.1 Power Up

Upon initial power up, BW500 and BW500/L displays:

```
P001 Language V
1-En 2-Fr 3-De 4-Es 5-It 6-Po 7-RU 1
```

The initial display prompts the user to select the preferred language.

5.3 Initial Start Up

5.3.2 Programming

Press:



BW500 and BW500/L then scrolls sequentially through the start up program as parameters P001 through P017 are addressed.

```
P002 Test Reference Selection V
Select 1-Weight, 2-Chain, 3-Ecal 1
```

For example: Accept 'weight' (supplied with scale) as the test reference.

Press the following key:



P003 Number of Load Cells V
Enter Number of Load Cells 2

For example: accept '2' as the number of load cells.

Note

For six load cell belt scales, select 4.

Press the following key:



P004 Rate Measurement System V
Select 1-Imperial, 2-Metric 2

For example: Accept '2' for measurements in metric.

Press the following key:



P005 Design Rate Units:
Select: 1-t/h, 2-kg/h, 3-kg/min

For example: accept '1' for units in t/h

Note

t/h equals metric tonnes per hour.

Press the following key: 1)



P008 Date:

Enter YYYY-MM-DD 1999-03-19²)

- 1) Not applicable for the BW500/L
- 2) default date

Press the following key:



P008 Date:

Enter YYYY-MM-DD 1999-03-19

For example, enter current date of March 19, 1999

Press the following keys in a sequence¹⁾:



P009 Time: V
Enter HH-MM-SS 00-00-00

1) Factory set time 24 hour clock

5.3 Initial Start Up

Press the following key:



P009 Time:

Enter HH-MM-SS

00-00-00

For example: enter current time of 14:41

Press the following keys in a sequence:















P011 Design Rate1): Enter Rate

0.00 t/h

1) Factory design rate

Press the following key:



P011 Design Rate:

Enter Rate

0.00 t/h

For example: rate of 100 t/h

Press the keys in the following sequence:





Enter Speed







0.00 m/s

1) Factory design speed

Press the following key:



P014 Design Speed E
Enter Speed 0.00 m/s

For example: speed of 0.8 m/s

Press the following keys in a sequence:







P015-01 Speed Constant V
Pulses/m 0.0000

Note: If the speed input is configured for constant speed, display value reads 'Jumpered'.

Press the following key to advance:



If the speed input is connected to a speed sensor, pressing enter at P015 invokes P690 for data entry. Press the following key:



P690-01 Speed Constant Entry E
1-Calculated, 2-Sensor Data 1

5.3 Initial Start Up

Select: 1 - Calculat	ted		Select: 2 - Sensor Da	ta
The program returns to P015. Cavalue per Parameter P690.	lculate the		The program advances through parameters P691 and P692 prompting entry from the sensor name-plate. From this data, the speed constant is calculated and automatically entered into P015.	
P015-01 Speed Constant	E		P691-01 Step 1:	V
Pulses/m	0.0000		Drive Pully Diameter	0.00 mm
Press the following keys in the			P692-01 Step 2:	V
given sequence:			Pulses per sensor Rev.	0.00
1 0 0 2 3 ENTER			Enter Pulses P015-01 Speed Constant	V
For example: speed constant of 100.3 pulses per meter			Pulses/m	0.0000
This value is calculated. For man Differential Speed (P015-02), fol			llculation, refer to P690 on page 143 r P015-01.	3. To program
P016 Belt Length	V			
Enter Length	0.00			
m				
factory set length				
Press the following key:	For example			
ENTER	belt length of 25 m			
P016 Belt Length	E			
Enter Length	0.000			
m				
For example belt length of 25 m				
Press the following keys:				
2 5 ENTER				
P017 Test Load: Weight M	2017 Test Load: Weight MS 1 V			
Enter test load 0.00				
kg/m				
If P002 Test Load Reference had	been set for 2-Ch	na	in, the display would read:	
	P017 Test Load: Chain MS 1 V			
	Enter test load 0.00 kg/r		0.00 kg/m	
or, if 3-ECal refer to ECal parame	ters (P693 - P699) c	on page 144)	
	P017 Test Lo			V
		0.00 kg/m		
or, if P002 is set to 1-Weight, pressing enter at P017 invokes P680 for data entry.				
Press the following key:				
ENTER				
P680 Test Load: Weight M	0 Test Load: Weight MS 1 V			
1-Enter Value, 2-Enter I	Data 0			

Select: 1 - Enter Value		Select: 2 - Enter Data	
The program returns to P017.			
Press		The program advances through parameters P681 and P682 prompting entry of the total mass of all the test weights used for SPAN calibration and the average measured idler space before and after the scale. From this data the test load is calculated and automatically entered into P017	
P017 Test Load: Weight MS 1	C	P681 Step 1: V	
Enter test load		Total Mass of Test Weights	0.00 kg
00.00			
Press		Units are selected in P004: metric, imperial.	
2 0 5 ENTER			
For example: test load of 20.5		P682 Step 2:	V
kg/m		Average Idler Space	m
		P017 Test Load: Weight MS 1	V
		Enter test load	00.00

Note

For a two or three idler system, multiply the average idler space by the number of scale idlers. For example, 1.5 m idler space with 2 scale idlers equals 3 m.

This value is calculated. For manual or automatic calculation, refer to P680. The test load value should be less than the design load. If not, contact Siemens.

The initial programming requirements are now satisfied. To ensure proper entry of all critical parameter values, return to P002 and review parameters through to P017.

5.4 Load Cell Balancing

5.4 Load Cell Balancing

Note


Load cell balancing is not required if the selected test reference is ECal (P002 = 3). In the case of ECal, the load cells are balanced by the ECal procedure.

If you are operating a two or four load cell belt scale, it is recommended that the load cells be balanced electronically prior to initial programming and calibration, or after either or both load cells have been reinstalled or replaced.

Unbalanced load cells can adversely affect the performance of your belt conveyor weighing system.

With the conveyor stopped and locked out, lift the belt off the weighing idlers.

5.4.1 Typical Two Load cell belt scale



- ① Belt travel
- 2 Load cell B
- 3 Test weight bar
- (4) Load cell A

5.4.1.1 Access P295


P295 Load Cell Balancing: E
Select: 1-A&B, 2-C&D 0

Option '2' enabled only if P003, number of load cells is 4

Press the following keys:



Load Cell Balancing A & B
Place weight at cell B and press ENTER




1 Test weight

Press the following key:



Load Cell Balancing A & B
Place weight at cell A and press ENTER

5.4 Load Cell Balancing



1 Test weight

Press the following key:



Load Cell Balancing A & B
Load cells are now balanced

Balancing the load cells requires a subsequent zero and span calibration

If four load cell scale, press the following key to continue:



P295 Load Cell Balancing: V
Select: 1-A&B, 2-C&D 1

Press the following key:




P295 Load Cell Balancing: E
Select:1-A&B, 2-C&D 1

Press the following keys:





Load Cell Balancing C & D
Place weight at cell D and press ENTER




1 Test weight

Press the following key:



Load Cell Balancing C & D
Place weight at cell C and press ENTER

5.4 Load Cell Balancing



1 Test weight

Press the following key:



Load Cell Balancing C &D
Load cells are now balanced

Balancing the load cells requires a subsequent zero and span recalibration

5.4.2 Balancing six load cell belt scales

For a six load cell belt scale, the six load cells are connected into four inputs. Load cells A, C and E are connected into inputs A and C; load cells B, D and F are connected into inputs B and D.

Balancing load cells is still recommended to optimize system accuracy. The balancing needs to be done twice, once for P295-01 = A and B and then once for P295-02 = C and D.

Three weights that are all very close to the same mass are required.

5.4.2.1 Balancing for A and B

- 1. Place one weight at load cell B, one weight at load cell D and one weight at load cell F, all at the same time.
- 2. Start the balancing procedure for A and B.
- 3. Press enter for B.
- 4. Move the 3 weights to A, C and E.
- 5. Press enter for A.

Balance for A side and B side is complete.

5.4.2.2 Balancing for C and D

- 1. Move all the weights back to B, D and F.
- 2. Set P295 to C and D.
- 3. Press enter for D (or B, depending on software revision).
- 4. Move the 3 weights again to A, C and E.
- 5. Press enter for C (or A, depending on software revision).

Balance for C and D is complete. Remove the weights and perform zero calibrations.

Note

After balancing is complete, applying a weight on A or B side should not result in the digital count values from PAR 943 being out by no more than a difference of 100.

5.4 Load Cell Balancing

5.4.3 Zero Calibration

Note

To obtain an accurate and successful calibration, ensure that the required criteria are met. Refer to Calibration Criteria (Page 218).

Press the following key:



```
Zero Calibration: Current Zero 0
Clear belt. Press ENTER to Start
```

The current zero count

Press the following key:



The zero count being calculated while calibration is in progress

The duration of the Zero calibration is dependent on speed (P014), length (P016), and revolutions (P360) of the belt.

```
Calibration Complete. Deviation 0.00

Press ENTER to accept value: 551205
```

The deviation from previous zero. For an initial zero there is no previous zero; hence the deviation is 0. For example: the new zero count, if accepted

Press the following key:



Zero Calibration. Current Zero 551205
Clear belt. Press ENTER to Start

Accepting the Zero returns to start of Zero. A new Zero can be performed, or continue to Span.

Note

The moisture meter is ignored during calibration. If inclinometer is used, then calibration is adjusted based on incline angle.

Span Calibration

When performing a Span Calibration where the test reference is ECal (P002 = 3), the supplied test weight or test chain must not be applied, and the conveyor must be run empty.

Note

To obtain an accurate and successful calibration, ensure that the required criteria are met. Refer to Calibration Criteria (Page 218).

With the conveyor stopped and locked out, apply the test weight or chain to the scale as instructed in the associate manuals; then start the conveyor.

0

Press the following key:



Span Calibration Current Span
Setup test Press ENTER to Start

For example: the current span count.

5.4 Load Cell Balancing

Press the following key:



```
Initial Span Calibration in progress %

Current Reading ####
```

The span count being calculated while calibration is in progress.

The duration of the Span calibration is dependent on speed (P014), length (P016), and revolutions (P360) of the belt.

```
Span Count Too Low
Press CLEAR to continue
```

- signal from load cell too low, ensure proper test weight or chain is applied during calibration
- · check for proper load cell wiring and ensure shipping brackets have been removed.

```
Calibration Complete Deviation 0.00

Press ENTER to accept value: 36790
```

- the deviation from the previous span. For an initial span, there is no previous span count; hence the deviation is 0.
- For example: the new span count, if accepted.

Press the following key:



```
Span Calibration. Current Span 36790
Setup test. Press ENTER to Start
```

For example: the current span count.

Accepting the Span returns to start of Span. A new Span can be performed, or enter **RUN** mode. If calibrating with a test weight or test chain, remove it from the scale and store in a secure place before returning to **RUN** mode.

Note

The moisture meter is ignored during calibration. If the Inclinometer is used, then calibration is adjusted based on incline angle.

5.4.4 RUN Mode

Proper programming and successful zero and span calibration allow entry into the **RUN** mode. Otherwise, entry is denied and the first missing item of programming or calibration is displayed.

Press the following key:



1		
Rate	0.00	t/h
Total 1	0.00	t

For example: if there is no material on the belt and the conveyor is running. The current rate is 0 and no material has been totalized.

Once the initial programming is complete and the BW500 and BW500/L is operating in the **RUN** mode, you may now put the belt conveyor into normal service. The BW500 is functioning under its initial program and calibration, reporting rate of material flow and totalizing.

Recalibration

6.1 Belt Speed Compensation

To achieve optimum accuracy in the rate computation, the belt speed displayed must equal that of the actual belt speed. As the speeds are likely to differ, a belt speed compensation should be performed.

Run the conveyor with the belt empty.

View the belt speed.

6.1.1 Access P018

P018 Speed Adjust V
Enter New Speed 0.60

For example: current speed of 0.6 m/s

Stop the conveyor and measure a length of the belt; marking the forward end (start time) and the back end (stop time). Use the belt scale as the stationary reference.

Run the belt and measure the time for the belt length to pass over the scale.

speed = (belt length / time) m/s or ft/min.

Refer to the Start Up (Page 40) section for instructions on parameter selection and changing values.

Press the following key:



P018 Speed Adjust E
Enter New Speed 0.60

For example: current speed of 0.6 m/s and enter correct speed of 0.63 m/s.

6.1 Belt Speed Compensation

Press the following keys in a sequence:



P015 Speed Constant V
Pulses/m 97.5169

Speed sensor constant, adjust for P015

P014 Design Speed V
Enter Speed 0.63 m/s

For constant speed (jumper), adjusts P014

The displayed speed (used in the rate computation) now equals the actual speed.

Note

When the speed adjust is entered, the instantaneous speed of the BW500 at that time is used; this may cause an additional error if the speed is not checked again compared to the BW500. Continue checking the speed against the BW500 and adjusting until the speed can be matched exactly to when the input is entered.

6.2 Material Tests

Perform material tests to verify the accuracy of the span calibration and compensate for material flow. If the material tests indicate a repeatable deviation exists, perform a manual span adjust (P019). This procedure automatically alters the span calibration and adjusts the test load (P017) value, yielding more accurate span recalibrations.

If the span adjust value is within the accuracy requirements of the weighing system, the material test was successful. Resume normal operation.

If the span adjust value is not acceptable, repeat the material test to verify repeatability. If the result of the second material test differs considerably, consult Siemens or contact your local Siemens representative.

If the span adjust values are significant and repeatable, perform a manual span adjust.

Note

Test weights are NOT used during material tests.

There are two methods of executing the manual span adjust: % Change and Material Test

- % Change: based on the material test, the difference between the actual weight of material and the weight reported by the BW500 and BW500/L is calculated and entered into P019 as % change.
- Material Test: based on material test, the actual weight of material is entered into P019

The method of execution is a matter of preference or convenience, and either way yields the same result.

6.2.1 %Change


To run a %Change material test	To run a	%Change	material	test
--------------------------------	----------	---------	----------	------


- 1. Run the belt empty
- 2. Perform a zero calibration
- 3. Put the BW500 and BW500/L into RUN mode
- 4. Record the BW500 and BW500/L total as the start value
- 5. Run material at a minimum of 50% of design rate over the belt scale for a minimum of 5
- 6. Stop the material feed and run the conveyor empty
- 7. Record the BW500 and BW500/L total as the stop value _____
- 8. Subtract the start value from the stop value to determine the BW500 and BW500/L total
- 9. Weigh the material sample if not already known

BW500 and BW500/L total =
material sample weight =

6.2 Material Tests

Calculate the span adjust value





% span adjust = (BW500 - material sample weight) x 100/ material sample weight

6.2.1.1 Access P019 and enter EDIT mode

P019 Manual Span Adjust E
Select 1-% Change 2-Material Test 0

Press the following keys:



P598 Span Adjust Percentage V
Enter Calculated +/- error 0.00

Press the following key:



P598 Span Adjust Percentage E
Enter Calculated +/- error 0.00

Press the following keys:



if % change is negative, remember to enter the minus sign, for example, -1.3.

P017 Test Load Weight:MS1 V
Enter Test load 56.78

For example: the new test load value is displayed

6.2 Material Tests

6.2.2 Material Test

Access P019 and enter EDIT mode

```
P019 Manual Span Adjust E
Select 1-% Change 2-Material Test 0
```

Press the following keys:



Material Test
Add to Totalizer 0-No 1-Yes

If yes, the weight of the material test will be added to the totalizer, if no, material is Material Test added to test totalizer (4) only. For example, do not add weight of material test to totalizer.

Press the following keys:



Material Test
Press ENTER to start

Press the following key:



Material Test tonnes

Press ENTER to start #.### t

The totalizer reading as the material test is run.

Press the following key:



Material Test 964.032 t
ENTER actual amount tonnes

For example: the weight totalized by the belt scale and BW500 and BW500/L 975.633 kg is the actual weight of the material test.

Press the following keys in a sequence:



Material Test Deviation -1.19
Accept 0-No, 1-Yes

The calculated deviation is displayed as a % of the actual weight.

Press the following keys:



P017 Test Load Weight: MS1 V
Enter Test Load 56.78

For example, the new test load value is displayed.

Verify the results of the span adjust by material test or return to normal operation.

6.3 Design Changes

Where parameters have been changed with a resultant impact on the calibration, they do not take effect until a recalibration is done.

If significant changes have been made, an initial zero (P377) and/or initial span (P388) may be required (See, under P377 (Page 182) or P388 (Page 183)).

6.4 Recalibration

To maintain the accuracy of the weighing system, periodic zero and span recalibration is required. Recalibration requirements are highly dependent upon the severity of the application. Perform frequent checks initially, then as time and experience dictate, the frequency of these checks may be reduced. Record deviations for reference.

The displayed deviations are referenced to the previous zero or span calibration. Deviations are continuously tallied for successive zero and span calibrations, and when exceed their limit (+12.5 and -12.5 from the initial zero or span), indicate an error message that the deviation or calibration is out of range.

6.4 Recalibration

6.4.1 Routine Zero

Note

To obtain an accurate and successful calibration, ensure that the required criteria are met. Refer to Calibration Criteria (Page 218).

Press the follwoing key:



Zero Calibration. Current Zero. 551205
Clear belt. Press ENTER to start

For example: the current zero count.

Press the following key:



Zero Calibration in progress %
Current Reading: 0.01 kg/m

For example: the load reported while calibration is in progress

Calibration complete. Deviation 0.02

Press ENTER to accept value 551418

For example: the calculated deviation in % of full span and the new zero count, if accepted.

A deviation that is high (Siemens recommends 3 or higher) should be investigated further to identify the source).

403.37

Calibration is out of range
Deviation report:

If unacceptable, press the following key to restart:



This indicates that the mechanical system is errant. P377, initial zero, should be used judiciously and only after a thorough mechanical investigation.

The cause of the increased deviation must be found and rectified. A zero recalibration as previously described can then be retried.

If the operator deems this deviation to be acceptable, set P377 to 1 to invoke an initial zero calibration. Further deviation limits are now based on this new initial zero.

Press the following key:



Zero Calibration. Current Zero 551418
Clear belt. Press ENTER to start

For example: zero calibration is accepted, played as the current zero.

Note

This is the end of zero calibration. Proceed with zero, or span recalibration, or return to RUN.

6.4.2 Initial Zero

Perform an initial zero if necessary when **calibration is out of range** message is shown. During this step the progress of the process will be shown on the display with a progress indicator in %.

Access P377 and enter EDIT mode

P377 Initial Zero E
Enter 1 to start initial Zero 0

Press the following keys



Zero Calibration. Current Zero 530560
Clear belt. Press ENTER to start

For example, the current zero.

Press the following key:



Initial Zero Calibration in progress %

Current Reading: #####

For example, the zero count being calculated while calibration is in progress.

Calibration complete. Deviation 0.00

Press ENTER to accept value 551413

For example: the deviation in % from previous zero. The new zero count if accepted. If unacceptable, press the following key to restart:



Press



Zero Calibration. Current Zero 551413
Clear belt. Press ENTER to start

For example, the current zero count.

Note

This is the end of zero calibration. Proceed with span recalibration or return to RUN.

6.4.3 Direct Zero

Use direct zero entry (P367) when replacing software or hardware, if it is not convenient to perform an initial zero. A record of the last valid zero count is required.

Access P367 and enter EDIT mode

P367 Direct Zero Entry E
Enter Zero Count 0

Press the following keys in a sequence:



Zero Calibration. Current Zero V
Enter Zero Count 551401

For example, the last valid zero count.

6.4.4 Auto Zero

The Auto Zero function is useful in outdoor applications where there are fluctuations in temperature, causing the zero to change throughout the day.

Auto Zero provides automatic zero calibration in the **RUN** mode under the following conditions:

- the auto zero input (terminals 29/30) is in a closed state; jumper or remote contact
- the load on the belt is within the programmed percentage (P371) based on the design load (P952)

Note

Set Parameter P371 to a value from 1 to 10%, default is 2%. See "P371 Auto Zero Initiation Upper Limit (Page 182)"

the terminal and load status coincide for at least one belt revolution

The rate display is interrupted by the Auto Zero routine.

Rate 0.00 t/h
Total 1: 0.00 tonnes AZ

(AZ flashes on and off)

Note

t/h equals metric tonnes per hour

```
Calibration Complete. Deviation 0.0

Auto-Zero value 551410
```

For example, typical zero and deviation values.

The duration of the auto zero is one or more belt revolutions (P360). If either condition is interrupted during that period, the auto zero is aborted and the RUN display is resumed. After one belt revolution, another auto zero will be attempted if the input and load conditions are met.

If the resulting zero deviation is less than an accumulated 2% from the last operator initiated zero, the auto zero is accepted.

If the deviation is greater than an accumulated 2%, an error message is displayed. The error message is cleared after five seconds, however if a relay is programmed for diagnostics, it remains in alarm so long as the Auto Zero conditions are being met.

If material feed resumes during an auto zero function and is greater than the maximum load on the belt (P371), the totalizing function is maintained.

6.4.5 Routine Span

Note

To obtain an accurate and successful calibration, ensure that the required criteria are met. Refer to Calibration Criteria (Page 218).

Press the following key:



Span Calibration. Current Span Setup test. Press ENTER to start 41285

For example: the current span count

Zero should be done prior to Span Setup test. Press Enter to start.

Perform a zero calibration or press:



Press the following key:



Span Calibration in progress

Current Reading: 55.56 kg/m

The load reported while calibration is in progress.

Calibration complete. Deviation 0.03

Press ENTER to accept value 41440

For example: the deviation in % from previous span, if the new span count is accepted. If unacceptable, press the following key to restart:



A deviation that is high (Siemens recommends three or higher) should be investigated further to identify the source).

Note

During this step the progress of the process will be shown on the display with a progress indicator in %.

Span Count too Low.
Press CLEAR to continue.

Signal from load cell too low: ensure shipping brackets are removed and proper test weight or chain is applied during span.

Calibration aborted
Belt speed is too low:

For example: belt speed is <10% of design (P014).

Calibration is out of range Deviation Error: XX.XX

This indicates that the mechanical system is errant. The use of P388, initial span, should be used judiciously and only after a thorough mechanical investigation has been exercised.

Find and rectify the cause of the increased or decreased deviation. Then re-try a span recalibration.

If this deviation is still unacceptable, set P388 to 1 to invoke an initial span calibration. Further deviation limits are now based on this new initial span.

Press the following key:



```
Span Calibration. Current Span 41440
Setup test. Press ENTER to start
```

For example: span calibration is accepted and displayed as the current value.

6.4.6 Initial Span

Note

Perform an initial span when a calibration out of range message appears.

During this step the progress of the process will be shown on the display with a progress indicator in %.

A zero calibration should be performed prior to performing a span calibration.

Access P388 and enter EDIT mode

P388-01 Initial Span E
Enter 1 to start Initial Span 0

Press the following keys:



Span Calibration. Current Span 41440
Setup test. Press ENTER to start 0

For example: the current span count.

Zero should be done prior to Span Setup test. Press ENTER to start

Perform a zero calibration or clear.

Press the following key:



Initial Span Calibration in progress

Current Reading: #####

The span count being calculated while calibration is in progress.

Calibration complete. Deviation 0.00

Press ENTER to accept value 41900

The deviation is reset. For example, the new span value if accepted or unacceptable, press the following key to restart:



Press the following key:



Span Calibration. Current Span 41900
Setup test. Press ENTER to start

For example: the current span count.

Note

End of span calibration. Remove the test weight and return to RUN.

6.4.7 Direct Span

Direct span entry (P368) is intended for use when replacing software or hardware, and when it is not convenient to perform an initial span. A record of the last valid span count is required.

Access P368 and enter EDIT mode

P368-01 Direct Span Entry

Enter Span Count

Press the following keys in a given sequence:



P368-01 Direct Span Entry V
Enter Span Count 41900

For example: the last valid span count.

6.4.8 Multispan

The BW500 offers a multispan function, which allows the BW500 to be calibrated for up to eight different feed conditions that would produce varying load characteristics. Different feed conditions are typically related to the running of different materials or multiple feed locations. The varying load characteristic often has a bearing on the belt tension, and is observed especially when in close proximity to the scale. To accommodate such scale applications, a span correction can be made by selecting and applying the appropriate span.

Since every material has its own unique physical properties, and may load the belt differently, a span calibration may be required for each material to realize maximum accuracy.

In the case of different feeder locations, a span calibration may be required to match each feedpoint or combination of feedpoints.

Each time one of the eight conditions is in effect, the corresponding multispan is selected prior to putting the BW500 into the **RUN** mode. The selection is made by either changing the multispan operation number, accessed via P365, or by external contacts connected to the Auxiliary input, and programmed via P270.

To enable multispan operation, the following must be addressed.

- connections
- programming
- calibration
- operation

Note


Multispan is not available with BW500/L.


Connections

If the span selection is to be done by remote contact, the following connections would apply. Otherwise, no additional connections to the BW500 are required.

Multispan Selection of Spans 1 and 2

Multispan Selection of Spans 1 to 8





^{*}Remote contact can be from relay, open collector switch, or BCD switch.

6.4.8.1 Programming

Access P365 and enter EDIT mode

Span 1 will have already been set as part of the Start Up and initial calibration. Therefore, select 2.

Access P017 and enter EDIT mode

Enter the test load value, and press the following key to do a span calibration:



To do a span calibration for another condition, (i.e. span 3 or 4 etc.), access P365 and repeat these steps for each condition. As with any initial span, follow the span calibration for each multispan with a material test and factoring.

To use remote span selection, auxilliary Inputs, 1 and/or 2 or 3, are programmed to read the contact state as the span selection. Remote selection overrides the keypad (or Dolphin Plus) selection. The auxilliary inputs override the keypad selection.

Access P270 and enter EDIT mode

P270-01 Auxiliary Input Function E
Select Function [0-13] 0

Enter the following key:



These programs Auxiliary Input 1 (terminal 24) to read the contact state for span selections: 1 or 2.

Access P270 and enter EDIT mode (when using spans 3 and/or 4)

If spans 3 and/or 4 are to be used:

Access P270 and enter EDIT mode (when using spans 3 and/or 4)

```
P270-02 Auxiliary Input Function E
Select Function [0-13] 0
```

Enter the following key:



This programs Auxiliary Input 2 (terminal 25), in conjunction with Auxiliary input 1 reads the contact state for the span selections 3 and 4.

Access P270 and enter EDIT mode (when using spans 5 to 8)

If spans 5, 6, 7, and/or 8 are to be used:

Access P270 and enter EDIT mode (when using spans 5 to 8)

```
P270-03 Auxiliary Input Function E
Select Function [0-13] 0
```

Enter the following key:



This programs Auxiliary Input 3 (terminal 26), in conjunction with Auxiliary input 1 and Auxiliary input 2 to read the contact state for span selections 5, 6, 7, and 8. Remote selection of a span is not enabled until a span calibration has been done. Initial span selection must be done via the Multispan parameter, P365.

Initial multispan calibration or span selection is made via the Multispan parameter (P365).

Operation

When span calibration is done, press the following key to revert to the RUN mode.



Rate kg/h 0.00 kg/h Multispan 2

Total 1: 0.00 kg

For example: if there is no material on the belt and the conveyor is running. The current rate is 0 and no material has been totalized.

When the material to be run on the belt changes, the multispan is changed to the corresponding span. This is completed either by changing the span value entered in P365, or by closing the appropriate contacts connected to the programmed Auxiliary inputs.

Span	Auxiliary Input Aux 1	Multispan Selection Aux 2	Multispan Selection Aux 3
1	⊣⊢	⊣⊢	⊣⊢
2	*	⊣⊢	⊣⊢
3	⊣⊢	*	⊣⊢
4	*	*	⊣⊢
5	⊣⊢	⊣⊢	*
6	*	⊣⊢	*
7	⊣⊢	*	*
8	*	*	*

It may be required to reset or note the totalizer value, as the process materials being conveyed change. Refer to Operation. (Page 99)


Linearization applies concurrently to spans.

6.5 Online Calibration

The Online Calibration feature may be used to routinely check, and if necessary adjust, the Span calibration in **RUN** mode, without interrupting the material flow or process.

Note

Not available with BW500/L.



Install a weigh bin, (bin or silo equipped to provide a 4 to 20 mA output proportional to weight), preceding the material infeed.

Connect the weigh bin to one of the mA inputs on the optional mA I/O board of the BW500: either mA input 1, terminals 5 and 6; or mA input 2, terminals 7 and 8.

Install a material feed control device, preceding the weigh bin.

- 1) Feeder
- ② Max. (e.g. 90%)
- ③ High (e.g. 70%)
- 4 Reference weight: (the amount of material held between High and Low levels)
- ⑤ Low (e.g. 30%)

Note

- Press the "PAR" key twice, to enter a parameter number directly.
- Whenever you wish to change a value, press "ENTER" to enable the EDIT mode.

6.5 Online Calibration

Press the following key:



P355 Online Calibration Feature
Select: 0-Off, 1-On

EDIT mode: value can be changed.

Select the Online Calibration feature:

Press the following keys:



6.5.1 Online Calibration feature

Access

P355 Online Calibration Features V
Select: 0-Off, 1-On 1

Value is accepted.

Enter the weigh bin reference weight, (the amount of material the bin holds between the high and low levels), in units selected in P005.

Press the following keys in a sequence:



Access

P356 Online Calibration Features V
Select: 0-Off, 1-On 10.000

For example: reference bin weight.

Enter the max., high, and low limit setpoints as a percentage in P357.

Press the following keys:



P357-01 Online Calibration Limits V
MAX Limit: 90.0

Limit as a percentage

Press the following keys:



Access

```
P357-02 Online Calibration Limits V
HIGH Limit: 70.0
```

Press the following keys:



Access

```
P357-03 Online Calibration Limits V
LOW Limit: 30.0
```

Calibrate the mA inputs on the BW500 to the 4 and 20 mA levels of the weigh bin. 4 mA is calibrated with the weigh bin empty, using P261-01 or -02. 20 mA is calibrated with the weigh bin full, using P262-01 and P262-02.

Assign one of the mA inputs for the Online Calibration function.

Press the following keys:



Access

```
P255-01 mA Input Function V
Select 0, 1-PID SP, 2-PID FV, 3-OCAL 3
```

For example: mA input 1 set to 3.

Assign one of the 5 relays, P100-01 to P100-05, to the Online Calibration function.

6.5 Online Calibration

Press the following keys:



Access

P100-01 Relay Function	V
Select Function [0-9] (see manual)	9

For example: relay 1 set to 9.

Program the assigned relay using P118, relay logic, so that when you connect the assigned relay to the weigh bin material feed control device, the weigh bin material feed stops when the Online relay is energized.

6.5.2 Activate Online Calibration

Activate Online Calibration

Press the following keys:



P358 Online Calibration Features V
0-OFF, 1-ACTIVE

Note

For remote access, Online Calibration can also be activated using one of the Auxiliary inputs (refer to P270 (Page 175))

When the Online Calibration is activated, normal operation continues until the weigh bin fills to the maximum level, (90% in the example shown). During the filling stage, the current level is displayed as a percentage.

Online Calibration - LOW > 19% Wait for LEVEL > MAX RLY

Current level displayed as percentage.

When the maximum limit is reached, the relay assigned to the Online Calibration function energizes to stop the weigh bin material feed.

Online Calibration - 94% > MAX
Wait for LEVEL < HIGH RLY1

Material continues to be discharged from the weigh bin, and when the level drops to the High limit (70% in the example) the Online totalizer is automatically activated.

Online Calibration - TOTAL 3.71 tonnes
Calibration in progress RLY1

Running total

When the Low limit (30%) is reached, the totalizer is deactivated and the assigned relay is deenergized, which reopens the material feed to the weigh bin.

6.5 Online Calibration

The BW500 Online material total, the amount of material totalized between the High and Low limits, is compared to the value entered in P356. The deviation percentage between these values and the new Span count value is displayed.

Online Calibration - Deviation 2.51%

Press ENTER to accept New span 22280

Deviation percent and new Span count value

Press the following key to accept the results.



Online Calibration Complete

Press ENTER to accept New span 22280

Note

- Deviation must be no greater than ±12% of the initial span or it will not be accepted.
- For remote access, Online Calibration can be accepted using one of the Auxiliary inputs: (refer to P270 (Page 175))

If you want to reject the results and return to RUN mode, press the following key:



Rate 0.00 t/h
Total 1: 10.15 t

Note

t/h equals metric tonnes per hour

For remote access, to return to **RUN** mode, program one of the Auxiliary inputs: (refer to P270 (Page 175))

6.5 Online Calibration

If you want to reject the results and perform another online calibration, press the following key to return to P358.



Access

P358 Online Calibration Features V
0-OFF, 1-ACTIVE 1

Press the following keys:



If the deviation is greater than $\pm 12\%$:

Calibration is out of range Deviation Error:

1. Rerun online calibration to verify the deviation: press the following key to return to P358.



- 2. Verify the mechanics of the belt scale: carry out material tests to ensure the readings are correct.
- 3. If the mechanics are functioning correctly, perform an initial span using P388.

6.6 Factoring

6.6 Factoring

Note

For optimum accuracy in the factoring results, a routine zero calibration is recommended.

To calculate the value of a new or unknown test weight to the current span, the factoring procedure is used.

With the belt empty, the test weight in place, and the conveyor running:

```
P359 Factoring
Select 1-Weight, 2-Chain
```

Press the following keys:



Factoring Weight
Place weight and press ENTER.

For example: factor the test weight.

Press the following key:



Factoring Weight

Factoring in progress ##.## kg/m

The load reported while factoring is in progress.

Factoring Weight

Press ENTER to accept value 45.25

For example: the new value is accepted.

6.6 Factoring

Press the following key:



P017 Test Load Weight: V
Enter Test Load 45.25

For example: the current test load value.

Factoring is complete. Remove test weight and return to **RUN** mode if desired.

Note

If multispan function is used, the test load value is stored for the current multispan only.

6.7 Linearization

6.7 Linearization

Conveyor applications where the ideal belt scale location has been compromised, or where there is a high degree of variation in belt tension, typically cause the belt scale to report load non-linearly. The BW500 and BW500/L provides a linearizing function (P390 - P392) to correct for the deficiency in the weighing system and to provide an accurate report of the actual process.

To verify that the cause of the non-linearity is not mechanical:

- · Run the conveyor belt empty and stop it.
- Lift the belt off of the scale and suspend various test weights to the scale. If the load reported by the BW500 and BW500/L is non-linear, a mechanical problem is indicated. Refer to the belt scale manual to resolve the non-linearity by improved installation or repair.

If it is determined that the non-linearity is due to the weighing application, and not the actual belt scale, apply linearization by performing the following:

- zero calibration
- span calibration at 90 to 100% of design rate
- material tests at 90 to 100% of design rate
- · manual span adjust if required
- material tests at 1 to 5 intermediary flow rates where compensation is required.

Note

- All initial linearization points must be calculated with linearization turned off (P390 = 0).
- Compensation points must be at least 10% of the design load apart.
- calculate the percentage compensation for each flow rate tested.
 %compensation = (actual weight totalized weight * 100)/totalized weight where:
 actual weight = material test
 totalized weight = BW500 and BW500/L total

Note

- After the compensation has been programmed into the BW500 and BW500/L, a material test should be run to verify the effect of linearization.
- If additional compensation is required, it must be based on new material tests performed with the linearization turned off (P390 = 0).

Example:

A non-linearity with respect to the ideal response exists in a belt scale application with design rate of 200 t/h. It is decided to do material tests at 15, 30, 45, 60 and 75% of the design load. After performing a zero and a span calibration at 100% of the design load, followed by material tests and manual span adjust, five material tests were performed at 30, 60, 90, 120 and 150 t/h, as indicated by the BW500. The following data was tabulated. (This example is exaggerated for emphasis).

The material tests should be run at same belt speed, representative of normal operation; in this case 1.2 m/s. For each rate, record the corresponding load value by scrolling to the BW500 load display during running conditions or by calculation.


load = (rate/speed)

BW500 load	material test	BW500 total	compensation ^{a)}
kg/m	tonnes	tonnes	%
6.94	2.5	2.8	-10.7
13.89	5.0	4.5	11.1
20.83	7.5	7.9	-5.1
27.78	10.0	9.2	8.7
34.72	12.5	13.3	-6.0

a) calculation example: % compensation = $[(2.5 - 2.8) \times 100]/2.8$

^{= -10.7}

6.7 Linearization



- Actual weight per material test
- 2 Totalized weight by BW500
- 3 Belt scale response
- 4 Linearized BW500 response
- ⑤ Internal response 100% 150% of span
- 6 % compensation
- ⑦ Span (100%)


Program the BW500 as follows:

Parameter	Function
P390 = 1	linearization – on
P391-01 = 6.94	point 1, load
P391-02 = 13.89	point 2, load
P391-03 = 20.83	point 3, load
P391-04 = 27.78	point 4, load
P391-05 = 34.72	point 5, load
P392-01 = - 10.7	point 1, compensation
P392-02 = 11.1	point 2, compensation
P392-03 = - 5.1	point 3, compensation
P392-04 = 8.7	point 4, compensation
P392-05 = -6.0	point 5, compensation

Note:Often only one point of compensation is required, usually at a low load value. In the prior example, if compensation was only required at 6.94 kg/m, the programming could be as follows. Compensation is optimized by establishing the next load value that agrees with the material test, hence where compensation is zero and entering it as the next compensation point.

P390 = 1	linearization on
P391-01 = 6.94	point 1, load
P391-02 = 20.00	point 2, load
P392-01 = -10.7	point 1, compensation
P392-02 = 0	point 2, compensation

6.7 Linearization



- ① Actual weight per material test
- 2 Totalized weight by BW500
- 3 Belt scale response
- 4 Linearized BW500 response
- ⑤ Internal response 100% 150% of span
- 6 % compensation
- ⑦ Span (100%)

For Parameter reference, go to Parameters (Page 160)

Operating

7.1 Load Sensing

For the BW500 and BW500/L to calculate rate and totalize material flow along the belt conveyor, a load signal representative of weight of material on the belt is required. The load signal is provided by the belt scale. The BW500 and BW500/L is compatible with belt scales fitted with 1, 2, 4, or 6¹⁾ strain gauge type load cells. To function with LVDT type sensors, an optional LVDT conditioning card is required.

Refer to Specifications (Page 210), and Installation (Page 14) for belt scale requirements and connection.

1) Not available with BW500/L

7.2 Speed Sensing

For the BW500 and BW500/L to calculate rate and totalize material flow along the belt conveyor, a speed signal representative of belt speed is required. For optimum accuracy of the weighing system, and both constant and variable speed applications, a speed sensor is required. The design speed (P014) and speed constant (P015) need to be programmed.

In constant speed applications (no speed sensor), the BW500 can be programmed to provide an internal speed signal. This is achieved by entering the design speed (P014) and providing a contact closure across speed input terminals (17/18). The speed constant (P015) defaults to 'jumpered'. This contact should change to open when the conveyor is idle to prevent errant totalization.

In applications with two speed sensors, the BW500 can be programmed to provide differential speed. % slip can be calculated, using the difference between the two speed signals with reference to the first speed.²⁾

Refer to Specifications (Page 210) and Installation (Page 14) for speed sensor requirements and connection.

²⁾ Differential speed detection is not available on the BW500/L.

7.3 Differential Speed Detection

Dual point speed sensing is used for monitoring speed at two points in the system where a difference in speed can be detrimental to the equipment or its operation. The two speed sensors are typically applied on belt conveyors to give an alarm if excessive slip between the head pulley and tail pulley is detected. The secondary speed sensor is especially useful on variable speed conveyors, and may also be used to detect a malfunction in the primary speed sensor.

The BW500 provides a 12 V DC, 150 mA maximum, regulated power supply for both speed sensors. The primary speed sensor is used for all "Run" display integration, and is the reference value for differential speed detection. The primary speed sensor is generally reserved for the driven device (tail pulley). The second speed sensor is generally reserved for the driving device (head pulley), and is used for comparison to the primary speed sensor, for differential speed detection only.

The second speed signal is compared to the primary speed signal, and will initiate an alarm condition if the second speed signal is outside the programmed high and low alarm setpoints.

Connect the second speed sensor as shown in the Installation section (refer to *AuxiliarySpeed Sensor*), and program the second speed sensor as described in the following steps:

- 1. Program one of the Auxiliary Inputs as a Speed Sensor input P270-01 to 05 = 16 (Speed Sensor).
- 2. Program second speed sensors speed constant P015-02 = pulses per meter or foot (Refer to Start Up on page 29, for speed sensor programming).
- 3. Program one of the alarms for Differential Speed Detection alarm P100-01 to 05 = 10 (Speed Differential).
- 4. Program the High Alarm setpoint P101-01 to 05 = 110% (default).
- 5. Program the Low Alarm setpoint P102-01 to 05 = 90% (default).

Note

Differential speed detection is not available on the BW500/L.

7.4 Moisture Compensation

Moisture Compensation is used to compensate for the moisture component of the material being weighed. It factors out the moisture component of load, rate and total for all multispans selected. The factored value is meant to report the dry mean values of the material being conveyed.

The BW500 receives the static load cell signal, and adjusts the value of the load being displayed and integrated by the moisture percentage. The mA I/O card is required to accept the mA signal from the Moisture Meter. This mA signal can represent 0 to 100% moisture. The moisture percentage is displayed in P398-01. Using P398-02, the moisture percentage can be represented as a percentage of mass to be deducted from the total mass¹⁾.

¹⁾ The BW500/L allows for a fixed moisture content to be entered. See "P398-01 Moisture Content (Page 184)".

Example:

Setting P398-02 = 30% will allow the 4 - 20 mA input to correspond to 0 - 30% moisture.

The Zero and Span calibration is not affected by the presence of a moisture meter. It is understood that the calibrations are performed using dry static weights.

The Moisture Meter must be connected to the appropriate mA input and programmed as described in the following steps:

- 1. Enable mA input function for moisture compensation P255-01 or 02 = 4 (moisture compensation).
- 2. Set appropriate mA input range P250-01 or 02 = 2 (default is 4 20 mA).
- 3. Set mA input moisture ratio P398-02 = 100% (default).
- 4. Observe moisture percentage using P398-01.

7.5 Incline compensation

Incline compensation is used to compensate for the varying vertical force component applied to the belt scale due to varying inclination of the conveyor. The BW500 and BW500/L receives the static load cell signal, and adjusts the load displayed and integrated, by a factor of COSINE of the angle of incline.

The Inclinometer should be mounted to the conveyor stringer, parallel to the center of the belt scale. The mA I/O card is required to accept the mA signal from the Inclinometer. This mA signal must represent -30 to 30°. The incline angle is displayed in P399.

The dynamic load cell signal will vary with the incline of the conveyor. The BW500 and BW500/L load display and integration values will remain constant for the given load on the belt scale through the specified range of inclination.

The Zero and Span calibrations of the BW500 and BW500/L will be adjusted based on the angle of incline of the conveyor. The Zero and Span calibration can be performed at any angle. However, if incline compensation will be used, it must be enabled for all Zero and Span calibrations¹⁾.

¹⁾ The BW500/L allows for a fixed inclined angle to be entered. See "P399 Incline Sensing (Page 184)".

The Inclinometer must be connected to the appropriate mA input and programmed as described in the following steps:

- 1. Enable mA input function for incline compensation P255-01 or 02 = 5 (Incline compensation).
- 2. Set appropriate mA input range P250-01 or 02 = 2 (default is 4 20 mA).
- 3. Observe incline angle using P399.

7.6 Modes of Operation

RUN is the normal or reference mode of operation. It continuously processes the load and speed signals from the belt scale to produce internal load, speed and rate signals, which are in turn used as the basis for totalization, mA output, relay control, and communication data. The **RUN** display is programmed (P081) to scroll through rate, totalization (P647), load and speed; either manually by pressing the enter key, or automatically.

Rate	Rate	Load
Total 1	Total 2	Speed

If the BW500 is programmed for batch control, the batch display is added to the display scroll. Refer to Batch Control (Page 188) for more information.

From the RUN mode, access to the PROGRAM mode, and zero and span calibration is made.

The **PROGRAM** mode allows viewing and, with security permission (P000), editing parameter values. During **PROGRAM**, **RUN** mode functions are still active, that is.: rate, relay, mA output and totalization.

If the **PROGRAM** mode is left idle for a period of ten minutes, it automatically reverts to **RUN** mode.

Zero and span calibrations effectively halt the **RUN** mode while they are in progress. During this time, totalization ceases, and all mA outputs, except for PID, fall to zero.

7.7 Damping

Damping (P080) provides control over the speed at which the displayed readings and output functions respond to changes in their respective input function: load, speed and the internal rate signals. Changes in the displayed rate of material flow, material loading and belt speed are controlled by the damping. Relay alarm functions based on input functions of rate, load and speed, respond to the damped value.

Damping consists of a first order filter applied to the signal (reading or output value).

If mA damping (P220) is enabled (value other than 0), then the damping (P080), as it pertains to the mA function, is overridden, and responds independently at the specified mA output damping rate (P220).

Note

Damping (P080 or P220) is not applicable to the mA output when programmed for PID function (P201 = 4).

7.8 mA I/O (0/4-20 mA)

7.8 mA I/O (0/4-20 mA)

Output

The standard BW500 and BW500/L provides one isolated mA output. The output can be assigned (P201) to represent rate, load or speed. The output range can be set to 0 - 20 mA or 4 - 20 mA (P200). The 0 or 4 mA value corresponds to empty or zero condition, whereas the 20 mA value corresponds to the associated design value: rate (P011), load (P952), or speed (P014). The mA output can be limited for over range levels of 0 mA minimum and 22 mA maximum (P212 and P213 respectively). The output 4 and 20 mA levels can also be trimmed (P214 and P215 respectively) to agree with a milliammeter or other external mA device.

The mA output value can be tested to output a prescribed value using parameter P911. Refer to P911 (Page 204).

The optional mA I/O board provides two additional mA outputs¹⁾, programmable as outputs 2 and 3, using the same parameters as the standard output (1). If programmed for PID control, output 2 is assigned to PID control loop 1 and output 3 is assigned to PID control loop 2.

1) not available with BW500/L

Input

The optional mA I/O board provides two mA inputs, programmable as inputs 1 and 2. If programmed for PID control, generally, input 1 is assigned to PID control loop 1 and input 2 is assigned to PID control loop 2.

The input range can be set to 0-20 mA or 4-20 mA (P250), and assigned a function (P255), for example: PID setpoint. The 4 and 20 mA levels can be trimmed (P261 and P262) to agree with an external device. The external device could be a moisture sensor, or an inclinometer.

Note

mA inputs not available with BW500/L

7.9 Relay Output

The BW500 offers five single pole single throw (SPST) relays that can be assigned (P100) to one of the following alarm functions, the BW500/L offers two relays of the same type:

- rate: relay alarms on high and/or low material flow rate.
- load: relay alarms on high and/or low belt load.
- speed: relay alarms on high and/or low belt speed.
- differential speed¹⁾: relay alarms if second speed signal outside high and/or low alarm setpoints.
- diagnostic: relay alarms on error condition as it is reported. See "Troubleshooting".
- PID¹⁾²⁾: PID control setpoint deviation
- batch pre-warn¹⁾
- batch setpoint¹⁾

For rate, load, and speed alarm functions, the high and low alarm setpoints (P101 and P102 respectively) are required and must be entered in the appropriate units. The high alarm setpoint acts as the setpoint deviation alarm for relays programmed for PID setpoint deviation.

The on/off actuation at both high and low setpoints is buffered by the damping (P080) and the programmable dead band (P117), to prevent relay chatter due to fluctuations. The relay is normally energized; holding the normally open (n.o.) contact closed (can be programmed for reverse operation, P118). Upon an alarm condition, the relay is deenergized and the relay contact is opened. Once in alarm, the relay remains in alarm state until the alarm condition is removed.

Example:

P014 = 2m/s, design speed

P100 = 3, belt speed

P101 = 100% (2 m/s)


P102 = 20% (0.4 m/s)

P117 = 2% (0.04 m/s)

¹⁾ Not available with BW500/L

²⁾ Is offered only if the PID system (P400) is enabled.

7.10 Totalization



1 Actual low alarm

'off' = 22%

'on' = 20%

alarm 'on' is with relay de-energized

7.10 Totalization

The totalization function is based on the internal rate (mass per unit time) signal proportional to belt speed and load on the associated belt scale. It is not affected by the damping function (P080). The rate signal is sampled several times a second to accurately count the mass of material conveyed. The count is held in the master totalizer used to increment the internal totalizers and to produce a pulse signal for the remote totalizers.

The BW500 provides several separate totalizer functions:

7.10.1 Internal Totalizer

The BW500 provides several separate totalizer functions:

- local display (totalizers 1 and 2)
- verification totalizer (totalizer 3)
- material test totalizer (totalizer 4)
- batch total (totalizer 5)

7.10.2 External Totalizer

• totalizer outputs (remote totalizers 1 and 2)

To avoid totalizing material at flow rates below the low flow rate limit, the totalizer drop out limit (P619) is set to a percentage of the design load. Below this limit, totalization stops. When material flow returns to a rate above the drop out limit, totalization resumes.

Totalizer resolution or count value is set by the respective internal (P631) and external (P638) totalizer¹⁾ resolution parameters.

¹⁾ If the resolution selected causes the totalizer to lag behind the count rate, the next possible resolution is automatically entered.

Example:

Internal totalizer 1

Given: P005 = 1 (t/h), P631 = 4

Then: totalizer count increments by 10 for each 10 metric tonnes registered

External totalizer 1

Given: P005 = 1 (t/h), P638 = 5

Then: contact closure occurs once for every 10 metric tonnes registered

For remote totalization, the contact closure duration (P643) is automatically calculated upon entry of the design rate (P011) and remote totalizer (P638) parameters, so that the duration of contact closure allows the relay response to track the total up to 150% of the design rate. The value can be changed to suit specific contact closure requirements, such as in the case of programmable logic controllers. If the duration selected is inappropriate, the next possible duration is automatically entered.

7.10 Totalization

External Totalizer Calculation Example:

Design Rate = 50 t/h (P011)

External Totalizer Resolution Selected = 0.001 (P638 = 1)

External Totalizer Contact Closure Time selected = 30 msec (P643 = 30)

External Totalizer Cycle Time = 60 msec (External Totalizer Contact Closure Time X 2)

1. Calculate the maximum number of pulses per second for the Contact Closure Time selected (P643).

Maximum Number of pulses per second

- = 1 / External Totalizer Cycle Time
- = 1/0.060
- = 16.6 (which is rounded to a whole number of 16 in the BW500)
- 2. Calculate the pulses per second required for the External Totalizer Resolution selected (P638).

Pulses per second = ((Design Rate) * 150%) / (External Totalizer Resolution X 3600)

- $= (50 \text{ t/h } \times 150\%) / (0.001 \times 3600)$
- = 20.83

Because the required 20.83 pulses per second is greater than the maximum 16 pulses per second, the External Totalizer Resolution of 0.001 will not allow the External Totalizer to track up to 150% of the design rate. The External Totalizer Resolution will have to be increased to 0.01 or the External Totalizer Contact Closure Time will have to be decreased.

The totalizers are reset through the master reset (P999), the totalizer reset (P648), or through the keypad.

- master reset: the reset of all totalizer functions is included in the master reset.
- totalizer reset: totalizer reset can be used to reset internal totalizers 1 and 2, or totalizer 2 independently. Resetting the internal totalizers 1 and 2 resets the internal registers for external totalizers 1 and 2.
- Keypad: pressing the following keys while in the RUN mode resets internal totalizer 1:





Placing the internal totalizers on to the display scroll of the RUN mode is controlled by the totalizer display parameter (P647); displaying either one or both totalizers.

PID Control

The PID control algorithm in the BW500 is designed specifically to work for feed rate control applications. It is based on motor control type algorithms and includes several anti-wind up provisions.

One way to prevent wind up is to monitor the input speed frequency from the weighfeeder. If the input frequency drops below 5 Hz, the PID control output freezes at its current value. Otherwise, the output winds up to 100% if the feeder is shut off while there is still a set point greater than zero. When the feeder is turned back on, there would be a surge of product flow until the system regains stability. With anti-wind up, the feeder can be stopped and started with minimal disruption to the controlled flow rate.

To operate the BW500 as a controller, address the following:

- hardware
- connections
- · setup and tuning
- programming

Note

PID control not available on the BW500/L.

8.1 Hardware

For the BW500 to operate as a controller, install the optional mA I/O board. Refer to Installation (Page 14).

8.2 Connections

8.2 Connections

Connections to process instruments, in addition to standard operating connections, must be made.

Refer to:


- Installation (Page 14), specifically:
- Relay Output (Page 35), for relay connections
- mA I/O board (Page 38), for mA input and output connections
- Auxiliary Inputs (Page 32), for optional remote control

Connect the BW500 as either a:

- 1. setpoint controller load control
- 2. setpoint controller rate control
- 3. setpoint controller rate and load control
- 4. setpoint controller external process variable with or without rate and load control

PID loop	mA output	terminals (mA I/O)	mA input	terminal (mA I/O)
1	2	1 & 2	1	5 & 6
2	3	3 & 4	2	7 & 8


8.2.1 Setpoint Controller – Rate Control



- ① Shearing weighfeeder
- ② Belt scale
- 3 Motor speed controller
- 4 Control output (P201-02 = 4)
- ⑤ Optional remote setpoint rate (P255-01 = 1)
- 6 Load
- 7 Speed
- Speed sensor


8.2 Connections

8.2.2 Setpoint Controller – Load Control



- ① Belt Scale
- 2 Motor speed controller
- ③ Control output (P201-02 = 4)
- 4 Optional remote setpoint rate (P255-01 = 1)
- ⑤ Load
- 6 Speed
- 7 PID 1 process value source rate (P402-01 = 1)
- Speed sensor

8.2.3 Setpoint Controller – Master/Slave Control




- (1) Belt scale
- ② Motor speed controller
- \bigcirc Control output rate (P201-02 = 4)
- 4 Remote ratio setpoint rate (P255-01 = 1 P418-01 to suit)
- (5) Load
- 6 Speed
- Speed sensor
- 8 PID 1 process value source rate (P402-01 = 1)
- 9 Belt scale
- Motor speed controller
- \bigcirc Control output rate (P201-02 = 4)
- ② Rate* (P201-01 = 1)
- \bigcirc Remote setpoint rate (P255 01 = 1)
- ① Load
- (15) Speed
- Speed sensor
- PID 1 process value source load (P402-01 = 1)

Figure 8-1 *P201-03=1 also applicable

8.2 Connections

8.2.4 Setpoint Controller – Rate and Load Control



- ① Motor speed controller rate
- 2 Motor speed controller load
- ③ PID 1 control output, (P201-02 = 4)
- 4 PID 2 control output, (P201-03 = 4)
- ⑤ PID 1 remote setpoint load (P255-01 = 1)
- 6 PID 2 remote setpoint rate (P255-02 = 1)
- 7 Load
- 8 Belt scale
- 9 Speed
- © PID 1 process value source load (P402-01 = 2), PID 2 process value source rate (P402-02 = 1)
- ① Speed sensor

8.3 Setup and Tuning

Before proceeding, it would be beneficial to qualify and quantify the terms you will encounter in the setup and tuning of the control system.

8.3.1 Proportional Control (Gain), P

The P term on the BW500 adjusts the control output based on the difference between the set point and the measured flow rate. A higher P term makes the BW500 more sensitive and faster to react to changes or disturbances. If set too high, the BW500 becomes less stable, and more susceptible to oscillations in the control output.

allowable input range: 0.000 to 2.000

• typical operating range: 0.300 to 0.600

default value: 0.400

The control output cannot reach the setpoint using only the P term. Since the P term acts on the difference between the setpoint and process variable, a small difference between these two always exist and the difference is never zero. A small P term can get the process very close to set point, but it would take a very long time. At the very least, an I term is required to eliminate the offset created by the P term.

8.3.2 Integral Control (Automatic Reset), I

The I term on the BW500 is used to increase or reduce the amount of control output to eliminate the offset caused by the P term. The I term acts on the accumulation of the error over small increments of time. As the process reaches setpoint and the error becomes small, the effect of the I term decreases. A higher I term makes the BW500 faster to react to changes, but can also make it less stable.

• allowable input range: 0.000 to 2.000 typical operating range: 0.100 to 0.300


default value: 0.200

The P and I terms together can make a suitable control algorithm and for many applications, they work fine. However, if faster response to changes is desired, it is necessary to use larger P and I terms. Unfortunately, larger terms can make the system unstable. A derivative term is needed to influence the control output as the process variable approaches the set point.

8.3 Setup and Tuning

8.3.3 Derivative Control (Pre-Act or Rate), D

The *D* term on the BW500 influences the control output based on changes in the magnitude and direction of the change in error. If there is a constant error, the *D* term has no effect. As the error gets larger, the *D* term combines with the P term to make the BW500 control output respond faster. When the error is getting smaller, the *D* term acts to reduce the amount of control output to help prevent overshooting the set point. In general, a higher *P* term will require a larger *D* term.



- allowable input range: 0.000 to 1.000
- typical operating range: 0.010 to 0.100
- default value: 0.050

The result of the derivative action is that it can make a system more responsive and more stable at the same time.

8.3.4 Feed Forward Control, F

On the BW500, the F term is used to adjust the control output based on a setpoint change. The use of this term can make the system reach the new setpoint faster. If the term is not used, the system responds using the P, I and D terms only. The difference between the new setpoint and the process variable is the error and the control algorithm responds to eliminate this new error.

When the *F* term is used and a new setpoint is entered, a proportion of the difference between the new setpoint and the process variable is automatically added on to the control output. This shifts the process variable closer to the new setpoint faster than using the *P*, *I* and *D* terms alone. This is done on a one time basis.

allowable input range: 0.000 to 1.000

• typical operating range: 0.250 to 0.550

• default value: 0.300

The PID control function of the BW500 can be configured to operate in several modes.

· controller output: direct acting

feedback: rate, load, or external

• control: local or remote (ratio) setpoint

8.4 PID Setup and Tuning

Proper tuning of the control PID terms is essential to system operation and optimum performance from the feeder. The recommended procedures for tuning the PID control terms at initial start-up are described in this section.

8.4 PID Setup and Tuning


8.4.1 Initial Start-Up


Although the default values of the P, I, D, and F terms will suit the majority of applications, shearing weigh feeders in particular, some tuning will be necessary nonetheless.


There are several techniques and procedures for tuning conventional PID controllers, some work better depending upon the application. We recommend using "closed-loop cycling" for the BW500 integrator/controller for feed rate control. This technique focuses on tuning the P term first while disabling the I and D terms. This is followed by adding and tuning the I term, then the D term. To outline this procedure:

- 1. With the P term set to its default value of 0.400, disable the I, D, and F terms by setting them to 0.000.
- 2. Enter a feed rate setpoint that is 30% of the designed maximum flow rate.
- 3. Having applied the test weights or chain provided, start the feeder and observe the time it takes the feeder to reach setpoint, also observe the oscillation around setpoint.

4. Adjust the P term accordingly for consistent oscillation and error. Progressively decrease the P term value if there is too much oscillation and error. Likewise, increase the value if the error is not consistent and oscillating around the setpoint. Refer to figures 1, 2, and 3 below.










- 5. Once the P term value is set to give the control output of the BW500 consistent oscillation and the error is at its minimum, turn the feeder off.
- 6. The I term value can now be set. Begin by entering the default value of 0.2.
- 7. Restart the feeder (test weights or chains still applied) and feed rate setpoint entered.

8.4 PID Setup and Tuning

8. Again observe the oscillation of the control output. Compare results to the figures 4,5 and 6 below.







- 9. The *D* term is not critical in typical shearing type weigh feeder applications. The purpose of the *D* term is to anticipate where the process is heading by looking at the time, rate, and direction of change of the process variable. The *D* term becomes very useful in applications where the material control point is far away from the measuring point. An example of this would be a weigh belt or conveyor with a belt scale (constant speed) being fed from a prefeeder some distance or more than a few seconds process time from the scale.

 A properly set *D* term will make the initial oscillations around the setpoint smaller, as in figure 6. A D term set too high induces high oscillations, as in figure 4. Omission of the *D* term, or set too low, shows no effect on the system.
- 10. The above closed loop cycling procedure allows ease in start up, but final adjustments may be necessary in actual process operation.

8.5 Programming

The BW500 is software ready, however the controller function must be specifically programmed in addition to programming of parameters P001 through P017.

The BW500 offers programming for two separate PID controls, 1 and 2. The controller being programmed is identified by the suffix to the parameter number. e.g. P400-01 indicates that PID for control system 1 is accessed.

Note

All programming should be done in the PID manual mode.

Access

```
P400-01 PID System E
Select: 0-Off, 1-Manual, 2-Auto 0
```

Select 1-manual to program PID parameters

Off disables the PID parameter set, P401 to P418. They are not accessible.

Manual: the control output is the manual output P410.

Auto: engages the PID controller function. This can also be done using the following key:



Note

For the mA output:

- mA output 2 (P201-02) is normally reserved for controller 1. The signal is output at terminals 1 and 2 on the mA I/O board.
- mA output 3 (P201-03) is normally reserved for controller 2. The signal is output at terminals 3 and 4 on the mA I/O board.

8.5 Programming

```
P201-02 mA Output Function E
Select: 1-Rate, 2-Load, 3-Speed, 4-PID 1
```

Select the PID function.

Note

For the mA input:

- mA input 1 is an external signal normally reserved for controller 1. The signal is input at terminals 5 and 6 on the mA I/O board.
- mA input 2 is an external signal normally reserved for controller 2. The signal is input at terminals 7 and 8 on the mA I/O board.

```
P250-01 mA Input Range E
Select 1- 0 to 20, 2-4 to 20 2
```

Select the appropriate range for the mA input signal.

```
P255-01 mA Input Function E
Select: 0, 1-PID SP, 2-PID PV 0
```

Assign either 1: PID setpoint, or 2: process variable as the function of the mA input.

```
P401-01 PID Update Time E
Readings between PID Updates 1
```

Enter the value, e.g. nominal value of 1.

```
P402 Process Variable Source E

1- Rate, 2-Load, 3-mA In
```

Select the source. Rate and load are internal values.

```
P405-01 Proportional Term E
Enter 0.40
```

Enter the value for the proportional term, for example: nominal value of 0.4.

P406-01 Integral Term E
Select 1- 0 to 20, 2-4 to 20 0.2

Enter the value for the integral term, for example: nominal value of 0.2.

P407-01 Derivative Term E
Enter 0.05

Enter the value for the derivative term, for example: nominal value of 0.05.

P408-01 Feed Forward Term E
Enter 0.3

Enter the value for the feed forward term, for example: nominal value of 0.3.

P410-01 Manual Mode Output E
Current Output Value 0

% value of output during manual operation, P400 = 1.

P414-01 Setpoint Configuration E
0-Local, 1mA In 0

Selection of setpoint source: 0 = local (keypad or Dolphin Plus), 1 = mA input

Local: the setpoint is the value entered into P415

mA Input 1: the setpoint is the mA value on input 1, terminals 5 and 6 on the mA I/O board mA Input 2: the setpoint is the mA value on input 2, terminals 7 and 8 on the mA I/O board

P415-01 Local Setpoint Value Enter Setpoint 0

Enter the setpoint value in engineering units. Not applicable if P414 = 1.

P416-01 External Setpoint E
Setpoint 0

Current setpoint value in engineering units, obtained from the mA input.

8.5 Programming

```
P418-01 Remote Setpoint Ratio E
Enter % of Master Output 100.000
```

Increase or decrease to scale input setpoint if desired.

```
P250-01 mA Input Range E
Select 1- 0 to 20, 2-4 to 20 2
```

Select the appropriate range for the mA input signal.

```
P255-01 mA Input Function E
Select 0, 1-PID SP, 2-PID PV 0
```

Assign either 1: PID setpoint, or 2: process variable as the function of the mA input.

Note

The PID setpoint can be modified while in RUN mode using the up/down arrow keys.

Batching

The batching process, as it relates to the BW500 operation, can be defined as the transfer of a predetermined quantity of material.

The process supports a count up operation (P560), in that the total (totalizer 5) begins at zero and increments up to the programmed setpoint (P564). A relay (RL1 through 5) programmed as the batch setpoint function (P100 = 8) is actuated when the material total reaches the setpoint. The relay contact acts as an interlock to the material feed to end the batch.

Another relay can be programmed as a pre-warn alarm (P100 = 7), to alert the process that batch end is near. The relay is actuated when the material total reaches the prewarn setpoint (P567) at some practical value below the batch setpoint. The pre-warn function is enabled/disabled from the batch process through P566.

For batch operations, the following must be addressed:


- Connections
- Programming
- Operation


Note

Not available on the BW500/L

9.1 Connections

9.1.1 Typical Ladder Logic





- * Typical relay assignment. Relays 1-5 are available for batch setpoint or pre-warm alarm function.
- ♦ Typical auxiliary input assignment. Inputs 1-5 are available for batch reset.
- ① BW500 / RL1* batch stop
- ② Stop
- 3 Start
- 4 Motor contactor / MC1
- ⑤ Alarm
- 6 BW500 / RL2* pre-warm
- 3 Batch reset
- 8 BW500/ aux 1

9.2 Programming

The pre-warn function is optional.

The setpoint associated with the pre-warn relay is entered in P567, batch setpoint.

The setpoint associated with the batch relay is entered in P564, batch pre-warn setpoint.

Batch Operation				
Access P100, relay function	select relay (1 – 5)			
	select function 7, pre-warn			
Access P560 Batch Mode Control	select 1, enable batch operation			
if batch pre-warn is selected access P567, batch pre-warn setpoint	enter the pre-warn total			
Access P568 Batch Pre-act	set to OFF (0) or AUTO (1) or manual (2)			

Relays			
Access P100, Relay Function	select relay (1 – 5)		
	select function 7, Pre-Warn		

9.3 Operation

9.3 Operation

Once the BW500 relays are connected to the process logic, and it is programmed, the BW500 is ready for totalizing the batch and stopping the process when the batch setpoint is reached. The batch operation: start, pause, resume, and cancel are controlled externally by the process control (e.g. PLC)

Place the unit in the RUN mode.

Press ALT DISP until the batch screen is displayed.

```
Rate 0.00 kg/h SP: 20.000
Batch 0.00 kg
```

For example: relay 1 is programmed for pre-warn, P100-1=7.

Start running the batch.

The display will show the rate of material flow and the batch total, as well as the batch setpoint. If pre-warn is used, relay contact is open.

When the batch total reaches the pre-warn setpoint, if programmed, the alarm event is removed and the assigned relay contact is closed.

```
Rate 123.4 kg/h SP: 20.000
Batch 17.00 kg ALM 1
```

The process continues, and when the batch total reaches the batch setpoint, the alarm event is displayed and the assigned relay is actuated (contact opened). Typically the relay contact would be integrated into the batch control logic to end the process.

```
Rate 123.4 kg/h
Batch 20.00 kg ALM 12
```

Relay 2 is programmed for batch setpoint, P100-2=8.

When the next batch is to be run, pressing the following keys then on the local keypad, or providing a momentary contact closure across an auxiliary input (programmed as batch reset, P270 = 8), sets the alarm display and resets the batch total to zero, and the relay contact to its closed state.





Rate 0.00 kg/h Batch 0.00 kg SP: 20.000

Note


The batch setpoint can be modified in RUN mode using the up/down arrow keys.

9.3.1 Pre-act Function

If repetitive batches are being run, the pre-act function (P568) can be enabled to automatically trip the setpoint relay before or after the batch setpoint is reached to assure best batch accuracy.

Communications 10

The BW500 and BW500/L is a sophisticated belt scale integrator that can communicate status back to a SCADA system using a serial device such as radio modems, leased lines, or dial up modems.



- ① Dial-up modem
- (2) Radio modem
- (3) Leased line modem

The BW500 and BW500/L supports two protocols: Dolphin and Modbus. Dolphin is a proprietary Siemens Milltronics protocol designed to be used with Dolphin Plus. Modbus is an industry standard protocol used by popular SCADA and HMI systems.

10.1 BW500 and BW500/L and SmartLinx

In addition to three onboard communication ports, the BW500 and BW500/L is compatible with Siemens' SmartLinx communication modules which provide an interface to popular industrial communication systems.

This section only describes the onboard communications. For more information on SmartLinx, please consult the appropriate SmartLinx manual.

10.2 Connections



When a SmartLinx card is installed and P799 = 1, the parameters that the SmartLinx card is writing to the BW500 and BW500/L will be continuously updated. Therefore, if you connect a SmartLinx card to the BW500, set P799 = 1 and not write anything to the SmartLinx card, your setpoints will be 0.

There are three serial communication ports on the BW500 and BW500/L:

Port	Description	
1	RS-232, Terminals 31 to 34	
2	RS-485, terminals 35 to 40	
3	RS-232, RJ-11 modular telephone jack	

Refer to the Installation (Page 14) for wiring diagrams specific to each port.

10.2.1 Wiring Guidelines

Improper wiring and choice of cables are the most common sources of communication problems. Listed below are some suggested guidelines:

- 15 meters (50 feet) for RS-232
- 1200 meters (4000 feet) for RS-485
- Ensure that communication cable is run separately from power and control cables (i.e. do not tie wrap your RS-232 cable to the power cable or have them in the same conduit).
- cable is shielded and connected to ground at one end only
- 24 AWG (minimum)
- follow proper grounding guidelines for all devices on the bus
- use good quality communication grade (shielded twisted pairs) cable that is recommended for RS-232.

10.3 Configuring Communication Ports

10.3 Configuring Communication Ports

The BW500 and BW500/L communications ports are setup by a series of parameters (P770 – P789) which are indexed by port.

The communication parameters are indexed to the following:

Port	Description		
1	RS-232, Terminals 31 to 34		
2	RS-485, terminals 35 to 40		
3	RS-232, RJ-11 modular telephone		

f indicates the factory setting.

Note

Changes to these parameters are not effected until the power to the unit is turned off and then back on.

10.3.1 P770 Serial protocols

The communications protocol used between the BW500 and BW500/L and other devices for the selected port, ports 1 to 3 (P770-01 to -03).

The BW500 and BW500/L supports Siemens Milltronics' proprietary "Dolphin" data format, as well as the internationally recognized Modbus standard in both ASCII and RTU formats. It also supports direct connection of a printer.

The Siemens protocol is compatible with the Dolphin Plus configuration program. See the Siemens web site for information on this PC product (http://www.siemens.com/processautomation (http://www.siemens.com/processautomation)).

The Modbus protocol is an open standard developed by AEG Schneider Automation Inc. Specifications are available from their web site (http://www.modicon.com/ (http://www.modicon.com/)).

Other protocols are available with optional SmartLinx cards.

Values

Of (01 and 02) communications disabled

1f (03) Siemens Milltronics "Dolphin" protocol

2 Modbus ASCII slave serial protocol

3 Modbus RTU slave serial protocol

4 printer

Note

BW500 and BW500/L must be in RUN mode to allow for the print operation.

10.3 Configuring Communication Ports

10.3.2 P771 Protocol address

Note

Applicable only to ports programmed for Modbus RTU or Modbus ASCII (P770).

The unique identifier of the BW500 and BW500/L on the network for the selected port, ports 1 to 3 (P771-01 to -03).

For devices connected with the Siemens protocol this parameter is ignored. For devices connected with a serial Modbus protocol this parameter is a number from 1- 247. It is up to the network administrator to ensure that all devices on the network have unique addresses.

Do not use the value "0" for Modbus communications as this is the broadcast address and is inappropriate for a slave device.

Values

0 to 9999 (f = 1)

10.3.3 P772 Baud Rate

The communication rate with the master device for the selected port, ports 1 to 3 (P772- 01 to -03).

The baud rate chosen should reflect the speed of the connected hardware and protocol used.

Values

1f (01 and 02) 4800 baud

2 9600 baud

3f (03) 19,200 baud

10.3.4 P773 Parity

The serial port parity for the selected port, ports 1 to 3 (P773-01 to -03).

Ensure that the communications parameters are identical between the BW500 and BW500/L and all connected devices.

For example many modems default to N-8-1 which is: No parity, 8 data bits, and 1 stop bit.

Values

Of none

1 even

2 odd

10.3.5 P774 Data bits

The number of data bits per character for the selected port, ports 1 to 3 (P774-01 to -03).

Protocol	P744 Value		
Modbus RTU	8		
Modbus ASCII	7 or 8		
Dolphin Plus	7 or 8		

Note

If using port 2, 8 data bits must be used.

Values

5 to 8 (f = 8)

10.3.6 P775 Stop bits

The number of bits between the data bits for the selected port, ports 1 to 3 P775-01 to -03).

Values

1 or 2 (f = 1)

10.3.7 P778 Modem attached

Sets port 1 (P778-01) to use an external modem.

Any connected modem must be set up to auto-answer incoming calls. The BW500 and BW500/L does not automatically configure the modem.

Autobaud (enabled by P778=1)

When the BW500 and BW500/L is powered up or the P779 Modem Inactivity Timeout expires three carriage returns are sent to the modem to allow it to set its serial connection to P772 Baud Rate.

If a connection is made with the modem at a different baud rate the BW500 and BW500/L will attempt to use that rate instead of the P772 value. For troubleshooting purposes the baud rate on the modem can be hard-coded to the rate set on the BW500 and BW500/L. See your modem documentation for information on fixing the baud rate.

Values

Of no modem connected

1 modem connected

10.3 Configuring Communication Ports

10.3.8 P779 Modem idle time

Sets the time in seconds that the BW500 and BW500/L will keep the modem connected even though no activity is happening.

To use this parameter ensure that P778=1.

This parameter allows for reconnection to the BW500 and BW500/L unit after an unexpected disconnect. Ensure that the value is low enough to avoid unnecessary delays when an unexpected disconnect occurs but long enough to avoid timeout while you are still legitimately connected.

Hanging Up

If the line is idle and the P779 Modem Inactivity Timeout expires then the modem is directed to hang up the line. This is done with the Hayes commands:

- · two second delay
- +++
- two second delay
- ATH

Ensure that P779 is set longer than the standard polling time of the connected master device. O disables the inactivity timer.

Values

0-9999: 0 (f = 1)

10.3.9 P780 RS-232 Transmission interval

Note

Applicable only to ports programmed for printer communication (P770).

Sets the interval between transmissions to be applied to the selected port, ports 1 to 3 (P780-01 to -03).

Enter the period in minutes (f = 0)

10.3.10 P781 Data message

Note

Applicable only to ports programmed for printer communication (P770).

Sets the data message to be delivered via the selected port, ports 1 to 3 (P781-01 to -03). All messages and printouts include time and date²⁾.

Entry:

```
0f = no message
```

- 1 = rate
- $2 = total^{1)}$
- 3 = load
- 4 = speed
- 5 = rate, total¹⁾, load and speed
- $6 = \text{rate and total}^{1)}$
- $7 = batching^{2}$
- 8 = rate and speed
- 9 = quick start parameters (P001 P017)
- 10 = all parameters
- 1) Totalizer 1 and/or 2 as set by P647, Totalizer Display.
- 2) Not available with BW500/L

10.3.11 P799 Communications Control

Assigns programming control either locally through the keypad or Dolphin Plus (P770 = 1), or remotely through Modbus protocol (P770 = 2 or 3) or SmartLinx.

Entry:

0 = local

1 = remote



When a SmartLinx card is installed and P799 = 1, the parameters that the SmarlLinx card is writing to the BW500 and BW500/L will be continuously updated. Therefore, if you connect a SmartLinx card to the BW500 and BW500/L, set P799 = 1 and not write anything to the SmarLinx card, your setpoints will be zero.


10.4 Dolphin Protocol

10.4 Dolphin Protocol

The protocol is available on all communications ports on all units. This protocol is not available for third party use.

The primary use of this protocol is to connect the BW500 and BW500/L to Siemens Dolphin Plus configuration software.

Dolphin Plus Screen Shot



10.5 Modbus RTU/ASCII Protocol

Modbus is an industry standard protocol owned by Schneider Automation Inc.¹⁾ and is used throughout process control industries for communication between devices. Modbus RTU and Modbus ASCII are both master-slave type protocols. BW500 and BW500/L's Modbus is a slave unit.

BW500 and BW500/L supports both the RTU and ASCII version of Modbus and attempts to automatically detect the type when a connection is made.

Note

- host should wait at least 500 ms between a message polls to the BW500 and BW500/L
- for Modbus RTU, the host should wait at least 1000 ms for a response from the BW500 and BW500/L. In Modbus ASCII mode the suggested timeout is 1500 ms.

A brief description of Modbus RTU and Modbus ASCII is given in this manual. For a full description of the Modbus protocol, contact your local Schneider representative. Also you may try their web site at:

http://www.modicon.com/ (http://www.modicon.com/)

At the time of publication of this manual, the Modbus Protocol was located under products / technical publications / communications products / Modbus protocol.

Note

Siemens does not own the Modbus RTU protocol. All information regarding that protocol is subject to change without notice.

10.5.1 How Modbus Works

As mentioned above, Modbus is a master-slave type protocol. This can also be referred to as a query-response protocol. What both of these terms mean is that on the network, there is one master which requests information from multiple slave devices. The slave devices are not permitted to talk unless they have been asked for information. When responding, the slaves will either give the information that the master has requested or give an error code consisting of why it can not give the information or that it did not understand the request. Refer to Error Handling (Page 158).

All BW500 and BW500/L information is mapped into the Modbus holding registers so that Modbus function code 03 can read from them and Modbus function code 06 and 16 can write to them.

¹⁾ Modicon is a registered trademark of Groupe Schneider.

10.5 Modbus RTU/ASCII Protocol

10.5.2 Modbus RTU vs. ASCII

There are two main differences between Modbus RTU and Modbus ASCII. The first is that Modbus RTU encodes the message in 8-bit binary, while ASCII encodes the message in ASCII characters. Therefore, one byte of information would be encoded into 8 bits for RTU and into two ASCII characters for ASCII (which would be two 7-bit units). The second difference is that the error checking method is different (see below).

Modbus RTU has the advantage that it has a much greater data throughput than ASCII. Modbus ASCII has the advantage that it allows time intervals of up to one second to occur between characters without causing an error. Either protocol works with the BW500 and BW500/L.

10.5.3 Modbus Format

Note

When using a commercial Modbus driver all of the message details are handled for you.

To give you a better idea of how a Modbus message works, a master on network would send a message in a format similar to this:

Station address	Function code	Information	Error check		
Where:					
Station address		the network address of cessed	the slave being ac-		
Function Code		number that represent a Modbus command, either:			
		03 read function			
Information depends or		depends on function co	unction code		
Error Check		Cyclical Redundancy Ch Longitudinal Redundan ASCII			

There is more to the frame than is described above, this is shown to give the user a general idea of what is going on. For a full description, refer to the Modbus specifications.

10.5.4 Modbus Register Map

The memory map of the BW500 and BW500/L occupies the Modbus holding registers (R40,001 and up).

The BW500 and BW500/L was designed to make it easy for users to get useful information via Modbus. The following chart gives an overview of the different sections.

Register Map for BW500 and BW500/L

Map Legend	Description
Type:	Arbitrary classification of registers.
Description:	Brief description or title of associated register.
Start:	Provides the starting address for the register(s) where the parameter values are to be read from or written to.
Number R:	The number of registers required to read or write the complete parameter value. Where the number of registers (6) are addressed in incrementing sequence from the start register.
Parameter Values:	Refer to Parameter Values.
Read:	Identifies the read / write capability for the register being addressed.
Reference:	Provides reference documentation for the register being addressed.

10.5 Modbus RTU/ASCII Protocol

Type	Description	Start	# R	Parameter Values	Read	Reference
Format	Format Word for 32 bit variables	40,062	1	0 - 1	r/w	Refer to Modbus Register Map (cont'd) section given below.
ID	Device Identifier	40,064	1	2	r	Refer to Modbus Register Map (cont'd) section given below.
Handshaking	Parameter	40,090	1	0-999	r/w	Refer to the
Area (Pa- rameter Access)	Primary Index	40,091	1	0 - 9	r/w	Modbus Register Map
Access)	Secondary Index	40,092	1	0 - 9	r/w	(cont'd) section giv-
	Format Word	40,093	1	bit mapped	r/w	en below.
	Read Value (word 1)	40,094	2	32 bits	r	
	Write Value (word 1)	40,096	2	32 bits	r/w	
Date and	YYYY	41,000	1	1996-2069	r/w	Refer to the Date and Time
Time ^{a)}	MM	41,001	1	1 - 12	r/w	
	DD	41,002	1	1 - 31	r/w	(R41,000 – 41,006) section giv- en below and also P008 (Page 162)
	hh	41,003	1	00 - 23	r/w	Refer to the Date and
	mm	41,004	1	00 - 59	r/w	
	SS	41,005	1	00 - 59	r/w	Time (R41,000 – 41,006) section given below and also P009 (Page 162)
	Time Zone	41,006	1	-12 - 12	r/w	see P739 (Page 200)
Process	Rate	41,010	2	32 bits	r	Refer to the
Values	Load	41,012		32 bits	r	Process Values (R41,010 – R41,048) section given below.
	Speed	41,014	2	32 bits	r	
	Total 1	41,016	2	32 bits	r	
	Total 2	41,018	2	32 bits	r	

Туре	Description	Start	# R	Parameter Values	Read	Reference
	Device State	41,020	1	bit mapped	r	Refer to the Process Values (R41,010 – R41,048) section giv- en below.
	Command Control	41,022	1	bit mapped	r/w	Refer to Command Controls (41,022) given below.
	Multi-Span Selection	41,024	1	1 - 8	r/w	Refer to Multispan (Page 81) and P365 (Page 181).
	Total 1 dec- imal places	41,025	1	1 - 3	r/w	Refer to Read/Write
	Total 2 decimal places	41,026	1	1 - 3	r/w	(R41,025 – R41,026) Total Deci- mal Places section giv- en below.
	Batch total	41,027	2	32 bits	r	Refer to P931 (Page 204).
	PID 1 Set- point ^{a)}	41,040	2	32 bits	r/w	Refer to P415
	PID 2 Set- point ^{a)}	41,042	2	32 bits	r/w	(Page 187).
	Batch Set- point ^{a)}	41,044	2	32 bits	r/w	Refer to P564. (Page 189)
	Batch Pre- warn Set- point ^{a)}	41,046	2	32 bits	r/w	Refer to P567 (Page 189).
I/O	Discrete Input	41,070	1	bit mapped	r	Refer to the I/O (R41,070
	Relay Out- puts	41,080	1	bit mapped		- 41,116) section giv- en below.
	mA Inputs ^{a)}	41,090	2	0000 - 20,000	r	en below.
	mA Outputs	41,110	3 _{b)}	0000 - 20,000	r	
Diagnostic	Diagnostic State	41,200	1	number code	r	Refer to the Trouble- shooting (Page 207)s ection.
	P940, load cell A, index 1	41,201	2	32 bits	r	Refer to P940 Load Cell mV

10.5 Modbus RTU/ASCII Protocol

Туре	Description	Start	# R	Parameter Values	Read	Reference
	P940, load cell B, index 2	41,203	2	32 bits	r	Signal Test (Page 205) and P943
	P940, load cell C, index 3 ^{a)}	41,205	2	32 bits	r	Load Cell A/D Reference (Page 205)
	P940, load cell D, index 4a)	41,207	2	32 bits	r	(1 age 200)
	P943, index 1	41,209	2	32 bits	r	
	P943, index 2 ^{a)}	41,211	2	32 bits	r	
	P943, index 3 ^{a)}	41,213	2	32 bits	r	
	P943, index	41,215	2	32 bits	r	
	P943, index 5	41,217	2	32 bits	r	
	P943, index 6 ^{a)}	41,219	2	32 bits	r	
	P943, index 7 ^{a)}	41,221	2	32 bits	r	
PID Tuning ^{a)}	PID 1 Pro- portional Term	41,400	2	32 bits	r/w	Refer to P405 (Page 186).
	PID 2 Pro- portional Term	41,402	2	32 bits	r/w	
	PID 1 Integral Term	41,404	2	32 bits	r/w	Refer to P406
	PID 2 Integral Term	41,406	2	32 bits	r/w	(Page 186).
	PID 1 Deriva- tive Term	41,408	2	32 bits	r/w	Refer to P407
	PID 2 Deriva- tive Term	41,410	2	32 bits	r/w	(Page 186).
	PID 1 Feed Forward Term	41,412	2	32 bits	r/w	Refer to P408 (Page 186).
	PID 2 Feed Forward Term	41,414	2	32 bits	r/w	
	PID 1 Re- mote Set- point Ratio	41,416	2	32 bits	r/w	Refer to P418 (Page 188).
	PID 2 Re- mote Set- point Ratio	41,418	2	32 bits	r/w	

a) Not available with BW500/L

b) BW500/L has 1 output only

10.5.5 Modbus Register Map (cont'd)

Format (R40,062)

This value determines the format of all unsigned, double-register integers (UINT32), except for those in the direct parameter access.

0 indicates that the most significant byte (MSB) is given first

1 indicates that the least significant byte (LSB) is given first

For more information on this data format see page 108 and also P742 Word Order Parameter

Device Identifier (R40,064)

This value identifies the Siemens device type and is "2" for the BW500 and BW500/L.

Handshaking Area (Parameter Access)

Built into BW500 and BW500/L is an advanced handshaking area that can be used to read and write 32 bit parameters.

Mapping

Parameter Read and Write (40,090 – 40,095) is a series of six registers that are used for reading and writing parameter values to and from the BW500 and BW500/L. The first three registers are always unsigned integers representing parameters and index values. The second three registers are the format and value(s) of the parameter.

All parameters normally accessed through the hand-held programmer are available through these registers:

Address	Description
40,090	Parameter (integer)
40,091	Primary Index (integer)
40,092	Secondary Index (integer)
40,093	Format word (bit mapped)
40,094	Read value, word 1
40,095	Read value, word 2
40,096	Write value, word 1
40,097	Write value, word 2

Reading Parameters

To read parameters through Modbus follow these steps:

- 1. Send the parameter, its primary index, and its secondary index (usually 0) and format to registers 40,090, to 40,093.
- 2. Wait until you can read the above values from the registers (40,090 to 40,093).
- 3. Read the value from registers 40,094 and 40,095.

10.5 Modbus RTU/ASCII Protocol

Writing Parameters

To set parameters through Modbus follow these steps:

- 1. Send the parameter, its primary index, and its secondary index (usually 0) to registers 40,090, 40,091, and 40,092.
- 2. Write the value to registers 40,096 and 40,097
- 3. Write the desired format word to register 40,093 to enable the BW500 and BW500/L to interpret the value correctly.

Format Register:

Bits	Values	Description
1 - 8	0 - 2	Error Code
9 - 11	0 - 7	decimal offset
12	0/1	decimal shift, Right (0) or Left (1)
13	0/1	Numeric format: Fixed (0) or Float (1)
14	0/1	Read or Write of data, Read (0), Write (1)
15	0/1	Word order: Most Significant word first (0), Least Significant Word first (1)
16		Reserved

The bits listed above are in order from least to most significant:

-																
	16	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1

For example, to format the output value so that it is shown with two decimal places shifted to the left the format bits would look like this:

16	0	reserved
15	0	most significant first
14	0	read
13	1	float format

12	0	
11	0	decimal offset +2
10	1	
9	0	
8	0	
7	0	
6	0	
5	0	no error code
4	0	
3	0	
2	0	
1	0	

The value sent to the BW500 and BW500/L is 000100100000000 binary or 4608 decimal.

The value **4608** is sent as an integer to register 40,093 to format the output words 40,094 and 40,095 accordingly.

If the numeric data type is set for integer and the value contains decimal places they are ignored. In this situation use the decimal offset to ensure that you have an integer value and then write your code to recognize and handle the decimal offset. Bits 9 to 11 indicate the number of places by which the decimal is to be shifted. Bit 12 indicates the direction by which the decimal point is shifted, left or right. For example, if the decimal offset (value of bits 9 to 11) is '2' and the shift (value of bit 12 is) '0', then the decimal point is shifted two places to the right.

Error Codes

The error codes returned in the format area are 8-bit integers found in the lowest 8 bits of the format word. This allows for 256 potential error codes.

Currently the BW500 and BW500/L has two error codes available:

Values	Description
0	No error
1	Data not available as percent (available as units)
2-255	Reserved

Date and Time (R41,000 - 41,006)1)

The date and time can be read or written in registers 41,000 to 41,006 as defined in the table above.

10.5 Modbus RTU/ASCII Protocol

Example: If you are located in Toronto, Canada and would like to set the date and time to February 14, 1999, 1:30 p.m. and 42 seconds, you would write the following:

Bits	Values
R41,000	1999
R41,001	2
R41,002	14
R41,003	13
R41,004	30
R41,005	42
R41,006	-5

Note

The time zone register is used only as a reference and does not affect the operation of the BW500.

¹⁾ Not available with BW500/L.

Process Values (R41,010 - R41,048)

Rate, Load, Speed, and Total (R41,010 - R41,019)

The associated registers provide the readings of rate, load, and speed. Totalizer 1 and Totalizer 2 in engineering units as displayed in the local BW500 and BW500/L display.

Device State (41,020 - 41,020)

The Device State word is used to feed back the current operating state of the product. Each bit gives the state of different parts of the product, some mutually exclusive, others are not. The state should be checked to verify any device commands.

Bit #	Description	Bit Clear	Bit Set (1)
1	PID 1 Mode ^{a)}	Manual	Auto
2	PID 1 Freeze ^{a)}	No	Yes
3	PID 1 Setpoint Source ^{a)}	Local	Remote
4	PID 2 Mode ^{a)}	Manual	Auto
5	PID 2 Freeze ^{a)}	No	Yes
6	PID 2 Setpoint Sourcea)	Local	Remote
7	Zero	No	In progress
8	Span	No	In progress
9	-	-	-
10	-	-	=
11	-	-	-
12	-	-	-
13	Write Privileges	No	Yes
14	System Configured	Not Configured	Yes
15	Mode	Calibration Mode	RUN Mode
16	Totalizing	Not Totalizing	Totalizing

a) Not available with BW500/L.

10.5 Modbus RTU/ASCII Protocol

Command Controls (41,022)

The command control word is used to control the unit. Each bit gives access to a command or state as if the operator was using the keypad.

Bits initiating a command (7-12) must change state to cause the command the begin. For example, to reset totalizer 1, Bit 9 must be set to 0, then changed to 1. It can stay set or clear for any period:

Bit #	Description	Bit Clear	Bit Set (1)
1	PID 1 Mode ^{a)}	Manual	Auto
2	PID 1 Freeze ^{a)}	No	Yes
3	PID 1 Setpoint Sourcea)	Local	Remote
4	PID 2 Mode ^{a)}	Manual	Auto
5	PID 2 Freeze ^{a)}	No	Yes
6	PID 2 Setpoint Sourcea)	Local	Remote
7	Zero	No change	Start
8	Span	No change	Start
9	Reset Totalizer 1	No change	Reset
10	Reset Totalizer 2	No change	Reset
11	Reset Batch Totalizera)	No change	Reset
12	Print	-	Print
13	-	-	-
14	-	-	-
15	-	-	-
16	-	-	-

a) Not available with BW500/L.



Before the BW500 and BW500/L can be commanded remotely, parameter P799 must be set for remote control.

Read/Write (R41,025 - R41,026) Total Decimal Places

Sets the number of decimal places (0-3) being read for Total 1, (words 41,016 and 41,017) and Total 2, (words 41,018 and 41,019).

With 3 decimal places, the largest value that can be read is 2,147,483.648.

With 2 decimal places, the largest value that can be read is 21,474,836.48.

With 1 or 0 decimal places, the largest value that can be read is 100,000,000.

Although the word registers are limited to reading a maximum value as indicated above for the defined number of decimal places, the overflow bits of Instrument_Status2 (Word 31) will only reflect an overflow condition (Bits 1 and 2 set to 1) when the decimal place is set to 2 or 3.

When set to 2 or 3, the word registers will stop accumulating at the indicated values however, the LUI will continue to totalize to a value of 100,000,000. Should this condition exist, prior to resetting the totalizer registers, be sure to observe and record the totalized value as displayed on the LUI. Not doing this could cause a reporting discrepancy in expected material totals within the process.

Once the internal totalizer registers realize a value of 100,000,000, the internal registers will perform a rollover, causing the display of the LUI to start from a value of 0. This will also cause the Instrument Status2 word bits to reset to 0.

Example: R41,025

Bits 0 and 1 are used to indicate the number of decimal places being read in Total 1: words 7 and 8.

Bit 15 is used to indicate if the decimal place is too large to read the total value correctly.

If three decimal places are being read in Total 1:

Bits	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
	0	0	1	0	0	1	0	0	0	0	0	0	0	0	1	1

If three decimal places are being read in Total 1, and the value is too large to be read with three decimal places:

Bits	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
	1	0	1	0	0	1	0	0	0	0	0	0	0	0	1	1

10.5 Modbus RTU/ASCII Protocol

I/O (R41,070 - 41,116)

The BW500 provides I/O in the form of:

- · discrete inputs
- relay outputs
- mA inputs¹⁾
- mA outputs¹⁾

 $^{1)}$ The standard BW500 provides only one mA output (0/4 – 20 mA). The inclusion of an optional mA I/O card provides two mA inputs (0/4 – 20 mA) and two additional mA outputs. The optional mA I/O card is not available with BW500/L

For the I/O, the assigned registers represent the logic status (e.g. open or closed) of the I/O as configured. Discrete inputs are configured via P270, auxiliary input function; while relay outputs are configured via P100, relay function.

The I/O are mapped into the respective input and output registers, R41,070 and R41,080, as follows:

R41,070		R41,080			
Input	Bit	Output	Bit		
1	1	1	1		
2	2	2	2		
3	3	3	3		
4	4	4	4		
5	5	5	5		

For the mA I/O, the assigned registers represent the mA level (e.g. 0 to 20 mA) of the I/O as registered in P911 and P914, mA output test (output value) and mA input value.

The mA I/O are mapped into the respective input and output registers:

Input	Register	Output	Register
1	R41,090	1	R41,110
2	R41,091	2	R41,111
		3	R41,112

For 0 to 20 mA I/O, the register value ranges from 0 to 20,000. For 4 to 20 mA I/O, the register value ranges from 4,000 to 20,000. If the 4 or 20 mA values have been trimmed, then the register value is adjusted accordingly; e.g. an I/O value of 22 mA would be registered as 22,000.

Diagnostic (R41,200)

Refer to Troubleshooting (Page 207)

PID Tuning (R41,400 - 41,419)¹⁾

For BW500 set up for PID control, several registers have been provided for tuning. Refer to PID Control (Page 109) and the associated parameters as listed in the register map.

Note

Before you can change any of the setpoints, P799 must be set for remote control.

Parameter Values

Bit Mapped bits are packed into registers in groups of 16 bits (1 word). In this manual we number the bits from 1 to 16, with bit 1 being the least significant bit and bit 16 referring to the most significant bit.

16	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1
MSB															LSB

Large numbers are put into unsigned 32 bit integers with a fixed decimal place of three. For example, a value of '7345' represents a value in the BW500 '7.345'. The default word order is that the first word is the most significant word (MSW) and the second word (register) is the least significant word (LSW).

For example, if we read R41,431 as a 32-bit, the 32 bits would look like the following:

	R41,431			R41,432	
16	MSB	1	16	LSB	1
32					

The whole is read as a 32-bit integer. The most significant byte (MSB) and least significant byte (LSB) can be reversed to accommodate some Modbus drivers.

¹⁾ Not available with BW500/L.

10.5 Modbus RTU/ASCII Protocol

Text Messages

If a Siemens device parameter returns a text message, that message is converted to a number and provided in the register. The numbers are shown in the table below:

Number	Text Message as Displayed on LCD
22222	invalid value
30000	off
30001	on
30002	====
30003	(parameter does not exist)
30004	err
30005	err1
30006	open
30007	shrt
30008	pass
30009	fail
30010	hold
30012	hi
30013	de
30014	en
-32768	value is less than -20,000
32767	value is greater than 20,000

10.6 Modems

The BW500 and BW500/L has been successfully connected to several different modems. In general, the Modbus protocol is a very modem friendly protocol. This section gives some general guidelines on modems and their connection. For detailed information, see the modem documentation.

Picking Modems

There are several different types of modems; dial-up, leased line, radio-link, fiber-optic, to name the most common.

Dial-up

uses a standard analog phone line and dials the number of the receiving modem.

Lease line

come in either 2 or 4 wire types and use special phone lines that are 'leased' from your phone company (or you) and do not require any dialing.

Radio-link

come in many different types, but all use radio frequencies for transmitting the information.

Fiber-optic

uses a fiber-optic line to connect the two modems.

Each type of modem and each model have various characteristics. Before purchasing the modem contact the modem manufacturer and ask if they have had experience using the modems with Modbus protocol with no flow control. If they have, ask them what settings were required.

Setting up the Modems

Modems can be configured using software, dip switches, jumpers, or a combination.

Dip switches are normally located at the back of the modem, jumpers are normally located on the motherboard and require that you remove the cover. Software normally requires you to use a standard terminal program and to connect to the RS-232 port on the modem and send special commands. The most popular command set is called the AT, or Hayse, command set.

Your modem manual should give details on how to configure it.

10.6.1 Example Setup

For a typical dial-up modem, try the following setup as a first attempt:

10.6 Modems

Master

Modem

- auto answer off (dip switch?)
- load factory default (dip switch?)
- no flow control (dip switch?)
- baud rate = 9600
- 10 data bits (probably the default)

Modbus RTU Software

- baud rate = 9600
- 8 bit
- no parity
- 1 stop bit
- dial prefix: ATDT
- Initialization command: ATE0Q0V1X05=0512=100
- Reset command: ATZ
- Hang-up command: ATHO
- Command response delay: 5 seconds
- Answer Delay: 30 seconds
- Inter-character delay: 55 ms

Slave

Modem

- auto answer on (dip switch?)
- load factory default (dip switch?)
- no flow control (dip switch?)
- baud rate = 9600
- 10 data bits (probably the default)

BW500 and BW500/L

- set P770, port 1, to the value 3 (Modbus RTU)
- set P771, port 1, to the value 1 (Network ID 1)
- set P772, port 1, to the value 3 (Baud rate of 9600)
- set P773, port 1, to the value 0 (No Parity)
- set P774, port 1, to the value 8 (8 Data Bits)
- set P775, port 1, to the value 1 (1 Stop Bit)
- set P778, port 1, to the value 1 (Communications through Modem)
- set P779, port 1, to the value 300 (Modem Inactivity of 300 seconds)

Note

Parameters are defined the in the Installation section

10.7 Error Handling

Modbus Responses

When polled by a Modbus Master, a slave device will do one of the following:

1. **Not reply** means something went wrong with the transmission of the message

2. Echo back the command with the correct response is the normal response, (see the Modbus specifications for more details)

3. **Return an Exception Code** reflects an error in the message

BW500 and BW500/L uses the following exception codes:

Code	Name	Meaning
01	Illegal Function	The function code received in the query is not an allowable action for the slave.
02	Illegal Data Address	The data address received in the query is not an allowable address for the slave.
03	Illegal Data Value	A value contained in the query data filed is not an allowable value of the slave.
04	Slave Device Failure	An unrecoverable error occurred while the slave was attempting to perform the requested action.
05	Acknowledge	The slave has accepted a request and is processing it, but a long duration of time is required.
06	Slave Device Busy	The slave is processing a long- duration program command.
08	Memory Parity Error	The slave attempted to read extended memory, but detected a parity error in the memory. Service may be required on the slave.

Error Handling

Errors can be divided up into two general sources:

- an error in transmission
- user tries to do something that is not a valid action

In the first case, the BW500 and BW500/L will not respond and let the master wait for a 'response time out' error, which will cause the master to re-send the message.

In the second case, it depends on what the user tries to do. Listed below are various actions and what the expected outcome is. In general, BW500 and BW500/L will not give an error to the user request.

- If the user reads an invalid parameter, the user will get a number back.
- If the user writes an invalid parameter (a non-existing parameter or a read only parameter), the value will be ignored and no error response will be made. However, the current value will not reflect the desired new value.
- If the user writes a read only register, then the value will be ignored and no error response will be made. However, the current value will not reflect the desired new value.
- If the user attempts to write one or more registers that are out of range, an exception response code 2 will be generated.
- If using an unsupported function code, undocumented results may occur. The user is encouraged not to do this.

Parameter assignment 1

f indicates factory set value

P000 Security Lock

Locks out the program editor so that parameter values for P001 through P999 cannot be changed. This however, does not prevent the access to the parameters for viewing.

Programming is locked out if the value of P000 is other than 1954.

Entry:

1954 = unlockedf

11.1 Start Up (P001 to P017)

This is the minimum parameter programming required before attempting a calibration and successful entry into the **RUN** mode.

11.1.1 P001 Language

Selects the language for communication with the BW500 and BW500/L

Entry:

1 = Englishf	5 = Italian
2 = French	6 = Portuguese
3 = German	7 = Russian
4 = Spanish	

11.1.2 P002 Test Reference Selection

Selects the type of test reference used to represent a material load: weight, chain, or electronic.

weight:	the weight that is supplied specific to the scale
chain:	optional, sized specific to scale and conveyor
electronic:	calibration based on automatic calculation of the mV span from the load cells

Entry:

1 = weightf

2 = chain

3 = ECal

11.1.3 P003 Number of Load Cells

Siemens belt scales are available in models of one, two, four, or six load cell design. Select the number of load cells corresponding to the belt scale connected. If using the optional remote LVDT conditioner card, for LVDT based scales, select "1".

Entry:

enter the number of load cells:	BW500: 1, 2f, 4, or 6 ¹⁾
	BW500/L: 1, 2f

¹⁾ For 6 load cell belt scales, enter 4.

11.1.4 P004 Rate Measurement System

Selects system of measurement used, either imperial or metric.

Entry:

1 = imperial

2 = metric f

11.1 Start Up (P001 to P017)

11.1.5 P005 Design Rate Units

Determines the units for programming and measurement.

		imperial - P004 = 1	metric - P004 = 2
entry:	1 <i>f</i> =	T/h (tons/hour)	t/h (tonnes/hour)
	2 =	LT/h (long tons/hour)	kg/h (kilograms/hour)
	3 =	lb/h (pounds/hour)	kg/min (kilo- grams/minute)
	4 =	lb/min (pounds/minute)	

Changing this parameter does not affect the rate (P011), belt speed (P014), or belt length (P016) parameters. These parameters should be re-entered for conformity in units.

t = 1000 kg

LT=2240 lb.

T=2000 lb.

11.1.6 P008 Date

Enter the current date in yyyy-mm-dd format:

yyyy = year

mm=month, 01 -12

dd=day, 01 - 31

e.g. 1999-03-19 (March 19, 1999)

Note

Not available with BW500/L.

11.1.7 P009 Time

Enter the current time in hh-mm-ss 24 hour format.

Where:

hh=hour

mm=minute

ss=second

Note

Not available with BW500/L.

11.1.8 P011 Design Rate

Specifies the design rate of material flow for the belt scale (f = 0.00).

Enter the design rate in the units selected (P005).

11.1.9 P014 Design Speed

Specifies the design speed for the conveyor belt (f = 0.00)

Speed units are:

feet/min if the imperial system of measurement has been selected, P004 = 1

metres/s if the metric system of measurement has been selected, P004 = 2

11.1.10 P015 Speed Constant

Set the speed constant for the speed sensor selected (P015-01 or $02)^{1)}$.

1) Index 02 is not available with BW500/L

The value in P015-01 is used with the speed sensor frequency, to calculate the actual belt speed (f = 0.000).

The value in P015-02 is used for differential speed detection²).

2) Not available with BW500/L

Note

Entry: If speed input is wired for constant speed (terminals 17/18 jumpered), value defaults to jumpered, and the second speed sensor is ignored.

If the speed input is connected to a speed sensor, press ENTER . P015 automatically jumps to P690. Refer to P690 (Page 197) for speed constant entry.

11.1.11 P016 Belt Length

The length of the conveyor belt (one belt revolution) (f = 0.000)

Length units are:

feet: if the imperial system of measurement has been selected, P004 = 1

metres: if the metric system of measurement has been selected, P004 = 2

Enter the belt length.

11.1 Start Up (P001 to P017)

11.1.12 P017 Test Load

The load to be referenced when performing a span (f = 0.00).

Load units are:

lb/ft: if the imperial system of measurement has been selected, P004 = 1

kg/m: if the metric system of measurement has been selected, P004 = 2

The display indicates the test reference as selected by P002: 'weight', 'chain', or 'ECal' and the multispan number MS, 1-8¹⁾.

1) Multispan function is not available with BW500/L.

Enter the test load value. In the case of weight, pressing enter at P017 invokes P680 for data entry.

In the case of ECal, pressing enter at P017 invokes P693 for data entry. ECal sets the value for P017 at 100% of design load (P952).

In the case of chain, pressing enter at P017 allows direct entry of the load value stamped on the chain's name plate.

If P002 is set to 'weight' the test load parameter presents two options:

1. enter the load in weight/unit length Set P680 Test Load: Weight (Options) to '1-Enter Value', and then enter the desired value for P017.

or

2. the mass and the weigh length. Set P680 Test Load: Weight (Options) (Page 196) to '2-Enter Data' and then enter the 'Total Mass of Test Weights' in P681, and the 'Average Idler Space' in P682.

Example:

3 standard MSI test weights, 1.2 meter idler spacing

Test Load: 24.6 kg (3x8.2 kg)/(1.2 m) = 20.5 kg/m

11.1.13 P018 Speed Adjust

This parameter allows adjustment to the speed constant for both speed sensors (P015-01 or P015-02)²⁾. Initially, this parameter displays the dynamic speed of the belt. If the displayed speed is not equal to the actual speed, enter the actual belt speed (f = 0.00).

For speed sensor applications, the value of P015 is automatically adjusted.

For constant speed (terminals 17/18 jumpered) the value of P014 is automatically adjusted.

2) Not available with BW500/L

11.1.14 P019 Manual Span Adjust

Provides a means for adjustment to the span calibration (f = 0)

The adjustment value is determined by performing material tests and is subsequently entered either as a calculation of % change into P598, or as the weight of the material test.

Entry:

1 = % change

2 = material test

Refer to Recalibration (Page 62).

11.1.15 P022 Minimum Speed Frequency

Sets the minimum frequency that the speed sensor can reliably read. Signals at low frequencies are erratic, adversely affecting the performance of the weighing system.

Entry:

1 = 1 Hz (at 1 Hz, it takes 1 s before defaulting to 0 speed)

2 = 2 Hzf (at 2 Hz, it takes 0.5 s before defaulting to 0 speed)

11.1.16 P080 Display Damping

P080-01 Rate

P080-02 Load

P080-03 Speed

Sets the speed of response to which the displayed readings (rate, load, and speed), and outputs (alarm and mA¹⁾) react to change. Refer to Operation (Page 99).

Note

Effect of damping (P080-01) on mA output can be overridden by mA output damping (P220).

The higher the damping value, the slower the response.

Enter damping value, range 0.000f – 999

1) Damping is not applicable to the mA output if programmed for PID function (P201 = 4).

11.1.17 P081 Display Scroll Mode

The **RUN** displays are scrolled either manually by pressing ALT DISP if the scroll mode is set to off, or automatically if the mode is set to on.

Entry:

0f = OFF

1 = ON

11.2 Relay/Alarm Function (P100 - P117)

Note

BW500 has 5 programmable relays and BW500/L has 2

These parameters are specific to the use of the relay/alarm function. Refer to Operation (Page 99).

11.2.1 P100 Relay Function

Sets the relay function for the relay selected; BW500: relays 1 to 5 (P100 -01 to -05), BW500/L: relays 1 and 2 (P100 - 01, 02)

Note

- To reset the Diagnostics relay, the BW500 and BW500/L must be cycled between PROGRAM and RUN mode
- To reset the Batch relays, the Batch totalizer must be reset.

Entry:

- 0 = OFF f
- 1 = rate
- 2 = load
- 3 = speed
- 4 = diagnostic
- 5 = PID-01 setpoint deviation¹⁾²⁾
- 6 = PID-02 setpoint deviation $^{1)2)}$
- $7 = \text{pre-warn}^{1)3}$
- $8 = setpoint^{1)3}$
- $9 = \text{online calibration}^{1)4)}$
- $10 = differential speed detection^{1)5}$
- 11 = certification rate alarm (high alarm preset to 100%, low alarm preset to 20 %)⁶⁾
- 1) Not available with BW500/L
- 2) Valid only if PID system (P400) is enabled
- 3) Valid only if batch function (P560) is enabled
- 4) Valid only if online calibration (P355) is enabled
- ⁵⁾ Valid only if Aux. input (P270) = 16 (differential speed detection)
- ⁶⁾ When selected parameters P101 and P102 are locked

11.2.2 P101 High Alarm / Deviation Alarm

High Alarm (f = 100)

For relay functions, P100 = 1, 2, and 3, this parameter sets the high alarm setpoint for the relay selected; BW500: relays 1 to 5 (P100 -01 to -05); BW500/L: relays 1 and 2 (P100 -01 to -02).

Enter the value in % of full scale.

Deviation Alarm (f = 10)1)

For relay functions, P100 = 5 and 6, this parameter sets the deviation setpoint for the relay selected; relays 1 to 5 (P100 - 01 to -05).

Enter the value in % of setpoint.

Differential Speed (f = 110)1)

For differential speed functions, P100 = 10, this parameter sets the high alarm setpoint for the relay selected; relays 1 to 5 (P100 -01 to -05).

11.2.3 P102 Low Alarm

Sets the low alarm setpoint for relay selected, BW500: relays 1 to 5 (P100 - 01 to - 05), BW500/L: relays 1 and 2 (P100 - 01 to - 02) (f=20).

Enter the value in % of full scale

Note

Not applicable if P100 = 4, 5, 6, 7, or 8.

Differential Speed (f = 90)1)

For differential speed functions, P100 = 10, this parameter sets the low alarm setpoint for the relay selected; BW500: relays 1 to 5 (P100 -01 to -05).

¹⁾ Not available with the BW500/L.

¹⁾ Not available with the BW500/L.

11.2.4 P107 Relay Alarms

Sets the alarm mode for the relay selected; BW500: relays 1 to 5 (P100 -01 to -05); BW500/ L: relays 1 and 2 (P100 -01 to -02).

Entry:

- 1 = high and low f
- 2 = high only
- 3 = low only

Note

Not applicable if P100 = 4, 5, 6, 7, or 8.

11.2.5 P117 Relay Dead Band

Sets the dead band for the relay selected; BW500: relays 1 to 5 (P100 -01 to -05); BW500/ L: relays 1 and 2 (P100 -01 to -02). The dead band prevents relay chatter due to fluctuations at the high or low setpoint (f = 3.0).

Enter the value in % of full scale, or for deviation alarm enter % of setpoint, range is 1 to 10 %.

Note

Not applicable if P100 = 4, 7, or 8.

11.2.6 P118 Relay Logic

Sets the logic applied to relays to determine their open or closed state.

Power Failure

The relays on the BW500 default to normally open under power loss.

Normal Operation

In software, all relays are programmed the same way; with \mathbf{ON} setpoints always indicating relay action. This parameter allows the reversal of the operation. Normally, P118 = 2 for each relay.

Reverse Operation

When P118 = 3, the operation of the indexed relay is reverse from normal.

Values

P118	Logic	Relay
2	positive logic	normally closed ^f
3	negative logic	normally open

11.2.7 P119 Override

This function allows the user to simulate an alarm condition: ON or OFF, which will override normal operation until P119 setting is returned to normal.

Values

P119	Condition	Display (alarm field)
0	normal	normal
1	alarm on	ALM #
2	alarm off	blank

11.3 mA I/O Parameters (P200 - P220)

These parameters are specific to the use of the mA output. Refer to mA Output (Page 104) for details.

- mA output 1 is physically located at terminals 21/22 on the main board
- mA outputs 2 and 3, and inputs 1 and 2 are physically located on the optional mA I/O board which is mounted onto the main board.¹⁾

In the case of assigning mA input and output functions to PID control¹⁾, the following correlation exist:

	mA input	mA output
PID control 1	1	2
PID control 2	2	3

¹⁾ Not available with the BW500/L.

11.3.1 P200 mA Output Range

Sets the mA range for the output selected, outputs 1 to 3 (P200 - 01 to - 03)²).

Entry:

1 = 0 - 20 mA

2 = 4 - 20 mAf

11.3.2 P201 mA Output Function

Assigns the mA output function for the output selected, outputs 1 to 3 (P201 - 01 to - 03) $^{2)}$

Entry:

1 = rate f

2 = load

3 = speed

 $4 = PID control output^{3)}$

²⁾ BW500/L has one output, parameters will not present multiple indexes.

²⁾ BW500/L has one output, parameters will not present multiple indexes.

³⁾ Not available with BW500/L.

⁴⁾ Valid for outputs 2 and 3, only if PID system (P400) is enabled.

11.3 mA I/O Parameters (P200 - P220)

11.3.3 P204 mA Output Average

Sets the averaging period, in seconds, for the rate output for output 1 only.

The instantaneous mA values are averaged for the set period, and then the average value is output during the next period while a new average is being calculated.

Entry:

0 = OFFf

1 - 999 = averaging period

11.3.4 P212 mA Output Minimum

Sets the minimum mA limit for the output selected, outputs 1 to 3 (P212 - 01 to - 03)²⁾. The limit sets the lower mA range (0 or 4 mA) to a minimum output value (f = 3.80).

Enter limit value, range 0 - 22

²⁾ BW500/L has one output, parameters will not present multiple indexes.

11.3.5 P213 mA Output Maximum

Sets the maximum mA limit for the output selected, outputs 1 to 3 (P213 - 01 to - 03)²⁾. The limit sets the upper mA range (20 mA) to a maximum output value (f = 22.00).

Enter limit value, range 0 - 22

²⁾ BW500/L has one output, parameters will not present multiple indexes.

11.3.6 P214 4 mA Output Trim

Trims the 4 mA output level for the output selected, outputs 1 to 3 (P214 - 01 to - 03)¹⁾. The trim adjust the output to agree with a milliammeter or other external mA input device.

Scroll the trim value up or down

1) BW500/L has one output, parameters will not present multiple indexes.

11.3.7 P215 20 mA Output Trim

Trims the 20 mA output level for the output selected, outputs 1 to 3 (P215 - 01 to - 03)¹⁾. The trim adjust the output to agree with a milliammeter or other external mA input device.

Scroll the trim value up or down

1) BW500/L has one output, parameters will not present multiple indexes.

11.3.8 P220 mA Output Damping

Sets the damping for the output selected, outputs 1 to 3 (P220 - 01 to - 03)¹⁾. Damping sets the speed at which the mA output reacts to change. The greater the damping value, the slower the response. If the value is 0, the mA output assumes the damping set in P080 (f = 0.00).

Enter the damping value, range 0.001 - 999

1) BW500/L has one output, parameters will not present multiple indexes.

11.3.9 **P250 mA input range**

Sets the mA range for the input selected, inputs 1 to 2 (P250 - 01 to - 02).

Entry:

1 = 0 - 20 mA

2 = 4 - 20 mAf

Note

Not available with BW500/L.

11.3.10 P255 mA Input Function

Assigns the mA input function for the input selected, inputs 1 to 2 (P250 - 01 to - 02)

- 0 = OFFf
- 1 = PID setpoint
- 2 = PID process variable
- 3 = Online calibration¹⁾
- 4 = Moisture compensation
- 5 = Incline compensation

Note

Not available with BW500/L.

¹⁾ Valid only if Online Calibration is turned on, (P355 = 1).

11.3 mA I/O Parameters (P200 - P220)

11.3.11 P261 4 mA Input Trim

Trims the 4 mA input level for the input selected, inputs 1 to 2 (P250 - 01 to - 02). The trim adjusts the input to agree with an external 4 mA source.

Follow the BW500 online instructions to trim the input

Note

Not available with BW500/L.

11.3.12 P262 20 mA Input Trim

Trims the 20 mA input level for the input selected, inputs 1 to 2 (P250 - 01 to - 02). The trim adjusts the input to agree with an external 20 mA source.

Follow the BW500 online instructions to trim the input.

Note

Not available with BW500/L.

11.3.13 P270 Auxiliary Input Function

Selects the auxiliary input function for the input selected; inputs 1 to 5 (P270 - 01 to - 05).

Value	Function	Symbol	Description
0	off		
1	alternate display:	00	momentary closure of the input contact caus- es the RUN display to scroll to the next dis- play.
2	reset totalizer 1:	00	momentary closure of the input contact resets the totalizer.
3	zero:	00	momentary closure of the input contact initiates a zero calibration.
4	span:	00	momentary closure of the input contact initiates a span calibration.
5	print:	00	momentary closure of the input contact sends a print request.
6a)	multispan selection:	⊣⊢	maintained closure state of the input con- tact(s) (up to 3) selects the multispan (P365).
8a)	reset batch:	00	momentary closure of the input contact resets the batch totalizer to zero.
9a)	PID freeze:	- 1 ⊬	off closure suspends PID function in the auto mode freeze function in the auto mode and holds output at last value
10 ^{a)}	PID setpoint source:	⊣ ⊢	remote local
		*	

11.3 mA I/O Parameters (P200 - P220)

Value	Function	Symbol	Description
11a)	PID mode:	ૠ	auto manual
12	external alarm:		the input contacts sta- tus is sensed off
13	remote communication write:	-1⊦ -1⊦	keypad / Dolphin Plus write (program) ena- bled SmartLinx/ remote device write (program) enabled
14 ^{a)}	initiate online calibration:	00	momentary closure of the input contact initi- ates online calibration
15ª)	accept new online cali- bration span:	<u> </u>	momentary closure of the input contact ac- cepts the online calibra- tion deviation
16 ^{a)}	auxiliary speed sensor		for differential speed detection

a) Not available with BW500/L.

Entry:

Note

Before you can use Online Calibration, P100, P255, P355, P356, and P357 must be set up.

- 0 = OFFf
- 1 = alternate display
- 2 = reset totalizer 1
- 3 = zero
- 4 = span
- 5 = print
- $6 = \text{multispan selection}^{1) 2}$
- $7 = reserved^{2}$
- $8 = \text{reset batch}^{2)}$
- $9 = PID freeze^{2}$
- 10 = PID setpoint source²⁾
- $11 = PID \mod e^{2}$
- 12 = external alarm
- 13 = remote communication write
- 14 = Initiate Online Calibration²⁾
- 15 = Accept new online calibration span^{2) 3)}
- 16 = Auxiliary speed sensor²⁾

¹⁾ If the BW500 is programmed for multispan operation, the auxiliary input contact state determines the multispan number (equivalent to P365). Input 1 is reserved for multispan 1 and 2 selection. Input 2 is reserved for multispan 3 and 4 selection. Input 3 is reserved for multispan 5 to 8 selection.

²⁾ Not available with BW500/L

³⁾ Enter 1 (existing – ALT DSP) to reject the new online calibration span.

11.4 Calibration Parameters (P295 – P360)

multispan selection	Auxiliary Input	auxiliary input 2	auxiliary input 3
1	⊣⊢	⊣⊢	⊣⊢
2	*	⊣⊢	⊣⊢
3	⊣⊢	*	⊣⊢
4	*	*	⊣⊢
5	⊣⊢	⊣⊢	*
6	*	⊣⊢	*
7	⊣⊢	*	*
8	*	*	*

If an attempt is made to select a multispan that has not been zero and span calibrated, the selection request is ignored.

Note

- When performing a remote span, it will first perform a zero, then it will ask you to set up span test. Once loading is within +/- 2% of the design test weight, it will perform the span.
- For the print command to work, the BW500 and BW500/L must be in RUN mode.

11.4 Calibration Parameters (P295 – P360)

11.4.1 P295 Load Cell Balancing

Initiates an electronic balancing of the load cell input signals. Balancing is required for belt scale models of two, four, or six load cell design.

Refer to Start Up (Page 40) for requirements and execution.

11.4.2 P341 Days Of Service

The cumulative days that the application device has been in service. The time is recorded once daily in a non-resettable counter. Periods of less than 24 hours. are not recorded, nor accumulated (f = 0).

11.4.3 P350 Calibration Security

P350 Calibration Security

		zero	Span	'Reset T'
entry:	0 = no additional security.f	Yes	Yes	Yes
	1 = in addition to P000 lock; no span.	Yes	No	Yes
	2 = in addition to P000; no zero, no span.	No	No	Yes
	3 = in addition to P000; no zero, no span, no totalizer 1 (T1) reset.	No	No	No

11.5 Online Calibration Options (P355 - P358)

Note

- Online calibration options must be enabled (P355 = 1) before they become available.
- Not available with BW500/L.

11.5.1 P355 Online Calibration Feature

Enables Online Calibration.

Entry:

0 = OFFf

1 = ON

11.5.2 P356 Online Calibration Reference Weight

Enter the weigh bin reference weight, (in units selected in P005), range 0.000 to 99999 (f = 0.000).

11.5 Online Calibration Options (P355 - P358)

11.5.3 P357 Online Calibration Limits

Use to enter the weigh bin limit settings.

P357.1 MAX LIMIT, range 0.0 to 100.0 (f = 0%)

P357.2 HIGH LIMIT, range 0.0 to 100.0 (f = 0%)

P357.3 LOW LIMIT, range 0.0 to 100.0 (f = 0%)

11.5.4 P358 Online Calibration Activation

Initiates online calibration.

Entry:

0 = OFFf

1 = ON

11.5.5 **P359 Factoring**

Factoring is used as a method of calculating the value of the test load (P017) to a new test reference; either: weight, or chain. The task is performed only for the weight or chain relevant for the multispan selected, if applicable.

Entry:

```
1 = weight (f = 1)
```

2 = chain

Refer to Recalibration (Page 62) for execution of the factoring procedure.

Note

Totalization is halted during the factoring procedure, and resumed only upon return to the **RUN** mode.

11.5.6 P360 Calibration Duration

Sets the number of whole belt revolutions to be used during a zero or span calibration.

Enter number of belt revolutions, range 1 to 99. For belt scale applications 1 belt revolution or 2 minutes, whichever is longer; for weighfeeder applications 3 belt revolutions or 5 minutes, whichever is longer.

11.5.7 P365 Multispan

Note

Not available with BW500/L.

Select the span reference to be applied for determination of rate and totalization.

Entry:

- 1 = multispan 1 (MS1), for product or condition Af
- 2 = multispan 2 (MS2), for product or condition B
- 3 = multispan 3 (MS3), for product or condition C
- 4 = multispan 4 (MS4), for product or condition D
- 5 = multispan 5 (MS5), for product or condition E
- 6 = multispan 6 (MS6), for product or condition F
- 7 = multispan 7 (MS7), for product or condition G
- 8 = multispan 8 (MS8), for product or condition H

Refer to Multispan and P270, Auxiliary Input Function (6).

11.5.8 P367 Direct Zero Entry

Directly enters the zero reference count.

Direct entry is intended for use when replacing software or hardware and it is not convenient to perform an initial zero at that time (f = 0).

Refer to Recalibration (Page 62) for execution.

11.5.9 P368 Direct Span Entry

Directly enters the span reference count for the span selected, 1 to 8 (P368-01 to -08).

Note

BW500/L has one span entry possible, no indices will be presented.

Direct entry is intended for use when replacing software or hardware and it is not convenient to perform an initial span at that time (f = 0).

Refer to Recalibration (Page 62) for execution.

11.5 Online Calibration Options (P355 - P358)

11.5.10 P370 Zero Limit Deviation %

Sets the zero calibration deviation limit (\pm) from the last initial zero. If the accumulated deviation of successive zero calibrations exceeds the limit, the zero calibration is aborted (f = 12.5).

Note

If the legal for trade certification switch has been set, the zero limit is $\pm 2\%$.

Enter the maximum allowable % deviation, range is 1 to 12.5 %.

11.5.11 P371 Auto Zero Initiation Upper Limit

This parameter sets maximum load on the belt as a percentage of design load at which the device will allow 'auto-zero' to run, min. 1.0%, max. 10.0%, default 2.0%.

When the certification switch is set this parameter will assume the default value (2.0%).

Note

Material will not be totalized during auto zero calibrations.

11.5.12 P377 Initial Zero

Resets the initial zero.

The initial zero is the reference zero to which all subsequent operator initiated zero calibrations are compared in determining whether they have deviated beyond the zero limit (P370) (f = 1).

Note

Refer to Initial Zero (Page 72) on for execution.

11.5.13 P388 Initial Span

Resets the initial span for the span selected, multispan 1 to 8 (P388-01 to -08)1).

The initial span is the reference to which all subsequent span calibrations are compared in determining whether they have deviated beyond an accumulated $\pm 12.5\%$ of the initialspan (f = 1).

Note

Refer to Initial Span (Page 78) for execution.

11.6 Linearization Parameters (P390 - P392)

These parameters are used to compensate for non-linear response of the weighing system to the BW500 and BW500/L. Refer to *Linearization* for execution, and example on the use of these parameters.

Note

In the case of multispan operation, the linearizer is applied to all spans.

11.6.1 P390 Linearizer

Enables or disables the linearization function.

Entry:

0 = OFFf

1 = ON

11.6.2 P391 Linearizer Load Points

Enters the load values, in units of P017, for the point selected, points 1 to 5 (P391-01 to -05) (f = 0.00, 150 % max.)

11.6.3 P392 Linearizer Compensation %

Enters the compensation value, in percent, for the point selected, point 1 to 5 (P392-01 to -05) (f = 0.00), range is -150 to 150 %.

¹⁾ BW500/L has one span entry possible, no indices will be presented.

11.7 Proportional Integral Derivative (PID) Control

11.6.4 P398-01 Moisture Content

Factors out moisture component of load, rate and total for all multispans selected. The factored values are meant to report the dry mean values of the material being conveyed (f = 0.00)

Enter the moisture content in % weight or mA Input Value¹⁾.

1) BW500/L will allow manual entry of a moisture content.

11.6.5 P398-02 Moisture Content

Allows moisture content P398-01 to be scaled to maximum value.

Enter the moisture content in % weight (maximum value 20 mA)

Note

Not available with BW500/L.

11.6.6 P399 Incline Sensing

Factors out the varying vertical force components applied to the belt scale for all multispans selected (f = 0.00). The value is presented in degree angle (0.0° = horizontal), with a range from -30 to 30 °.

P399 can also be used for a constant angle if a mA input is not configured. Otherwise, P399 will contain the current value corresponding to the mA input.¹⁾

1) BW500/L does not have mA inputs, only a fixed incline compensation value can be entered.

11.7 Proportional Integral Derivative (PID) Control

Note

- Changes to P401, P402, and P414 are not immediately effected while in auto mode.
 Change should be made in the manual mode and are effected upon return to the auto mode.
- The PID function does not control during any of the calibration functions (e.g. zero, span, factor, material test).
- Not available with BW500/L.

11.7.1 P400 PID System

Enables the selected PID system, systems 1 or 2 (P400 - 01 or - 02).

Entry:

- 0 = OFFf
- 1 = manual
- 2 = auto

11.7.2 P401 PID Update Time

Sets the update time (P401 – 01 or -02) for the corresponding PID system (1 or 2).

Normally the controller is updated each time the process value is updated (every 300 ms). However in unstable or slow reacting systems the controller update can be programmed to update on a multiple of the process value update. A high value can introduce instability (f = 1).

Entry:

- 1 = 300 ms
- 2 = 600 ms
- 3 = 900 ms, etc.

11.7.3 P402 PID Process Value Source

Determines the source of the process value (P402 - 01 or - 02) for the corresponding PID system (1 or 2)

The process value is the value that the controller is trying to match with the setpoint (f = 1)

Enter:

- 1 = rate f
- 2 = load
- 3 = mA input 1
- 4 = mA input 2

11.7 Proportional Integral Derivative (PID) Control

11.7.4 P405 Proportional Term

Sets the proportional term (P405-01 or -02) for the corresponding PID system (1 or 2) (f = 0.400)

The proportional term is the proportional gain. A gain of 1 is equivalent to a proportional band of 100%.

The proportional band is the range of deviation from the setpoint that corresponds to the full range or the control output.

Enter the proportional term 0.000 to 2.000.

11.7.5 P406 Integral Term

Sets the integral term (P406-01 or -02) for the corresponding PID system (1 or 2) (f = 0.200) Enter the integral term 0.000 to 2.000.

11.7.6 P407 Derivative Term

Sets the derivative term (P407-01 or -02) for the corresponding PID system (1 or 2) (f = 0.050)

Enter the derivative term 0.000 to 1.000.

11.7.7 P408 Feed Forward Term

Sets the feed forward term (P408-01 or -02) for the corresponding PID system (1 or 2) (f = 0.300)

Enter the feed forward term 0.000 to 1.000.

11.7.8 P410 Manual Mode Output

Displays the percentage output value (P410-01 or -02) for the corresponding PID system (1 or 2).

When the PID system is in manual, this is the value output, providing bumpless transfer when switching from manual to auto. When switching from auto to manual, this parameter is loaded with the current controlled value.

11.7.9 P414 Setpoint Configuration

Configures the setpoint (P414-01 or -02) for the corresponding PID system (1 or 2).

Determines the source for the PID's setpoint. If local, the setpoint value is entered into P415. The setpoint can be set from the mA input 1 or 2. The mA value is scaled to the full scale value of the process value (P402).

Entry:

- 0 = localf
- $1 = mA input 1^{1}$
- $2 = mA input 2^{1}$
- $3 = \% \text{ rate}^{2}$
- $4 = \% \log^{2}$

11.7.10 P415 Local Set point Value

Sets the local set point (P415-01 / 02), in engineering units, for the corresponding PID system (1 or 2) when in auto mode. For the external process variable, the set point is shown in % (f = 0.000).

Note

The PID setpoint can be modified while in RUN mode using the up/down arrow keys.

11.7.11 P416 External Setpoint

Displays the external setpoint (P416-01 / 02), in engineering units, for the corresponding PID system (1 or 2). For the external process variable, the setpoint is shown is %.

If the setpoint is external (P414 = 1 or 2), then this parameter displays the setpoint value that is being input, either mA input 1 or 2.

¹⁾ For PID-01, the setpoint source is mA input 1; for PID-02, the setpoint source is mA input 2.

²⁾ Options 3 and 4 are only available if P402 has been set for an external process value source. For option 3, the setpoint will be the current rate value displayed as a percentage: for option 4 it will be the current load value displayed as a percentage.

11.8 Batch Control (P560 - P568)

11.7.12 P418 Remote Setpoint Ratio

Sets the remote setpoint ratio (P418 -01/02) for the corresponding PID system (1 or 2) when P414 = 1 or 2 (f = 100).

The remote setpoint ratio scales remote setpoint input by the set percentage. A value of 100 means that the setpoint is 100% of the mA input.

11.7.13 P419 PID Freeze Option

Note

If the input speed frequency drops below 5 Hz, the PID control output freezes at its current value.

Enables or disables the PID freeze option described in the note above.

Entry:

0 = OFF

1 = ONf

11.8 Batch Control (P560 – P568)

The following parameters are specific to the use of the BW500 as a batch controller. P564-P568 is accessible only when Count Up (1) is selected.

Note

Not available with the BW500/L

11.8.1 P560 Batch Mode Control

Enables the batch control function.

Batch control is count up.

Entry:

0 = OFFf

1 = count up

11.8.2 P564 Batch Setpoint

Sets the batch total. When the amount of material delivered reaches this point, the batch relay contact opens (P100) to signal the end of the batch. (f = 0.000).

Enter the setpoint of the units of weight selected (P005).

Note

The batch setpoint can be modified while in RUN mode using the up/down arrow keys.

11.8.3 P566 Batch Pre-Warn

Enables or disables the pre-warn function associated with batch control, warning that the batch is nearing completion.

Entry:

0 = OFFf

1 = ON

11.8.4 P567 Batch Pre-Warn Setpoint

Sets the setpoint for the pre-warn function (P566). When the batch reaches the setpoint, the relay contact associated with the pre-warn function (P100) closes (f = 0.000).

Enter setpoint in units of weight selected (P005).

11.9 Totalization (P619 - P648)

11.8.5 P568 Batch Pre-Act

Acts on the batch operation such that when the batch totalizer is reset, the batch total is compared to the setpoint (P564). The difference is then applied to pre-act on the setpoint for the next batch to improve the accuracy of the batch. The activity is internally limited to $\pm 10\%$ of the batch setpoint.

Entry:

 $0 = OFF^f$

1 = Auto

2 = Manual

e.g. For Auto Batch Pre-Act

	1st batch	2nd batch	3rd batch
setpoint	1000	1000	1000
pre-act	1000	950	960
total	1050	990	1000

11.8.6 P569 Manual Batch Pre-Act Amount

Enter a value to make the setpoint relay change state at a known value lower than the setpoint (P564). This allows the feeding system to empty with each batch. The value of the manual pre-Act entry is generally reflective of the material that is left in the feeding system.

Example:

Setpoint = 1000

Manual Pre-Act = 50

The setpoint relay will activate when the batch totalizer reaches 950.

11.8.7 P598 Span Adjust Percentage

Accessible only through manual span adjust (P019), when percent change (1) is selected. Refer to % Change.

11.9 Totalization (P619 - P648)

The following parameters are specific to the use of the BW500 and BW500/L totalizers. See "Totalization (Page 106)".

11.9.1 P619 Totaling Dropout

Sets the limit, in percent of design load, below which material rates are not totalized (f = 3.0).

The value of 0 is reserved to allow both negative and positive totalization. Enter drop out value in % of design load, range is 0 to 25 %.

11.9.2 P620 Display Zero Dropout

Activates the limit as defined in P619 'Totalling Dropout', below which, the rate and/or load are set to 0.0.

-01 = Rate

-02 = Load

11.9.3 P621 mA Zero Dropout

Activates the limit as defined in P619 'Totalling Dropout', below which, the analog output, with respect to rate and load only, is set to 0.0.

Note

- Valid only if P201 = 1 or 2
- BW500 has three mA outputs, BW500/L has one

11.9 Totalization (P619 - P648)

11.9.4 P631 Totalizer Resolution

This parameter sets the resolution of the totalizer selected.

Totalizers are:

- -01 = totalizer 1
- -02 = totalizer 2
- -03 = verification totalizer
- -04 = material test totalizer
- $-05 = batch totalizer^{1)}$

Entry:

- 1 = 0.001 (one thousandth)
- 2 = 0.01 (one hundredth)
- 3 = 0.1 (one tenth)
- 4 = 1 (unit)f
- 5 = 10 (x ten)
- 6 = 100 (x hundred)
- 7 = 1000 (x thousand)

¹⁾ Not available with the BW500/L

11.9.5 P634 Communication Totalizer Resolution

Used to set the number of fixed decimal places for Total 1 and Total 2 for SmartLinx or Modbus communication.

Entry:

P634 Index	Description	Value	# of decimal places
Primary Index 1	Total 1 for SmartLinx communication	3 ^f	3
		2	2
		1	1
		0	0
Primary Index 2	Total 2 for SmartLinx communication	3 ^f	3
		2	2
		1	1
		0	0

With 3 decimal places set, the largest readable value is 2, 147, 483.638. With 2 decimal places set, the largest readable value is 21, 474, 836.38. With 1 or 0 decimal places set, the largest readable value is 100, 000, 000.

Note

This parameter is only relevant if viewing the totalizer value using remote communications, such as SmartLinx or Modbus.

11.9 Totalization (P619 - P648)


11.9.6 P635 Verification Totalizer

Enables a dedicated internal totalizer that totals the amount of material conveyed during a zero or span verification. It is used to verify the accuracy of the scale.

If a printer is connected to a port and the required programming is in order, a printout of the activity is automatically done on completion of the verification process.

Note

Date and time are not available with the BW500/L



Entry:

0 = off, verification totalizer disabled^f

1 = do not total, verification totalizer is enabled, but main totalizers¹⁾ are disabled

2 = add total, verification totalizer is enabled as well as main totalizers¹⁾

1) Main totalizers consist of internal totalizers 1 and 2, and external totalizers 1 and 2.

11.9.7 P638 External Totalizer Resolution

Note

- If the resolution selected would cause the totalizer to lag behind the count at 100% of design rate, the next possible resolution is automatically entered.
- External Totalizer output frequency must not exceed 13.33 Hz at 150% of design rate.

This parameter sets the resolution of the selected external totalizer.

Totalizers are:

P638-01, external totalizer 1 (T1), terminals 52/53

P638-02, external totalizer 2 (T2), terminals 55/56

Entry:

1 = 0.001 (one thousandth)

2 = 0.01 (one hundredth)

3 = 0.1 (one tenth)

4 = 1 (unit) f

5 = 10 (x ten)

6 = 100 (x hundred)

7 = 1000 (x thousand)

11.9.8 P643 External Contact Closure

Sets the duration of the contact closure, in ms, for the external totalizer selected, totalizers 1 and 2 (P643-01 or -02) (f = 30)

Permissible values are in 10 ms increments from 0. The value is automatically calculated upon entry of P011 (design rate) and P638 (totalizer 1 resolution, external) so that the duration of contact closure allows the transistor switch response to track the total, up to 150% of the design rate. The value can be changed to suit specific contact closure requirements, such as in the case of programmable logic controllers.

Note

- If the duration selected causes the totalizer to lag behind the count rate, the next possible duration is automatically entered.
- External Totalizer output frequency must not exceed 13.33 Hz at 150% of design rate.

11.9 Totalization (P619 - P648)

11.9.9 P647 Totalizer Display

Selects the totalizer combination to be displayed, either manually through the scroll display key or automatically by control of the display mode (P081).

Entry:

- 1 = totalizer 1f
- 2 = totalizer 2
- 3 = totalizer 1 and 2

11.9.10 P648 Totalizer Reset, Internal

Manual reset of the selected internal totalizer when the entry is made (f = 0).

Entry:

- 0 = no reset
- 1 = reset totalizer 2
- 2 = reset totalizers 1 and 2

Resetting the internal totalizers 1 and 2 resets the internal registers for external totalizers 1 and 2.

11.9.11 P680 Test Load: Weight (Options)

Selects the method by which the test load is entered into P017.

1 = enter value: returns to P017 for entry of the test load value. This value is calculated by the formula: Total Mass of the test weights/average idler spacing

Example:

3 test weights each weighing 8.2 kg, idler spacing before the scale is 1225 mm, the idler spacing after the scale is 1175 mm.

The average idler spacing is 1225 +1175/2=1200 mm or 1.2 m

Total mass of test weights/average idler spacing = 3X8.2 kg/1.2 m = 24.6/1.2 = 20.5 kg/m

2 = enter data: advances to P681 and P682 for entry of required data to automatically calculate and enter the test load into P017.

11.9.12 P681 Total Mass of Test Weights

For test load data entry (P680=2) this parameter is enabled for entry of the total mass of all of the test weights used for span calibration. The mass units are determined in P004 (imperial=1, metric=2).

11.9.13 P682 Average Idler Spacing

For test load data entry (P680=2) this parameter is enabled for entry of the average idler space before and after the scale. On multiple scale idler systems, this includes the entire weigh area. The length units are determined in P004 (imperial=1, metric=2).

11.9.14 P690 Speed Constant Entry

Selects the method by which the speed constant is entered, for both speed sensors (P690-01 or $02)^{1)}$.

1) BW500/L has only one speed input

1 = calculated, this selection returns the program to appropriate P015 for entry of speed constant:

(speed sensor pulses per revolution)/(pulley circumference (m or ft) / revolution)

e.g:

WS300-256 PPR mounted on 6" Bend Pulley

(256 pulses per revolution)/(0.478 meters per revolution) = 534.694 pulses per meter or 162.975 pulses per feet

OR

2 = sensor data, the selection forwards the program to P691 and P692 for entry of the required sensor data for automatic calculation. The calculated value is automatically entered into P015-01 or 02.

11.9.15 P691 Drive Pulley Diameter

For speed constant entry (P690 = 2), this parameter is enabled for entry of the drive pulley diameter (P691-01 or $02)^{1}$).

Enter the pulley diameter (units determined in P004).

1) BW500/L has only one speed input

11.9.16 P692 Pulses Per Sensor Revolution

For speed constant entry (P690 = 2), this parameter is enabled for entry of the pulses per revolution that the speed sensor delivers (P692-01 or 02)¹⁾.

Enter the pulses per revolution from the speed sensor nameplate.

1) BW500/L has only one speed input

11.10 ECal Parameters (P693 – P698)

11.10 ECal Parameters (P693 – P698)

Accessible only through P017 for ECal test reference. After Ecal completion, only a zero calibration is necessary to allow access to the **RUN** mode.

Note

ECal is not available on six load cell belt scales.

11.10.1 P693 Load Cell Capacity Units

Determines the units used for entering eCal data:

- 1 = kg
- 2 = lb
- $3 = Other (mV Span)^{1)}$

¹⁾ In the case of other, software jumps to P699 since data entry P694 through P698 are not applicable if P693=4.

11.10.2 P694 ECal Load Cell Capacity

Enters the load cell's weighing capacity for the selected cell (f = 1.0).

- -01 = load cell A
- -02 = load cell B
- $-03 = load cell C^{2)}$
- $-04 = load cell D^{2}$

Enter the value in the units corresponding to the scale selection, e.g. in kg if P693 = 1, or lb. if P693 = 2 or 3.

²⁾ Not available with BW500/L

11.10.3 P695 ECal Load Cell Sensitivity

Enters the load cell's sensitivity for the selected cell (f = 1.0).

- -01 = load cell A
- -02 = load cell B
- $-03 = load cell C^{2)}$
- $-04 = load cell D^{2)}$

Enter the value in mV/V obtained from load cell nameplate.

11.10.4 P696 ECal Load Cell Excitation

Determines the excitation applied to the load cells.

Nominally this value is 10 V. However, a measurement of the voltage at the load cell provides the most accurate entry.

Enter the load cell excitation in VDC.

11.10.5 P697 ECal Idler Spacing

Enters the measured distance between the weighing idlers. Refer to the associated belt scale instruction manual (f = 1.0).

Distance units are:

feet: if the imperial system of measurement has been selected, P004 = 1

metres: if the metric system of measurement has been selected, P004 = 2


Enter the distance to three decimal points.

²⁾ Not available with BW500/L

11.10 ECal Parameters (P693 – P698)

11.10.6 P698 ECal Conveyor Inclination

Enters the inclination or declination angle of the conveyor at the point where the belt scale is installed (f = 0.0000).



Enter the inclination in degrees.

Upon entry, display jumps to P017 to display the design load value as the test load.

11.10.7 P699 ECal mV Span

Enter the mV span corresponding to 0 to 100% full scale load.

Upon entry, display jumps to P017 to display the design load value as the test load.

11.10.8 P735 Back Light

Sets the intensity of the back light for the LCD (f = 10).

Entry:

0 = off

1 to 10 = low to high

11.10.9 P739 Time Zone

The offset from Greenwich mean time (GMT) of local time.

This parameter does not affect any timed events because all times are local. It can be accessed by a remote computer for synchronization purposes.

Enter local time zone -12 to 12

11.11 Communication (P740 - P799)

Note

Changes to these parameters are not effected until the power to the unit is turned off and then back on.

These parameters cover the various communications formats supported by the BW500 and BW500/L: serial printer, Dolphin Plus, SmartLinx, and Modbus.

11.11.1 P742 Word Order Parameter

Note

This parameter affects SmartLinx and Modbus communications

This value determines the format of all unsigned, double-register integers (UINT32), except for those in the direct parameter access.

Values	Description
Of	most significant byte (MSB) is given first
1	least significant byte (LSB) is given first

11.11.2 P750 – P769 SmartLinx Module Specific Parameters

These parameters are specific to the SmartLinx module installed. Refer to the module documentation for a list and description of the specific parameter requirements.

11.11.3 P770 – P789 Local Port Parameters

These parameters are specific to programming of the BW500 and BW500/L communication ports. Refer to Communications (Page 130) for a listing and description of these parameters.

11.12 SmartLinx Hardware Testing

These parameters are used to test and debug a SmartLinx card (if installed).

11.12 SmartLinx Hardware Testing

11.12.1 P790 Hardware Error

The results of ongoing hardware tests in the communications circuitry.

Values	Description
PASSf	No errors
FAIL	least significant byte (LSB) is given first Error oc- curred communicating with card; device will try to reinitialize communications with card. If message continues, record values in P791 and P792 and contact your local Siemens representative.
ERR1	No module installed, or module not supported; SmartLinx communications have been disabled

If FAIL or ERR1 is displayed in P790 (Hardware Error), go to P791 (Hardware Error Code) and P792 (Hardware Error Count) for information about the error.

11.12.2 P791 Hardware Error Code

Indicates the precise cause of Fail or ERR1 condition from P790.

Values	Description
Of	No errors
Any other value	Error code; provide this code to your Siemens representative for troubleshooting

11.12.3 P792 Hardware Error Count

A count that increments by 1 each time Fail is reported in P790 (Hardware Error).

Values	Description
	Error count; provide this number to your Siemens representative for troubleshooting.

11.12.4 P794 SmartLinx Module Type

This parameter is used to identify the module type when SmartLinx is used. If you are not using SmartLinx, this parameter is not functional. Please see the associated SmartLinx instruction manual for a full description of this parameter.

11.12.5 P795 SmartLinx Protocol

This parameter is used to identify the protocol when SmartLinx is used. If you are not using SmartLinx, this parameter is not functional. Please see the associated SmartLinx instruction manual for a full description of this parameter.

If a SmartLinx module is not configured, P795 will have a value of either 255 or 0.

11.12.6 P799 Communications Control

Assigns programming control through the local keypad (or Dolphin Plus, P770 = 1), or through a Modbus protocol (P770 = 2 or 3)

Entry:

0 = local

1 = modbus

11.13 Test and Diagnostic (P900 - P951)

Note

These parameters are used for test and diagnostic purposes.

11.13.1 P900 Software Revision

Displays the EPROM (Flash ROM) software revision level.

11.13.2 P901 Memory Test

Tests the memory. Test is initiated by scrolling to the parameter or repeated by 'pressing enter'

Display:

PASS = normal

FAIL = consult Siemens.

11.13 Test and Diagnostic (P900 - P951)

11.13.3 P911 mA Output Test

Tests the mA output value for the output selected, outputs 1 to 3 (P911 -01 to -03)1)

Displays the value from the previous measurement. A test value can be entered and the displayed value is transmitted to the output. Upon returning to the **RUN** mode, the parameter assumes the actual mA output level (f = 0).

Use the **UP** and **DOWN** arrow to scroll the value

1) BW500/L has one output only

11.13.4 P914 mA Input Value

Displays the current mA input value for the input selected, inputs 1 to 2 (P914 – 01 to -02).

Note

- Not applicable if mA I/O board is not connected.
- Not available for BW500/L

11.13.5 P918 Speed Input Frequency

Displays the frequency of the speed input signal in Hertz.

11.13.6 P931 Running Totalizer

- 1 = Total 1
- 2 = Total 2
- 3 = Verification Total
- 4 = Material Test Load
- 5 = Batch Total
- 6 = NTEP Total
- 7 = OCal Start Total
- 8 = 0Cal End Total

11.13.7 P940 Load Cell mV Signal Test

Displays the raw (unbalanced) mV signal input for the selected load cell, load cells A to $D^{1)}$ (P940 – 01 to – 04).

Range 0.00 - 50.0 mV.

1) Depending on the number of load cells selected by P003, not all load cells may be in use.

11.13.8 P943 Load Cell A/D Reference

Displays the A/D reference value for the selected load cells. These values are affected by load cell balancing (P295).

Load cells are:

- -01 = A and B
- $-02 = C \text{ and } D^{2)}$
- -03 = A and B plus C and D²⁾
- -04 = A
- -05 = B
- $-06 = C^{2}$
- $-07 = D^{2}$

11.13.9 P948 Error Log

Displays a log of the last 25 error or alarm events (P948 - 01 to - 25) that have occurred. Event 01 is the current error.

Display:

0 = no error

= error code; refer to *Troubleshooting*

11.13.10 P950 Zero Register

Registers the number of zero calibrations that have been done since the last master reset (f = 0).

11.13.11 P951 Span Register

Registers the number of span calibrations for the span selected, span 1 to 8 (P951 - 01 to - 08), that have been done since the last master reset (f = 0).

²⁾ Not available for BW500/L

11.13 Test and Diagnostic (P900 - P951)

11.13.12 P952 Design Load

Displays the value of the design load, which corresponds to the full scale value for alarm and mA output functions. The design load is calculated, based on the design rate and design speed (f = 0.00).

11.13.13 P999 Master Reset

Resets parameters and totalizers to their factory setting (f = 0).

Enter 9 to execute the reset.

Diagnostics and troubleshooting 12

12.1 Generally

- 1. First check to see that:
 - There is power at the unit
 - The LCD is showing something
 - The device can be programmed using the fixed keypad.
- 2. Then, check the wiring pin outs and verify that the connection is correct.
- 3. Next, go over the setup parameter P770 to P779 and verify that these values match the settings in the computer that you are using to communicate with it.
- 4. Finally, if you should check that the port you are using on the computer. Sometimes trying a different Modbus driver will solve the problem. An easy stand-alone driver called ModScan32, is available from Win-Tech at www.win-tech.com (www.win-tech.com). We have found that this driver has been very useful to test communications.

12.2 Specifically

Q1: I tried to set a Siemens device parameter, but the parameter remains unchanged.

A1:

- a. Try setting the parameter from the keypad. If it can't be set using the keypad, check the lock parameter (P000) and
- b. Check to ensure that the SW1 (certification switch) is not in the certification position.

Error Code	! a)	Code Name	Message/Action
201		Error - Load Cell A & B	Reading between A & B > 15000, or no signal. Check wiring.
202		Error - Load Cell C & D	Reading between C & D > 15000, or no signal. Check wiring.
203	*	Err: 203	Memory failure test. Consult Siemens.
210	*	Remote Totalizer 1 exceeded	Increase resolution.
211	✓	Remote Totalizer 2 exceeded	Increase resolution.
212	*	Maximum speed ex- ceeded	Speed is > twice the design speed. Check design belt speed, actual belt speed, speed constant. Perform speed constant adjust (P018) if necessary.
213	*	Maximum rate exceed- ed	Rate is > three times the design rate. If no me- chanical cause, check to see if re-rating the de- sign rate is required.
220		Span too low	The span is based on the Design Load (P952). Ensure that the mV value representing the design load is greater than 1 mV. Typically the Test Load (P017) value is less than the value in P952; if it is greater than P952 check that the values entered in START UP parameters (P001 to P017) are entered correctly. Ensure proper test weight or chain is applied during span calibration.
221		Span out of range	Span deviation > 12.5%. Consider an initial span (P388). Refer to Initial Span.

Error Code	! a)	Code Name	Message/Action
222	*	Auto Zero out of range	Zero deviation > mini- mum limit. Consider an initial zero (P377). Refer to Initial Zero.
223		Security Violation	An attempt to run command / calibration that is not allowed under current security level.
225		BF	Flashes in the bottom right corner of display when battery charge is too low.
227	✓	Err: 227	No process data available. Consult Siemens.
228		Batch pre-act adjust- ment > 10%	Pre-act adjustment is ignored. Tune process to limit batch error.
240		Integrator not config- ured	P002-P017 must be programmed
241	•	No PID mA Input	PID Process Value Source (P402) or PID Setpoint (P414) has been programmed for a mA Input, however mA Input Function (P255) has not been pro- grammed properly.
242	✓	No PID mA Output	PID System (P400) has been turned on, but mA Output (P201) has not been programmed properly.
243		No batch setpoint relay	Batch has been set up, but no relay has been configured for a set- point.
244	/	No speed relay	Second speed sensor configured, but no relay is assigned
PF		Power Failure	Displayed at the bottom right corner of the display if power is interrupted after the integrator has been calibrated.

^{a)} The codes in this column with checkmarks will produce relay output for a diagnostic alarm.

Technical specifications 13

Specification		
Power		
	AC version	100 240 V AC +/- 10%, 50/60 Hz, 55 VA max.
		Fuse FU3 = 2AG, 2AMP, 250V Slo Blo
	DC version	10 - 30 V DC, 26 W max.
		Fuse FU2 = 3.75A Resettable (not user replaceable)
Application		
		 Compatible with Siemens belt scales or equivalent 1, 2, 4, or 6 load cell scales (1 or 2 load cell scales for BW500/L)
		Compatible with LVDT equipped scales, with use of optional interface board
Accuracy		0.1 % of full scale
Resolution	-	0.02 % of full scale
Environmental		
	• Location	Indoor/outdoor
	Altitude	2000 m max.
	Ambient temperature	-20 to 50 °C (-5 to 122 °F)
	Relative humidity	Suitable for outdoor (Type 4X / NEMA 4X /IP65 enclosure)
	Installation category	II
	Pollution degree	4
Enclosure		
	• Type	Type 4X / NEMA 4X / IP65
	• Dimensions	285 mm W x 209 mm H x 92 mm D (11.2" W x 8.2" H x 3.6" D)
	Material	Polycarbonate
Programming	·	Via local keypad and/or Dolphin Plus interface
Display		Illuminated 5 x 7 dot matrix liquid crystal display with 2 lines of 40 characters each
Memory		 Program and parameters stored in non-volatile FLASH ROM, upgradable via Dolphin Plus interface Runtime totalizers and clock settings¹⁾ stored in battery backed RAM, battery P/N BR2330 or use equivalent 3V
		Lithium battery, 5 year life

Inputs	
Load cell	0 45 mV DC per load cell
Speed sensor	Pulse train 0 V low, 5 V high (TTL setting) or 10 24 V high (HTL setting), 1 3000 Hz or open collector NPN switch or relay dry contact
Auto zero	Dry contact from external device
mA	See optional mA I/O board 1)
Auxiliary	5 discrete inputs for external contacts (Low = 0 V, High = 10 24 V), each programmable for either display scrolling, totalizer 1 reset, zero, span, multispan, print, batch reset, or PID function.

¹⁾ Not available with BW500/L.

Outputs			
mA		 1 programmable 0/4 20 mA²⁾, for rate, load, and speed output Optically isolated 0.1 % of 20 mA resolution 750 Ω load max See optional mA I/O board ¹⁾ 	
Load cell		10 V DC compensated excitation for strain gauge type, 6 cells max, BW500 has 4 independent inputs, BW500/L has 2. The maximum load, in either case, must not exceed 150 mA.	
Speed sensor		12 V DC, 150 mA max. excitation	
Remote totalizer 1		Contact closure 10 300 ms duration	
		Solid state relay contact rated 30 V DC, 100 mA max.	
		• Max. contact on-resistance = 36Ω	
		Max. off-state leakage = 1 uA	
Remote totalizer 2		Contact closure 10 300 ms duration	
		Solid state relay contact rated 240 V AC/DC, 100 mA max.	
		• Max. contact on-resistance = 36Ω	
		Max. off-state leakage = 1 uA	
Relay output			
	• BW500	5 alarm/control relays, 1 form 'A' SPST relay contact per relay, max. 5 A at 30 V DC / 250 V AC non-inductive; min. 10 mA at 5 V DC	
	• BW500/L	2 alarm relays	

¹⁾ Not available with BW500/L.

²⁾ Device will output a high current reading upon applying and removing power.

Communications	
Two RS232 ports	
One RS485 port (isolated)	
SmartLinx compatible (see Options below)	

Cable		
One load cell		
	Non-sensing	4 wire shielded, 20 AWG or equivalent, 150 m (500 ft.) max.
	Sensing	6 wire shielded, 20 AWG or equivalent, 300 m (1000 ft.) max.
Two/four/six1) load cells		
	Non-sensing	6 wire shielded, 20 AWG or equivalent, 150 m (500 ft.) max.
	Sensing	8 wire shielded, 20 AWG or equivalent, 300 m (1000 ft.) max.
Speed sensor		3 wire shielded, 18 AWG or equivalent, 300 m 1000 ft.)
Auto zero		1 pair, twisted/shielded, 18 AWG, 300 m (1000 ft.) max.
Remote total		1 pair, twisted/shielded, 18 AWG, 300 m (1000 ft.) max.

¹⁾ For four or six load cell scales, run two separate cables of the two load cell configuration. Four/six load cells not available with BW500/L.

Options		
	Speed Sensor	Siemens MD-36/36A/256 or 2000A, RBSS, TASS, WS100, or WS300, or compatible
	SmartLinx Modules	protocol specific modules for interface with popular industrial communications systems (refer to associated product documentation)
mA I/O board ¹⁾		
	• Inputs	 2 programmable 0/420 mA for PID, control, incline, and moisture compensation, and online calibration Isolated 0.1 % of 20 mA resolution 200 Ω input impedance
	• Outputs	 2 programmable 0/4 20 mA for PID control, rate, load, and speed output Isolated 0.1% of 20 mA resolution 750 Ω load max.
	Output supply	Isolated 24 V DC at 50 mA, short circuit protected
LVDT interface card		For interface with LVDT based scales

¹⁾ Not available with BW500/L.

Weight	2.6 kg (5.7 lb.)	
Approvals		
	BW500	BW500/L
CE ¹⁾ , UKCA ¹⁾ , cCSAus, FM, RCM, GOST	✓	✓
Legal for Canadian Trade - Measurement Canada approved	✓	
Legal for US Trade - NTEP approved	✓	
Legal for European Trade - MID approved	✓	
Legal for International Trade - OIML approved	✓	
Legal for international frade - Office approved	V	

¹⁾ EMC performance available upon request

Certificates 14

14.1 Certification

For installations requiring trade certification, the BW500 and BW500/L provides a certification compliance switch. Refer to the layout diagram.

After certification of the installation has been obtained, the switch is set. The switch must be positioned to the left to enable trade certification compliance.

When the switch is set for certification, editing most parameter values, span calibrations, and main totalizer reset are denied. The maximum acceptable deviation from one zero calibration to another is limited to an accumulated \pm 2% of the zero value, and the totalizer dropout (P619) is limited to 3% or less, when the certification switch is set.

To set the certification switch, disconnect power before opening the enclosure lid.

- slide switch to the left position
- · close the lid
- reconnect the power

Note

Not available with BW500/L.

14.2 Parameters unlocked when certification switch is set:

P000	Security Lock
P009	Time
P100	Relay Function (if P100 is set to '11 - Certification Rate alarm', P100 will be locked)
P560 - P569	Batch Control Functions
P648	Totalizer Reset. Unlock entry #1
P080	Damping Display
P081	Display scroll mode
P400 - P419	PID
P631	Lock index '01', unlock remaining index '02 - 05'
P634	Unlock
P635	Unlock
P647	Unlock

14.3 Certification Printing

14.3 Certification Printing

Certification printing is allowed if the following conditions are met:

- certification switch is set
- rate is below 2 %
- a communications port has been programmed for a printer

The printout must consist of the following:

- Date: YYYY-MM-DDTime: HH:MM:SS
- Instrument ID#: Belt Scale serial number
- Units: Units set in P005
- Start Total: End total of previous print
- End Total: Accumulated totalizer including Start Total
- Net Total: End total minus Start Total

If a power failure occurs during totalization, power failure indicator "PF" will be printed in the middle of a new line, even if it has been cleared from the screen. "PF" will be cleared from the screen after printing.

Appendix

A.1 Appendix I

A.1.1 Memory Backup

The BW500 and BW500/L requires no maintenance or cleaning, other than a periodic replacement of the memory backup battery. Refer to Installing/replacing the back-up battery (Page 39).

A.1.2 Software Updates

Software updates require Siemens Dolphin Plus software, contact your local Siemens representative.

It is recommended that the old software and parameters be saved to your PC before downloading the new software.

Once installed, a master reset (P999) must be done.

The parameters can then be reloaded, either manually or downloaded from the previously saved file. If downloading parameters via Dolphin Plus, confirm that BW500 and BW500/L is in **PROGRAM** mode. The zero and span values are included in the parameter file, However, new zero and span calibrations should be done regardless, and as soon as possible to ensure operating accuracy.

A.1 Appendix I

A.1.3 Calibration Criteria

Zero

- belt must be empty. Run the conveyor for several minutes to limber the belt and ensure that it is empty.
- test weights or chain are not used during a zero calibration
- · conveyor running at normal speed
- moisture input not used during a zero calibration
- inclination will be used if feature is activated

Span

- a zero must be done prior
- belt must be empty
- test weight or chain must be applied
- conveyor running at normal speed test reference (chain or weight applied)
- · moisture input not used
- inclination will be used if feature is activated

PID Systems

- zero and span criteria must be met
- set controller (P400) to manual and adjust the output for 100% belt speed (using the 4 and 8 keys).
 - If the PID is not set to manual, the speed output will be the last value prior to starting the zero or span calibration
- shut off the prefeed to conveyor
- In process where a prefeed device is included, it must be turned off to ensure that no material is fed onto the belt.

A.2 Appendix II

Appendix II: Software Revision History

Software Revision	Date	Changes	
2.00	April 30, 1999	Original software release	
2.01	July 20, 1999	 French language added 38400 baud rate option removed Span updated to reference current zero value NTEP printout added Totalizer rollover updated to 1,000,000 for all resolutions Added units to verification totalizer printout Error display updated to 	
		toggle between error and run mode	
2.02	October 08, 1999	 Limited external contact closure to 300 msec Added software filter to speed signal Factoring now based on current zero value Individual damping added for Rate, Load and Speed display Parameters saved permanently in Flash German added Devicenet added Display only the load cells selected 	
2.03	May 16, 2000	Allow proper startup if no RAM battery installed	
2.04	June 30, 2000	Larger flash added	

A.2 Appendix II

Software Revision	Date	Changes
2.05	February 07, 2001	SmartLinx update time increased to 250 msec.
		Batch totalizer was made accessible using Modbus
		New real time clock added
		BW500 calibrations no long- er affected by time out
		 Auto Zero alarm relay will now reset toggling from program to run mode
2.06	February 17, 2001	Updated calibration error so that it will not display a neg- ative 0 error, -0.00%
3.00	April 27, 2001	Added flowmeter option
		Parameters are no longer changeable with remote communications when certi- fication switch set
3.01	July 17, 2001	Increased maximum idle time for SmartLinx to 9999 seconds
		 Fixed totalizer error when load is negative and totalizer drop out is 0.00
		Allowed access to P635 in certification mode
		Setting of certification switch changes totalizer dropout to 0.00
3.02	August 07, 2001	Fixed bug in totalizer P619 totalizer dropout

Software Revision	Date	Changes
3.03	February 20, 2002	Fixed timing issue with in- terval printing
		Added % rate and % load to PID setpoint configuration, P414
		Updated Auto Zero to allow run display to be seen, AZ now flashes in bottom right hand corner of display
		Updated span adjust calculation
		Increased totalizer resolution to 100,000,000
		Improved error interruption on display
		Fixed zero and span calibra- tion using remote communi- cations
3.04	May 09, 2002	Fixed SmartLinx error check- ing
		Fixed error with discrete inputs
		Added P419 PID freeze ena- ble/disable
		Updated zero calibration when certification switch set, now references last op- erator initiated zero prior certification switch set
		Added power failure indicator on display, "PF"
		Added online calibration
3.05	November 11, 2002	SmartLinx memory map increased
		Improve external totalizer contact closure duration
3.06	July 23, 2003	Updated PID control be- tween remote/ local setpoint
		Improve Dolphin Plus com- munications
		Batch setpoint now adjusta- ble in "RUN" mode
		Slowed down the display when scroll key is held

A.2 Appendix II

Software Revision	Date	Changes	
3.08	March 1, 2006	 Remote zero and span calibrations fixed Differential speed detection added Moisture meter added Inclinometer feature added 	
3.09	August 8, 2006	 Remote totalizer exceeded error fixed Totalizer dropout (P619) now limited to 3% or less when certification switch enabled 	
3.11	March 31, 2009	 Second speed sensor accuracy at frequencies below 10 Hz fixed Parameter download using Dolphin Plus fixed (Dolphin Plus patch required) Electronic load cell balancing of C&D fixed Word order format with remote communication fixed Integrator serial number added to printout Power failure message added to printout 	
3.12	August 2009	Fixed word order for SmartLinx	

Software Revision	re Revision Date Cha		
3.13	December 2010	 BW500/L option added Updated eCal and test load parameters Added option 11 to P100 Zero and Span show progress in % Added display and mA dropout Totalizer dropout (P619) now limited to 25% Improve Modbus communication Improve Diagnostic parameter Remote span does not require zero prior to running Online calibration now adjusts P017 value New language options for print strings Added load cell values to Modbus map 3 decimal place resolution on batch totalizer added Updated Display options for remote parameters changes 	
3.13.03	June 12, 2012	Added Portuguese, Italian and Russian languages	
3.13.04	Feb 26, 2013	Added Smartlinx options, Profinet, Modbus TCP/IP, Ethernet/IP	

Product documentation and support

B

B.1 Product documentation

Process instrumentation product documentation is available in the following formats:

- Certificates (http://www.siemens.com/processinstrumentation/certificates)
- Downloads (firmware, EDDs, software) (http://www.siemens.com/processinstrumentation/downloads)
- Catalog and catalog sheets (http://www.siemens.com/processinstrumentation/catalogs)
- Manuals (http://www.siemens.com/processinstrumentation/documentation)

You have the option to show, open, save, or configure the manual.

- "Display": Open the manual in HTML5 format
- "Configure": Register and configure the documentation specific to your plant
- "Download": Open or save the manual in PDF format
- "Download as html5, only PC": Open or save the manual in the HTML5 view on your PC

You can also find manuals with the Mobile app at Industry Online Support (https://support.industry.siemens.com/cs/ww/en/sc/2067). Download the app to your mobile device and scan the device QR code.

Product documentation by serial number

Using the PIA Life Cycle Portal, you can access the serial number-specific product information including technical specifications, spare parts, calibration data, or factory certificates.

Entering a serial number

- 1. Open the PIA Life Cycle Portal (https://www.pia-portal.automation.siemens.com).
- 2. Select the desired language.
- 3. Enter the serial number of your device. The product documentation relevant for your device is displayed and can be downloaded.

To display factory certificates, if available, log in to the PIA Life Cycle Portal using your login or register.

Scanning a QR code

- 1. Scan the QR code on your device with a mobile device.
- 2. Click "PIA Portal".

To display factory certificates, if available, log in to the PIA Life Cycle Portal using your login or register.

B.2 Technical support

Technical support

If this documentation does not completely answer your technical questions, you can enter a Support Request (http://www.siemens.com/automation/support-request).

For help creating a support request, view this video here (www.siemens.com/opensr).

Additional information on our technical support can be found at Technical Support (http://www.siemens.com/automation/csi/service).

Service & support on the Internet

In addition to our technical support, Siemens offers comprehensive online services at Service & Support (http://www.siemens.com/automation/serviceandsupport).

Contact

If you have further questions about the device, contact your local Siemens representative at Personal Contact (http://www.automation.siemens.com/partner).

To find the contact for your product, go to "all products and branches" and select "Products & Services > Industrial automation > Process instrumentation".

Contact address for business unit: Siemens AG Digital Industries Process Automation Östliche Rheinbrückenstr. 50 76187 Karlsruhe, Germany

Glossary

Auto Zero

Allows a zero calibration to be performed automatically in **RUN** mode when the load drops below the preset amount (P371) of design for 1 complete calibration period (P360).

Auxiliary Inputs

Can be programmed to allow the use of an external contact to provide the following functions, display scroll, totalizer 1 reset, Zero, Span, Multispan, Print, Batch reset, or PID functions.

Batching

The accumulation of a predetermined quantity of material.

Contacts

A junction of electrical conductors in open (not connected) or closed (connected) states.

Damping

Provides control over the speed at which the displayed rate, load, speed readings, and output functions are updated in response to changes in the internal rate signals.

Design Rate

This is the maximum material flow rate for this particular application (100% full scale).

Differential Speed

Difference in speed at two points in a mechanical system.

Direct Span

If replacing software or hardware, this allows the entry of the previously recorded span value.

Direct Zero

If replacing software or hardware, this allows the entry of the previously recorded zero value.

Factoring

Used to calculate the test load value of a new or unknown test weight using the current span as reference.

Inclinometer

Accepts incline information about conveyor or scale.

Initial Span

Usually the first span performed, it is used as reference for all other spans to determine whether they have deviated beyond the accumulated +/- 12.5%.

Initial Zero

Usually the first zero performed, it is used as reference for all other zeros to determine whether they have deviated beyond the Zero Limit (P370).

Input/Output Trim

Allows the 4 and 20 mA values to be adjusted and verified with an external source (meter).

Linearization

Compensates for non-linear output of the belt scale caused by varying load rates.

Load Cell

Strain Gauge type transducer that produces an electrical output proportional to force (load) applied.

LVDT

An electromechanical transducer that produces an electrical output proportional to the displacement of a separate movable core.

mA

A unit of measure for current flow, milliamperes.

Material Test

Material samples used to verify the accuracy of the span calibration.

Modbus

An industry standard protocol used by popular SCADA and HMI systems.

Moisture sensor

A mA input function to incorporate moisture reading from an external moisture sensor.

Multispan

Since every material has its own unique physical properties, and may impact differently, a span calibration is required for each material to realize maximum accuracy.

PID

Proportional Integral Derivative control is used to control the feed rate to a setpoint, either internal to the BW500 or external.

RAM

Random Access Memory.

Random Access Memory

Memory that has both read and write capabilities.

Relay

An electromechanical device with contacts that can be closed or opened by energizing a coil.

Routine Span

Any operator initiated span calibration.

Routine Zero

Any operator initiated zero calibration.

Setpoint

A value that the integrator is trying to match.

SmartLinx

An interface to popular industrial communication systems.

SPA

Single Parameter Access, used to view or edit parameters through the available communication ports.

Span

This is a count value representing the mV signal provided by either the LVDT or Load Cell at 100% design load.

Span Register

This is the number of span calibrations that have been performed since the last master reset.

Test Weight

A calibrated weight which will represent a certain load on the scale.

Totalizer

An incremental counter that records the total of material that has been monitored.

Zero Register

Shows the number of zero calibrations that have been performed since the last master reset.

Index

	online
A	Calibration
alarm	online, 85
	Catalog
condition, 105, 170	catalog sheets, 224
display, 129	Certificates, 224
event, 128	Command Controls, 150
function, 166	communication
high, 168	configuration ports, 132
mode, 169	ports, 130
Approvals, 214	communications, 130
Auto Zero, 75	configuring ports, 132
Autobaud, 135	ports, 12, 132
Auxiliary Input, 83, 83, 83	protocol, 132, 134
Auxiliary Input	Communications, 212
Auxiliary Input	configuring communication ports, 132
	Connections, 82, 110
	control
В	feed forward, 117
halancing 52	integral, 115
balancing, 52	<u> </u>
batching, 125	output, 115
baud rate, 134, 156	PID, 118, 171
belt speed compensation, 62	proportional, 115
bit values, 153	rate, 110
	system, 115
C	controller
C	function, 121
Cable, 213	logic, 107, 195
calibration	PID, 109, 118
online, 87, 89, 179, 213, 223	setpoint, 110
calibration	Customer Support, (Refer to Technical support)
ECal, 52, 164, 198, 198	
initial, 52, 58, 73, 78, 80, 82	_
online	D
calibration	Damping, 103
initial	data
calibration	advanced access, 145
ECal	bits, 135
calibration	types, 153
online	Date and Time, 147
calibration	deviation
ECal	
	alarm, 105
calibration	Device Identifier, 145
ECal	Device State, 149
calibration	Diagnostic, 153
online	Dial-up modem, 130
	Direct span, 80

calibration

direct zero, /4	K
discrete	Key, 41
input, 211	Key, 11
Dolphin, 13	
Plus, 13, 130, 133, 138	L
Dolphin"	L
protocol, 138	Leased line modem, 130
Downloads, 224	linearization, 94
	load cell, 210
	load cells, 52
E	LVDT, 28, 210
F1 100	
Ecal, 198	
ECal, 59	M
error	A 422 244
check, 140	mA, 122, 211
codes, 147	analog, 12
handling, 159	I/O board, 110
error"	input, 104, 122, 171
messages, 159	output, 121, 171
example modem setup, 156	output test, 204
External Totalizer, 108	Main entry, 158
	Manuals, 224
	Mapping, 145
F	maximum separation, 131
factorium 02 02	Milltronics BW500, 12
factoring, 92, 93	Milltronics BW500 and BW500/L features, 12
Format register, 145, 147	Milltronics BW500/L, 12
Format Register, 146	Modbus, 139
function, 211	how modbus works, 139
alarm, 105	protocol, 130, 139
output, 105	responses, 158
pre-act, 129	RTU/ASCII protocol, 139
	Modbus RTU Software, 156
	modem, 130
Н	modems, 130, 155
Handshaking Area, 145	available, 135
Hanging Up, 136	example setup, 156
High Alarm, 168	hanging up, 136
Hotline, (Refer to Support request)	inactivity timeout, 136
Troume, (Neter to Support request)	picking, 155
	setting up, 155
I	setung up, 155
1	modes
I/O board, 122	run mode, 65
Incline compensation, 102	•
initial span, 78	Moisture Compensation, 101
initial startup, 118	mounting
initial zero, 70, 72	wall mount, 18
Input, 211	Mounting the Enclosure, 17
Installation, 14, 18	multispan, 81, 93
installing or replacing the battery, 39	
Instrumentation I/O, 12	
•	

N	P215 20 mA output trim, 172
network address, 134, 137, 137, 141	P220 mA output damping, 173
Non metallic enclosure, 14	P250 mA input range, 173
non-linearity, 94	P255 mA input function, 173
<i>5,</i>	P261 mA input trim, 174
	P262 mA input trim, 174
0	P270 auxilliary input function, 175
Online Calibration OF	P341 days of service, 178
Online Calibration, 85	P350 calibration security, 179
Options, 213 Output, 104, 212	P355 online calibration feature, 179 P356 online calibration reference weight, 179
Output, 104, 212	P357 online calibration limits, 180
	P359 factoring, 180
P	P360 calibration duration, 180
•	P365 multispan, 181
P388 and enter EDIT mode, 79	P367 direct zero entry, 181
P392 linearizer compensation %, 183	P370 zero limit deviation, 182
P771 (IP) network address, 134, 136, 137	P370 zero limit deviation, 162
P772 (IP) baud rate, 134	P371 auto zero initiation upper limit, 182
P774 (IP) data bits, 135	P377 initial zero, 182
P775 (IP) stop bits, 135	P388 initial span, 183
P778 (IP) modem available, 135	P390 linearizer, 183
P779 (G) modem inactivity timeout, 136	P391 linearizer load points, 183
parameter, 183	P398 moisture content, 184
P000 security lock, 160	P398-02 moisture content, 184
P001 language, 160	P399 incline sensing, 184
P002 test reference selection, 161	P400 PID system, 185
P003 number of load cells, 161	P401 PID update time, 185
P004 rate measurement system, 161	P402 PID process value source, 185
P005 design rate units, 162	P405 proportional terms, 186
P008 date, 162	P406 integral term, 186
P009 time, 162	P407 derivative term, 186
P011 design rate, 163	P408 feed forward term, 186
P014 design speed, 163	P410 manual mode output, 186
P015 speed constant, 163	P414 setpoint configuration, 187
P016 belt length, 163	P415 local set point value, 187
P017 test rate, 164	P416 external setpoint, 187
P019 manual span adjust, 165	P418 remote setpoint ratio, 188
P022 minimum speed frequency, 165 P080 damping display, 165	P419 PID freeze option, 188
P081 display scroll mode, 166	P560 batch mode control, 188
P100 relay function, 167	P564 batch setpoint, 189
P101 high alarm/deviation alarm, 168	P566 batch pre-warn, 189
P102 low alarm, 168	P567 batch pre-warn setpoint, 189
P107 relay alarms, 169	P568 batch pre-act, 190
P118 relay logic, 170	P569 manual batch pre-act amount, 190
P119 relay override, 170	P598 span adjust percentage, 190
P200 mA output range, 171	P619 totaling dropout, 191
P201 mA output function, 171	P620 display zero dropout, 191
P204 mA output average, 172	P631 totalizer resolution, 192
P212 mA output minimum, 172	P634 communication totalizer resolutions, 193
P213 mA output maximum, 172	P635 verification totalizer, 194
P214 mA output trim, 172	P638 external totalizer resolution, 195

P643 external contact closure, 195	PID Systems, 218
P647 totalizer display, 196	PID Tuning, 153
P648 totalizer reset, internal, 196	product ID, 145
P690 speed constant entry, 197	PROGRAM, 40
P691 drive pulley diameter, 197	protocol, 133
P692 pulses per sensor revolution, 197	proceedi, 133
P693 load cell capacity units, 198	
· · · · · · · · · · · · · · · · · · ·	R
P694 Ecal load cell capacity, 198	N
P695 Ecal load cell sensitivity, 199	Radio modem, 130
P696 Ecal load cell excitation, 199	RAM, 210
P697 Ecal idler spacing, 199	rate
P699 Ecal mV span, 200	control, 110, 118
P735 back light, 200	Reading Parameters, 145
P739 time zone, 200	Refer to, 18
P770 (IP) protocol, 133	
P770-P789 Local port parameters, 201	Register Map, 141, 145
P773 parity, 134	relay, 110, 125, 127, 167, 168, 169, 169, 170
P781 data message, 137	relay
P794 SmartLinx module type, 202	alarm, 105
P795 SmartLinx protocol, 203	functions, 168
P901 memory test, 203	relay
P911 mA output test, 204	relay
	relay
P914 mA input value, 204	relay
P918 speed input frequency, 204	relay
P931 running totalizer, 204	batch, 189
P940 load cell mV signal test, 205	relay
P943 load cell A/D reference, 205	setpoint, 190
P948 error log, 205	relay
P999 master reset, 206	contacts, 212
relay dead band, 169	relay/, 166
parameters	remote
P358 online calibration activation, 180	
P750 - P769 SmartLinx module specific	setpoint, 188
parameter, 201	reset
P771 protocol address, 134	master, 108, 206
P790 hardware error, 202	reset a parameter value, 44
P792 hardware error count, 202	RS232 Port 3, 36
parity, 134	RUN, 40
read and write, 145	RUN mode, 61
reading, 145	
SmartLinx hardware testing, 201	
<u> </u>	S
values, 149	CCADA 120
writing, 146	SCADA, 130
paramter	Service, 225
P799 communications control, 203	Service and support
PID, 105, 118, 211	Internet, 225
function, 104	setpoint, 189
manual mode, 121	batch, 128
setpoint, 104, 173	local, 187
setup and tuning, 117, 118	PID, 173
PID	rate, 118
PID control, 109	relay, 190

remote, 188	W
Slave, 157	
SmartLinx, 130, 131, 133	web site, 139
Software updates, 217	Weight, 214
span, 80, 181	wiring 9-pin to RJ-11, 37, 39
adjust, 65, 69	guidelines, 131
calibation, 82	Writing Parameters, 146
calibration, 65, 69, 81, 84, 94	Withing Furdiffictors, 1 10
correction, 81	
direct, 80	Z
initial, 78, 80, 82	
multispan, 81, 82	zero, 211
mV, 200	calibration, 58, 92
recalibration, 71, 73 remote, 82	direct, 74 initial, 72
routine, 76	recalibration, 69
verification, 194	routine, 70
Span, 218	verification, 194
span adjust value, 66	Zero, 218
Span Calibration, 59	
Specification, 210	
stop bits, 135	
Support, 225	
Support request, 225	
Т	
l	
Technical support, 225	
partner, 225	
personal contact, 225	
term	
derivative, 115, 186	
forward, 186	
integral, 186 proportional, 186	
test	
load, 65, 93, 180, 200	
material, 65, 96, 184	
value, 204	
Text Messages, 154	
To access parameter directly, 43	
To change a parameter value, 44	
To select a parameter, 43	
totalization, 106	
totalizer, 107, 107, 196	
functions, 107	
internal, 194	
master, 106 totalizer	
totalizer	
troubleshooting, 207	

For more information

Level measurement: www.siemens.com/level

Weighing and batching systems: www.siemens.com/weighing

Siemens AG Process Industries and Drives Process Automation 76181 Karlsruhe Germany

© Siemens AG 2021 Subject to change without prior notice Printed in Canada A5E33482052-AG





