

# SIEMENS

## SITRANS F

### Coriolis flowmeters SITRANS FC410/FCS400

#### Operating Instructions


7ME461 (Standard and hygienic sensor)


<u>Introduction</u>	<b>1</b>
<u>Safety notes</u>	<b>2</b>
<u>Description</u>	<b>3</b>
<u>Installing/mounting</u>	<b>4</b>
<u>Connecting</u>	<b>5</b>
<u>Commissioning</u>	<b>6</b>
<u>Operating FC410</u>	<b>7</b>
<u>Parameter assignment FC410</u>	<b>8</b>
<u>Service and maintenance</u>	<b>9</b>
<u>Diagnostics and troubleshooting FC410</u>	<b>10</b>
<u>Technical data</u>	<b>11</b>
<u>Dimension drawings</u>	<b>12</b>
<u>Product documentation and support</u>	<b>A</b>
<u>Technical reference</u>	<b>B</b>
<u>Modbus communication FC410</u>	<b>C</b>


## Legal information

### Warning notice system

This manual contains notices you have to observe in order to ensure your personal safety, as well as to prevent damage to property. The notices referring to your personal safety are highlighted in the manual by a safety alert symbol, notices referring only to property damage have no safety alert symbol. These notices shown below are graded according to the degree of danger.

 <b>DANGER</b>
indicates that death or severe personal injury <b>will</b> result if proper precautions are not taken.

 <b>WARNING</b>
indicates that death or severe personal injury <b>may</b> result if proper precautions are not taken.

 <b>CAUTION</b>
indicates that minor personal injury can result if proper precautions are not taken.

<b>NOTICE</b>
indicates that property damage can result if proper precautions are not taken.


If more than one degree of danger is present, the warning notice representing the highest degree of danger will be used. A notice warning of injury to persons with a safety alert symbol may also include a warning relating to property damage.

### Qualified Personnel

The product/system described in this documentation may be operated only by **personnel qualified** for the specific task in accordance with the relevant documentation, in particular its warning notices and safety instructions. Qualified personnel are those who, based on their training and experience, are capable of identifying risks and avoiding potential hazards when working with these products/systems.

### Proper use of Siemens products

Note the following:

 <b>WARNING</b>
Siemens products may only be used for the applications described in the catalog and in the relevant technical documentation. If products and components from other manufacturers are used, these must be recommended or approved by Siemens. Proper transport, storage, installation, assembly, commissioning, operation and maintenance are required to ensure that the products operate safely and without any problems. The permissible ambient conditions must be complied with. The information in the relevant documentation must be observed.

### Trademarks

All names identified by ® are registered trademarks of Siemens AG. The remaining trademarks in this publication may be trademarks whose use by third parties for their own purposes could violate the rights of the owner.

### Disclaimer of Liability

We have reviewed the contents of this publication to ensure consistency with the hardware and software described. Since variance cannot be precluded entirely, we cannot guarantee full consistency. However, the information in this publication is reviewed regularly and any necessary corrections are included in subsequent editions.

# Table of contents

<b>1</b>	<b>Introduction</b> .....	<b>7</b>
1.1	Document history .....	7
1.2	Product compatibility FC410 .....	7
1.3	Items supplied .....	8
1.4	Checking the consignment.....	9
1.5	Security information .....	9
1.6	Transportation and storage .....	10
<b>2</b>	<b>Safety notes</b> .....	<b>11</b>
2.1	Preconditions for use .....	11
2.2	Laws and directives .....	11
2.2.1	Conformity with European directives .....	12
2.3	Requirements for special applications .....	13
2.4	Use in hazardous areas.....	13
2.4.1	Installation in hazardous areas .....	14
2.4.2	Maximum temperature specifications for Ex use .....	15
<b>3</b>	<b>Description</b> .....	<b>19</b>
3.1	System integration.....	19
3.2	Modbus RTU technology FC410.....	19
3.3	Design .....	20
3.4	Nameplate layout.....	22
3.5	Features .....	27
3.6	Applications.....	27
3.7	Approvals .....	28
<b>4</b>	<b>Installing/mounting</b> .....	<b>29</b>
4.1	Basic safety notes.....	29
4.1.1	Installation location requirements .....	31
4.1.2	Proper mounting.....	32
4.2	Installation instructions.....	32
4.2.1	Sensor installation .....	32
4.2.1.1	Mounting the sensor.....	35
4.2.1.2	Hydrostatic testing.....	37
4.2.1.3	Installing with insulation .....	37
4.2.1.4	Pressure guard .....	37
4.3	Disassembly.....	39

<b>5</b>	<b>Connecting .....</b>	<b>41</b>
5.1	Basic safety notes.....	41
5.2	Wiring .....	44
5.3	Connecting FC410/FCS400.....	44
5.3.1	Setting the EOL termination DIP switches .....	47
<b>6</b>	<b>Commissioning .....</b>	<b>49</b>
6.1	Basic safety notes.....	49
6.2	General requirements .....	50
6.3	Remote commissioning with PDM FC410.....	50
6.3.1	Functions in SIMATIC PDM.....	51
6.3.2	Commissioning steps .....	51
6.3.3	Initial setup.....	51
6.3.4	Adding a device to communication network .....	53
6.3.5	Configuring a new device .....	56
6.3.6	Wizard - Quick Start via PDM .....	57
6.3.7	Wizard - Zero Point Adjustment .....	62
6.3.8	Changing parameter settings using SIMATIC PDM .....	65
6.3.9	Parameters accessed via drop-down menus .....	66
6.3.10	Process values.....	67
<b>7</b>	<b>Operating FC410.....</b>	<b>69</b>
7.1	Remote operation .....	69
7.1.1	Overview of device configuration software .....	69
7.1.2	SIMATIC PDM .....	69
7.1.2.1	Check SIMATIC PDM version .....	69
7.1.2.2	Updating the Electronic Device Description (EDD) .....	70
7.1.2.3	Set address .....	70
<b>8</b>	<b>Parameter assignment FC410.....</b>	<b>71</b>
8.1	Functions.....	71
8.1.1	Process values.....	71
8.1.2	Low flow cut-off.....	76
8.1.3	Empty tube monitoring .....	77
8.1.4	Process noise damping.....	77
8.1.5	Totalizer.....	78
8.1.6	Security .....	79
8.1.7	Simulation .....	80
8.1.8	Float transmission.....	80
<b>9</b>	<b>Service and maintenance .....</b>	<b>83</b>
9.1	Basic safety notes.....	83
9.2	Recalibration.....	84
9.3	Cleaning .....	84
9.4	Maintenance and repair work .....	85
9.4.1	Maintenance information FC410.....	87
9.4.2	Service information FC410.....	87

9.5	Replacing the device .....	88
9.6	Spare parts/Accessories .....	88
9.6.1	Ordering of spare parts .....	88
9.6.2	Replaceable components .....	88
9.7	Transportation and storage .....	89
9.8	Return procedure .....	89
9.9	Disposal.....	90
9.9.1	Special disposal required .....	90
<b>10</b>	<b>Diagnostics and troubleshooting FC410.....</b>	<b>91</b>
10.1	Device status symbols .....	91
10.2	Fault codes and corrective actions .....	92
10.2.1	Diagnostics .....	92
10.2.2	Alarm messages.....	94
10.3	Operation troubleshooting.....	95
10.3.1	Updating the firmware .....	95
10.3.2	Troubleshooting sensor-related problems .....	97
10.3.2.1	Step 1: Inspecting the application.....	98
10.3.2.2	Step 2: Performing a zero point adjustment.....	98
10.3.2.3	Step 3: Calculating the measurement error .....	98
10.3.2.4	Step 4: Improving the application .....	99
10.4	Diagnosing with PDM.....	101
<b>11</b>	<b>Technical data.....</b>	<b>103</b>
11.1	Power .....	103
11.2	Performance .....	103
11.3	Construction.....	105
11.4	Sensor design .....	106
11.5	Basic electrical requirement for master system.....	107
11.6	Cables and cable entries.....	107
11.7	Operating conditions .....	108
11.8	Process variables FC410 .....	109
11.9	Approvals note.....	109
11.10	Certificates and approvals.....	109
11.11	SensorFlash .....	110
11.12	Modbus Communication Specification.....	110
11.13	PED .....	111
11.14	Pressure - temperature ratings.....	115
11.14.1	Stainless steel sensors .....	116
11.14.2	Pressure drop curves .....	118

<b>12</b>	<b>Dimension drawings</b> .....	<b>119</b>
12.1	Sensor dimensions .....	119
12.2	316L stainless steel - standard & hygienic .....	120
12.3	316L stainless steel - NAMUR .....	121
12.4	316L stainless steel - Hygienic versions .....	122
<b>A</b>	<b>Product documentation and support</b> .....	<b>123</b>
A.1	Product documentation .....	123
A.2	Technical support .....	124
<b>B</b>	<b>Technical reference</b> .....	<b>125</b>
B.1	Theory of operation .....	125
B.2	Sensor dimension dependent default settings .....	126
B.2.1	Mass flow .....	126
B.2.2	Volume flow .....	127
B.2.3	Standard volume flow .....	127
B.2.4	Fraction .....	128
B.2.5	Zero point adjustment .....	128
B.3	Exception handling .....	129
B.4	Float definition .....	129
<b>C</b>	<b>Modbus communication FC410</b> .....	<b>131</b>
C.1	Modbus addressing model .....	131
C.2	Modbus function codes .....	131
C.3	Changing Modbus communication settings .....	136
C.4	Modbus holding registers tables .....	137
	<b>Index</b> .....	<b>157</b>

# Introduction

These instructions contain all information required to commission and use the device. Read the instructions carefully prior to installation and commissioning. In order to use the device correctly, first review its principle of operation.

The instructions are aimed at persons mechanically installing the device, connecting it electronically, configuring the parameters and commissioning it, as well as service and maintenance engineers.

## 1.1 Document history

The following table shows major changes in the documentation compared to the previous edition.

The most important changes in the documentation when compared with the respective previous edition are given in the following table.

Edition	Note
06/2020	Second edition <ul style="list-style-type: none"> <li>• Chapter Technical data (Page 103) updated</li> <li>• Overall revision of chapters and contents</li> </ul>
06/2017	First edition

### NOTICE

#### Use in a domestic environment

This Class A Group 1 equipment is intended for use in industrial areas.

In a domestic environment this device may cause radio interference.

## 1.2 Product compatibility FC410

Manual edition	Remarks	Device revision	Compatibility of device integration package	
06/2020	Manual updated	Modbus RS-485 RTU FW: 4.00.00-xx HW: 3	SIMATIC PDM V8.2 Service Pack 1 or later	EDD: 2.00.01 or later
12/2019	Manual updated	Modbus RS-485 RTU FW: 4.00.00-xx HW: 3	SIMATIC PDM V8.2 Service Pack 1 or later	EDD: 2.00.01 or later


## 1.3 Items supplied

Manual edition	Remarks	Device revision	Compatibility of device integration package	
06/2017	New Hardware extending sensor sizes	Modbus RS-485 RTU FW: 4.00.00-xx HW: 3	SIMATIC PDM V8.2 Service Pack 1	EDD: 2.00.xx or later
05/2015	Update of Modbus holding registers: Modbus address 2215 to 2218 added.	Modbus RS-485 RTU FW: 2.03.03-01 HW: 2	SIMATIC PDM 8	EDD: 1.01.00-00
12/2013	First edition	Modbus RS-485 RTU FW: 2.03.02-01 HW: 2	SIMATIC PDM 6	EDD: 1.00.01-01

## 1.3 Items supplied

### With M12 plug connection


- SITRANS FC410/FCS400 flowmeter
- Micro SD card with production certificates
- DVD containing software, certificates and device manuals





## With sensor terminal housing

- SITRANS FC410/FCS400 flowmeter
- Packet of cable glands
- Micro SD card with production certificates
- DVD containing software, certificates and device manuals




---

### Note

#### Supplementary information

Supplementary product and production specific certificates are included on the SensorFlash® SD card.

---

### Note

Scope of delivery may vary, depending on version and add-ons. Make sure the scope of delivery and the information on the nameplate correspond to your order and the delivery note.

---

## 1.4 Checking the consignment

1. Check the packaging and the delivered items for visible damages.
2. Report any claims for damages immediately to the shipping company.
3. Retain damaged parts for clarification.
4. Check the scope of delivery by comparing your order to the shipping documents for correctness and completeness.

	<b>WARNING</b>
<b>Using a damaged or incomplete device</b>	
Risk of explosion in hazardous areas.	
<ul style="list-style-type: none"> <li>• Do not use damaged or incomplete devices.</li> </ul>	



## 1.5 Security information

Siemens provides products and solutions with industrial security functions that support the secure operation of plants, systems, machines, and networks.

1.6 Transportation and storage

In order to protect plants, systems, machines and networks against cyber threats, it is necessary to implement – and continuously maintain – a holistic, state-of-the-art industrial security concept. Siemens’ products and solutions form one element of such a concept.

Customers are responsible for preventing unauthorized access to their plants, systems, machines and networks. These systems, machines and components should only be connected to the enterprise network or the Internet if and only to the extent necessary and with appropriate security measures (firewalls and/or network segmentation) in place.

You can find more information on protective measures in the area of industrial security by visiting:  
<https://www.siemens.com/industrialsecurity>.

Siemens’ products and solutions undergo continuous development to make them more secure. Siemens strongly recommends performing product updates as soon as they are available and using only the latest product versions. Use of product versions that are no longer supported, and failure to apply latest updates may increase customer’s exposure to cyber threats.

To stay informed about product updates, subscribe to the Siemens Industrial Security RSS Feed under  
<https://www.siemens.com/industrialsecurity>.

## 1.6 Transportation and storage

To guarantee sufficient protection during transport and storage, observe the following:

- Keep the original packaging for subsequent transportation.
- Devices/replacement parts should be returned in their original packaging.
- If the original packaging is no longer available, ensure that all shipments are properly packaged to provide sufficient protection during transport. Siemens cannot assume liability for any costs associated with transportation damages.

<b>NOTICE</b>
<b>Insufficient protection during storage</b>
The packaging only provides limited protection against moisture and infiltration.
<ul style="list-style-type: none"><li>• Provide additional packaging as necessary.</li></ul>

Special conditions for storage and transportation of the device are listed in Technical data (Page 103).

The contents of this manual shall not become part of or modify any prior or existing agreement, commitment or legal relationship. The sales contract contains all obligations on the part of Siemens as well as the complete and solely applicable warranty conditions. Any statements regarding device versions described in the manual do not create new warranties or modify the existing warranty.


The content reflects the technical status at the time of publishing. Siemens reserves the right to make technical changes in the course of further development.

## Safety notes


### 2.1 Preconditions for use

This device left the factory in good working condition. In order to maintain this status and to ensure safe operation of the device, observe these instructions and all the specifications relevant to safety.

Observe the information and symbols on the device. Do not remove any information or symbols from the device. Always keep the information and symbols in a completely legible state.

Symbol	Explanation
	Consult operating instructions

Use the device only for flow measurement in accordance with this operating instructions and observe the technical data (Page 103).

 <b>WARNING</b>
<p><b>Improper device modifications</b></p> <p>Risk to personnel, system and environment can result from modifications to the device, particularly in hazardous areas.</p> <ul style="list-style-type: none"> <li>• Only carry out modifications that are described in the instructions for the device. Failure to observe this requirement cancels the manufacturer's warranty and the product approvals.</li> </ul>

### 2.2 Laws and directives

Observe the safety rules, provisions and laws applicable in your country during connection, assembly and operation. These include, for example:

- National Electrical Code (NEC - NFPA 70) (USA)
- Canadian Electrical Code (CEC) (Canada)

Further provisions for hazardous area applications are for example:

- IEC 60079-14 (international)
- EN 60079-14 (EU)

**US Installations only: Federal Communications Commission (FCC) rules**

---

**Note**

- This equipment has been tested and found to comply with the limits for a Class A digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference when the equipment is operated in a commercial environment.
  - This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the operating instructions, may cause harmful interference to radio communications. Operation of this equipment in a residential area is likely to cause harmful interference to radio communications, in which case the user will be required to correct the interference at his own expense.
- 

**2.2.1 Conformity with European directives**

The CE marking on the device symbolizes the conformity with the following European directives:

Electromagnetic compatibility EMC 2014/30/EU	Directive of the European Parliament and of the Council on the harmonisation of the laws of the Member States relating to electromagnetic compatibility
Low voltage directive LVD 2014/35/EU	Directive of the European Parliament and of the Council on the harmonisation of the laws of the Member States relating to the making available on the market of electrical equipment designed for use within certain voltage limits
Atmosphère explosive ATEX 2014/34/EU	Directive of the European Parliament and the Council on the harmonisation of the laws of the Member States relating to equipment and protective systems intended for use in potentially explosive atmospheres
Pressure equipment directive PED 2014/68/EU	Directive of the European Parliament and of the Council on the approximation of the laws of the Member States concerning pressure equipment
2011/65/EU RoHS	Directive of the European Parliament and the Council on the restriction of the use of certain hazardous substances in electrical and electronic equipment

The applicable directives can be found in the EC conformity declaration of the specific device.

---

**Note**

**CE declaration**

The CE declaration certificate is available on the SensorFlash SD card delivered with the device.

---

## 2.3 Requirements for special applications

Due to the large number of possible applications, each detail of the described device versions for each possible scenario during commissioning, operation, maintenance or operation in systems cannot be considered in the instructions. If you need additional information not covered by these instructions, contact your local Siemens office or company representative.

---

### Note

#### Operation under special ambient conditions

We highly recommend that you contact your Siemens representative or our application department before you operate the device under special ambient conditions as can be encountered in nuclear power plants or when the device is used for research and development purposes.

---

## 2.4 Use in hazardous areas

### Qualified personnel for hazardous area applications

Persons who install, connect, commission, operate, and service the device in a hazardous area must have the following specific qualifications:


- They are authorized, trained or instructed in operating and maintaining devices and systems according to the safety regulations for electrical circuits, high pressures, aggressive, and hazardous media.
- They are authorized, trained, or instructed in carrying out work on electrical circuits for hazardous systems.
- They are trained or instructed in maintenance and use of appropriate safety equipment according to the pertinent safety regulations.

 <b>WARNING</b>
--


<b>Use in hazardous area</b>
------------------------------

Risk of explosion.
--------------------

- |   |
|---|
| <ul style="list-style-type: none"> <li>• Only use equipment that is approved for use in the intended hazardous area and labeled accordingly.</li> <li>• Do not use devices that have been operated outside the conditions specified for hazardous areas. If you have used the device outside the conditions for hazardous areas, make all Ex markings unrecognizable on the nameplate.</li> </ul> |
|---|

 <b>WARNING</b>
<b>Loss of safety of device with type of protection "Intrinsic safety Ex i"</b>
If the device or its components have already been operated in non-intrinsically safe circuits or the electrical specifications have not been observed, the safety of the device is no longer ensured for use in hazardous areas. There is a risk of explosion.
<ul style="list-style-type: none"><li>• Connect the device with type of protection "Intrinsic safety" solely to an intrinsically safe circuit.</li><li>• Observe the specifications for the electrical data on the certificate and/or in Technical data (Page 103).</li></ul>

### 2.4.1 Installation in hazardous areas

 <b>WARNING</b>
<b>Equipment used in hazardous areas</b>
Equipment used in hazardous areas must be Ex-approved for the region of installation and marked accordingly. It is required that the special conditions for safe use provided in the manual and in the Ex certificate are followed!

### Hazardous area approvals

The device is approved for use in hazardous areas and has the approvals listed below. Special conditions for safe installation and operation specified by each approval authority are included in the relevant certificate.

### See also

Certificates and approvals (Page 109)

### Special conditions for safe use

In general, it is required that:

- EN/IEC 60079-14 is considered for installation in hazardous areas.
- Appropriate cable connectors are used.
- Sensor is connected to the potential equalization throughout the hazardous area.
- The device is not opened when energized and when an explosive gas or dust atmosphere may be present.

Further information and instructions including approval-specific special conditions for safe use in Ex applications can be found in the certificates on the documentation disk and at the product

web page of SITRANS FCS400 ([www.siemens.com/FCS400](http://www.siemens.com/FCS400)) or SITRANS FC410 ([www.siemens.com/FC410](http://www.siemens.com/FC410)).

**⚠ WARNING**

**Substitution of components**

Substitution of components may impair Intrinsic Safety.

**⚠ WARNING**

**Laying of cables**

Risk of explosion in hazardous areas.

Cable for use in hazardous areas must satisfy the requirements for having a proof voltage of at least 500 V AC applied between the conductor/ground, conductor/shield and shield/ground.

Connect the devices that are operated in hazardous areas as per the stipulations applicable in the country of operation.

**⚠ WARNING**

**Field wiring installation**

Ensure that the national requirements of the country in which the devices are installed are met.

## 2.4.2 Maximum temperature specifications for Ex use

The maximum dust layer shall be no greater than 5 mm (T5 85°C).

The apparatus housing shall be connected to the potential equalising conductor in the hazardous area.

The maximum allowable process fluid temperatures with respect to the marked temperature class and maximum surface temperature for the device in the following maximum ambient temperatures are:

Ta (°C)	Maximum Process Temperature per Temperature Class (°C)			
	T6	T5	T4	T3
60	70	70	70	70
55	85	100	100	100
50	85	100	130	130
45	85	100	135	160
40	85	100	135	190
35	85	100	135	200
30	85	100	135	200

2.4 Use in hazardous areas

The maximum allowable process fluid temperatures with respect to maximum surface temperatures for hazardous dusts for the device when used with hazardous dusts in the following maximum ambient temperatures are:

Ta (°C)	Tprocess max (°C)	
	Applications with up to 500 mm dust or isolation	Applications with up to 5 mm dust or isolation
60	-40	70
55	-10	100
50	20	130
45	50	160
40	80	190
35	110	200
30	140	200

- If Tprocess ≤ 85°C, maximum surface temperature = 85°C
- If Tprocess > 85°C, maximum surface temperature = process temperature

The maximum pressure associated with the process medium in the internal pipes shall be limited to 100 bar.

The equipment internal circuits at the 4-Pin Connection – A, B, 0 and 15 V or Connector X700 (Pin 1 = 15 V, Pin 2 = 0 V, Pin 3 = A and Pin 4 = B) are not capable of withstanding a 500 V r.m.s. a.c. test to earth as required by clause 6.3.13 of IEC 60079-11:2011. This shall be taken into account in any equipment installation.

When the equipment is installed as 'Ex d', the connector (1/2" NPT or M20) shall be replaced with a suitably certified Ex d cable gland or Ex d Conduit Sealing Device and the voltage of the equipment shall not exceed 60 V d.c.

If the equipment is installed as flameproof only, it shall not subsequently be installed as intrinsically safe unless it can be verified that there has been no damage to the safety components within the intrinsically safe circuit on which safety depends by, for example, an over-voltage at the supply terminals. The safety components on which intrinsic safety depends have been assessed up to an input voltage of 60 V d.c.

**Intrinsically safe installations only:**

A temporary connection of the SITRANS to an uncertified programming or data download device is permitted, when the SITRANS is located in the non-hazardous area (typically prior to installation). Alternatively, such a connection may be made when the SITRANS remains in the hazardous area, but the area is declared 'gas-free'. The uncertified programming or data download device shall be suitably-approved as a SELV supply to IEC 60950-1, IEC 61010-1 or an equivalent standard, with a maximum output voltage of 60 V. The input terminals of the SITRANS have a maximum voltage Um = 60V.

If the equipment is installed as flameproof only, it shall not subsequently be installed as intrinsically safe unless it can be verified that there has been no damage to the safety components within the intrinsically safe circuit on which safety depends by, for example, a voltage above 60 V at the supply terminals.



If the Sensor is mounted remotely from the Adapter, the wiring shall be given protection against torsional and tensile stresses (e.g. by the use of conduit).

---

**Note**

Only installation as Ex ia can be used for installation in Zone 20.

---

2.4 Use in hazardous areas

## Description

SITRANS Coriolis flowmeter systems consist of a transmitter and a sensor. The following table lists the available combinations of transmitters and sensors.

Transmitter	Sensor type
FCT010	FCS400 DN 15 to DN 50 (0.5" to 2")

### 3.1 System integration

The FC410 flowmeter functions as a Modbus RTU slave with standard Modbus commands implemented. Setup parameters, process values, diagnostics, and status information are mapped as Modbus registers.

The device can be connected point-to-point or in a multidrop network in non-hazardous or hazardous areas. It can be connected to different hosts for example a PLC system or a PC used as service tool or configuration tool.

---

#### Note

##### Multidrop installations in hazardous areas

Multidrop installations in hazardous areas require flameproof conduit seals for each device.

---

The FCS400 7ME4617-... is preconfigured for integration with the SITRANS FCT070.

### 3.2 Modbus RTU technology FC410

Modbus RTU is an open serial protocol based on master/slave architecture. The protocol interconnects field equipment such as sensors, actuators, and controllers and is widely used in both process and manufacturing automation. The fieldbus environment is the base level group of digital networks in the hierarchy of plant networks.

#### Features

The SITRANS F Modbus RTU communication complies with the Modbus Serial Line Protocol. Among other things this implies a master / slave protocol at level 2 of the OSI model. A node (the master) issues explicit commands to one of the slave nodes and processes responses. Slave nodes will not transmit data without a request from the master node, and do not communicate with other slaves.

Modbus is a mono master system, only one master can be connected at a time.

### Unicast communication mode

In unicast mode (master/slave mode) the master sends a request to a specific slave device and waits a specified time for a response.




Figure 3-1 Unicast Mode

### Modbus Frame

The Modbus frame is shown below and is valid for both requests and responses.

Table 3-1 Modbus Frame

SLAVE ADDRESS	FUNCTION MODE	DATA	CRC
1 Byte	1 Byte	0 to 252 Bytes	2 Bytes


### References

For further information, please refer to the following specification and guidelines available at the Modbus Organization (<http://www.modbus.org/>) website

1. Serial Line Specification & Implementation guide
2. Application Protocol Specification

## 3.3 Design

The SITRANS FC410 flowmeter uses the Coriolis principle to measure flow. The device is a one channel flowmeter with Modbus RTU RS-485 output.



## Flowmeter design

All primary process measurement of mass flow, volume flow, density and process temperature are done in the SITRANS FCT010 transmitter.

The SITRANS FCS400 sensor comprises two parallel bent tubes welded directly to the process connections at each end via a manifold.

The sensors are available in AISI 316L stainless steel. The sensor enclosure is made of AISI 304 stainless steel which has a pressure rating related to size.

The sensor enclosure can be equipped with a pressure guard or flushed with dry inert gas at the threaded ports for non-hazardous applications only.

---


### Note

Ex certification requires that the threaded ports always remain closed.

---

The SITRANS FCT010 transmitter is available in an aluminium enclosure with an ingress protection grade of IP67/NEMA 4X. It has a 4-wire M12 cable or terminated cable connection for communication and power supply.

## Flowmeter overview



- ① Transmitter
- ② Lid-lock
- ③ Cable feed-through (M12 socket or cable gland)
- ④ Plug and threaded port for example for pressure guard
- ⑤ Sensor enclosure
- ⑥ Process connections

## See also

Pressure - temperature ratings (Page 115)

## 3.4 Nameplate layout

Each part of the FC410/FCS400 Coriolis flowmeter has 3 nameplate types showing the following information:

- product identification
- product specifications
- certificates and approvals

---


### Note

#### Identification

Identify your device by comparing your ordering data with the information on the product and specification nameplates.


---

### FC410: Nameplate with general information



- |   |               |   |
|---|---------------|---|
| ① | SITRANS FC410 | Product name                                      |
| ② | FW            | Firmware version                                  |
| ③ | HW            | Hardware version                                  |
| ④ | Manufacturer  | Manufacturer name and location                    |
| ⑤ | Country       | Manufacturing country                             |
| ⑥ | Address range | Modbus device address range                       |
| ⑦ | Communication | Communication: Modbus Master/Slave RTU technology |
| ⑧ | Power Supply  | Power supply                                      |

## FCS400 sensor: Nameplate with general information



- |   |                              |  |
|---|------------------------------|--|
| ① | SITRANS FCS400 <sup>1)</sup> | Product name   |
| ② | Serial no.                   | Sensor serial number                                   |
| ③ | Sen. RS                      | Mechanical sensor version number                       |
| ④ | Size DN                      | Size   |
| ⑤ | Manufacturer                 | Manufacturer name and location                         |
| ⑥ | Country                      | Manufacturing country                                  |
| ⑦ | Sensor order no.             | Sensor replacement order number                        |
| ⑧ | System order no.             | Flowmeter system order number (transmitter and sensor) |

<sup>1)</sup> With remote versions, the transmitter is identified as 'SITRANS FCT070' and the sensor as 'SITRANS FCS400'.

## Flowmeter serial number construction

The flowmeter serial number is constructed as follows:

PPYMDDxxxxxx

where

PP = Production factory (Siemens S.A.S. Haguenau: N1)

Y = Production year (for encryption, see below)

M = Production month (for encryption, see below)

DD = Production day (for encryption, see below)

xxxxxx = Sequential number

Encryption:

### Calendar year (Y)

1950, 1970, 1990, 2010

1951, 1971, 1991, 2011

1952, 1972, 1992, 2012

1953, 1973, 1993, 2013

1954, 1974, 1994, 2014

1955, 1975, 1995, 2015

1956, 1976, 1996, 2016

1957, 1977, 1997, 2017

1958, 1978, 1998, 2018

1959, 1979, 1999, 2019

### Code

A

B

C

D

E

F

H (G)

J

K

L

## Description


---

### 3.4 Nameplate layout

1960, 1980, 2000, 2020	M
1961, 1981, 2001, 2021	N
1962, 1982, 2002, 2022	P
1963, 1983, 2003, 2023	R
1964, 1984, 2004, 2024	S
1965, 1985, 2005, 2025	T
1966, 1986, 2006, 2026	U
1967, 1987, 2007, 2027	V
1968, 1988, 2008, 2028	W
1969, 1989, 2009, 2029	X
<b>Month (M)</b>	<b>Code</b>
January	1
February	2
March	3
April	4
May	5
June	6
July	7
August	8
September	9
October	O
November	N
December	D
<b>Day (DD)</b>	<b>Code</b>
Day 1 to 31	01 to 31 (corresponding to the actual date)



## FCS400 sensor: Nameplate with specific information




<p>① EX approvals</p> <p>II: Group II</p> <p>1/2: category 1/2 (On Zone 0)</p> <p>G: for gas</p> <p>Ex: for use in explosive atmosphere</p> <p>db: type of protection flame proof</p> <p>IIC: Gas group</p> <p>T4: temperature class</p> <p>Ga/ Protection level</p> <p>Gb:</p>	<p>Ex approval specifications</p>
<p>② ⚠</p>	<p>Consult the operating instructions</p>
<p>③ Year of manufacture</p>	<p>Manufacturing year</p> <p>More detailed manufacturing date information is given in the serial number found on the identification nameplate</p>
<p>④ Cal. factor</p>	<p>Calibration factor</p>
<p>⑤ qm (min)</p>	<p>Minimum flow with water at 20 °C (68 °F)</p>
<p>⑥ qm (nom)</p>	<p>Nominal flow with water at 20 °C (68 °F)</p>
<p>⑦ IS</p>	<p>Power supply</p>
<p>⑧ Enclosure</p>	<p>Degree of protection</p>
<p>⑨ Tamb.</p>	<p>Ambient temperature range</p>
<p>⑩ Accuracy</p>	<p>Accuracy for mass flow and density</p>
<p>⑪ 2813</p>	<p>Notified Body ID (ATEX, example)</p>
<p>⑫ CE</p>	<p>CE mark</p>

**Note****Approval identifications**

Approval certificates and notified body identifications are available for download at [siemens.com](https://www.siemens.com)

### FCS400 sensor: Nameplate with approval information




#### Note

##### Logos and warnings

Logos and warnings are only shown on the product where applicable. The combination shown in the example above is relevant for a hygienic sensor.


The Australian C-tick mark is mandatory on all products.

### Sensor EHEDG and 3A nameplate



These nameplates appear on all Hygienic sensors 7ME461.-.2...-.....

### QR code



With the use of a smart phone, the QR code provides a direct link to

- the product support portal, which includes access to the "How to Install" YouTube video
- the product and production-specific documentation maintained in the production database.

## 3.5 Features

- The flowmeter can be used as Modbus slave in stand-alone or parallel operation on Modbus or third party automation systems
- Compact sensor design
- NAMUR conforming sensor built-in lengths (on request)
- High immunity against process noise
- Fast response to step changes in flow
- High update rate (100 Hz) on all process values
- Measurement of:
  - Mass flow
  - Volume flow
  - Density
  - Medium temperature
  - Frame temperature
- Independent low flow cut-off settings for mass flow and volume flow
- Automatic zero point adjustment (initiated by host system)
- Process noise damping using digital signal processing (DSP).
- One totalizer for summation of mass flow. The totalizer is reset on loss of power.
- Empty tube monitoring
- Simulation of process values:
  - Mass flow
  - Volume flow
  - Density
  - Medium temperature
  - Frame temperature
- Troubleshooting and sensor checking
- Use in hazardous areas according to specification
- Intelligent filtering system for aerated flow
- Unit selection of process values and totalizer

## 3.6 Applications

The main applications of the Coriolis flowmeter can be found in all industries, such as:

- Chemical & Pharma: detergents, bulk chemicals, acids, alkalis, pharmaceuticals
- Food & Beverage: dairy products, beer, wine, soft drinks, fruit juices and pulps, bottling, CO<sub>2</sub> dosing, CIP/SIP-liquids, mixture recipe control

### 3.7 Approvals

- Automotive: fuel injection nozzle & pump testing, filling of AC units, engine consumption, paint robots
- Oil & Gas: filling of gas bottles, furnace control, test separators, bore-hole plasticizer dosing, water-cut metering
- Water & Waste Water: dosing of chemicals for water treatment

## 3.7 Approvals

---

### Note

For further details see Certificates and approvals (Page 109).

---

The device is available with approvals for general purpose and for hazardous areas. In all cases, check the nameplate on your device, and confirm the approval rating.

# Installing/mounting




---

## Note

The weight of the sensors > DN25 is exceeding 18 kg. It takes two persons to safely lift this part or unit.

---

## 4.1 Basic safety notes

### CAUTION

#### Hot surfaces resulting from hot process media

Risk of burns resulting from surface temperatures above 65 °C (149 °F).

- Take appropriate protective measures, for example contact protection.
- Make sure that protective measures do not cause the maximum permissible ambient temperature to be exceeded. Refer to the information in Technical data (Page 103).

### WARNING

#### Wetted parts unsuitable for the process media

Risk of injury or damage to device.

Hot, toxic and corrosive media could be released if the wetted parts are unsuitable for the process medium.

- Ensure that the material of the device parts wetted by the process medium is suitable for the medium. Refer to the information in Technical data (Page 103).


---


## Note


### Material compatibility


Siemens can provide you with support concerning selection of sensor components wetted by process media. However, you are responsible for the selection of components. Siemens accepts no liability for faults or failures resulting from incompatible materials.


---


 <b>WARNING</b>
<b>Unsuitable connecting parts</b>
Risk of injury or poisoning.
In case of improper mounting, hot, toxic, and corrosive process media could be released at the connections.
<ul style="list-style-type: none"><li>• Ensure that connecting parts (such as flange gaskets and bolts) are suitable for connection and process media.</li></ul>


 <b>WARNING</b>
<b>Exceeded maximum permissible operating pressure</b>
Risk of injury or poisoning.
The maximum permissible operating pressure depends on the device version, pressure limit and temperature rating. The device can be damaged if the operating pressure is exceeded. Hot, toxic and corrosive process media could be released.
Ensure that maximum permissible operating pressure of the device is not exceeded. Refer to the information on the nameplate and/or in Technical data (Page 103).

 <b>WARNING</b>
<b>Unprotected cable ends</b>
Risk of explosion through unprotected cable ends in hazardous areas.
<ul style="list-style-type: none"><li>• Protect unused cable ends in accordance with IEC/EN 60079-14.</li></ul>

 <b>WARNING</b>
<b>Incorrect mounting at Zone 0</b>
Risk of explosion in hazardous areas.
<ul style="list-style-type: none"><li>• Ensure sufficient tightness at the process connection.</li><li>• Observe the standard IEC/EN 60079-14.</li></ul>

 <b>WARNING</b>
<b>Loss of explosion protection</b>
Risk of explosion in hazardous areas if the device is open or not properly closed.
<ul style="list-style-type: none"><li>• Close the device as described in Installing/mounting (Page 29).</li></ul>

 <b>CAUTION</b>
<b>External stresses and loads</b> Damage to device by severe external stresses and loads (e.g. thermal expansion or pipe tension). Process media can be released. <ul style="list-style-type: none"><li>• Prevent severe external stresses and loads from acting on the device.</li></ul>

 <b>DANGER</b>
<b>Pressure applications</b> Danger to personnel, system and environment will result from improper disassembly. <ul style="list-style-type: none"><li>• Never attempt to loosen, remove, or disassemble process connection while vessel contents are under pressure.</li></ul>


#### 4.1.1 Installation location requirements

<b>NOTICE</b>
<b>Aggressive atmospheres</b> Damage to device through penetration of aggressive vapors. <ul style="list-style-type: none"><li>• Ensure that the device is suitable for the application.</li></ul>

<b>NOTICE</b>
<b>Direct sunlight</b> Damage to device. The device can overheat or materials become brittle due to UV exposure. <ul style="list-style-type: none"><li>• Protect the device from direct sunlight.</li><li>• Make sure that the maximum permissible ambient temperature is not exceeded. Refer to the information in Operating conditions (Page 108).</li></ul>


### 4.1.2 Proper mounting

<b>NOTICE</b>
<b>Incorrect mounting</b> The device can be damaged, destroyed, or its functionality impaired through improper mounting. <ul style="list-style-type: none"><li>• Before installing ensure there is no visible damage to the device.</li><li>• Make sure that process connectors are clean, and suitable gaskets and glands are used.</li><li>• Mount the device using suitable tools. Refer to the information in Construction (Page 105).</li></ul>

 <b>WARNING</b>
<b>High pressure hazard</b> In applications with working pressures/media that can be dangerous to people, surroundings, equipment or others in case of pipe fracture, we recommend that special precautions such as special placement, shielding or installation of a pressure guard or a safety valve are taken when the flowmeter is mounted.

## 4.2 Installation instructions

### 4.2.1 Sensor installation

 <b>CAUTION</b>
<b>Electromagnetic fields</b> Do not install the flowmeter in the vicinity of strong electromagnetic fields, for example near motors, variable frequency drives, transformers etc.

#### Upstream / downstream

- No pipe run requirements, that is straight inlet/outlet sections, are necessary.
- Avoid long drop lines downstream from the sensor to prevent process media separation causing air / vapor bubbles in the tube (min. back pressure: 0.2 bar).
- Avoid installing the flowmeter immediately upstream of a free discharge in a drop line.



## Location in the system

The optimum location in the system depends on the application:

- Liquid applications  
Gas or vapor bubbles in the fluid may result in erroneous measurements, particularly in the density measurement.
  - Do not install the flowmeter at the highest point in the system, where bubbles will be trapped.
  - Install the flowmeter in low pipeline sections, at the bottom of a U-section in the pipeline.




Figure 4-1 Liquid applications, wrong location with trapped air/gas

- Gas applications  
Vapor condensation or oil traces in the gas may result in erroneous measurements.
  - Do not install the flowmeter at the lowest point of the system.
  - Install a filter.




Figure 4-2 Gas applications, wrong location with trapped oil

## Flow direction

The calibrated flow direction is indicated by the arrow on the sensor. Flow in this direction will be indicated as positive by default. The sensitivity and the accuracy of the sensor do not change with reverse flow.

The indicated flow direction (positive/negative) is configurable.

<b>! CAUTION</b>
<b>Accurate measurement</b>
The sensor must always be completely filled with process media in order to measure accurately.

<b>NOTICE</b>
<b>Orienting the sensor</b>
To avoid water or moist ingress, transmitters should be oriented with cable entrances aiming downwards.

### Orienting the sensor

The sensor operates in any orientation. The optimal orientation depends on the process fluid and the process conditions. Siemens recommends orienting the sensor in one of the following ways:

1. Vertical installation with an upwards flow (self-draining)




Figure 4-3 Vertical orientation, upwards flow

2. Horizontal installation, tubes down (recommended for liquid applications)




Figure 4-4 Horizontal orientation, tubes down

3. Horizontal installation, tubes up (recommended for gas applications)




Figure 4-5 Horizontal orientation; tubes up

---


#### Note

##### Hygienic applications

In 3A and EHEDG certified hygienic applications the flowmeter must be installed vertically as shown in 1 above.

---

Installation in a drop line is only recommended if a pipeline reduction or orifice with a smaller cross-section can be installed to create back-pressure and prevent the sensor from being partially drained while measuring.



- ① Back pressure orifice
- ② On / off valve

Figure 4-6 Installation in drop line

#### 4.2.1.1 Mounting the sensor

- Install the sensor in well-supported pipelines in order to support the weight of the flowmeter.
- Center the connecting pipelines axially in order to assure a stress-free installation. The flowmeter must not be used to bring the rest of the pipework into line. Make sure the pipework is aligned correctly before inserting the flow sensor.
- Install two supports or hangers symmetrically and stress-free on the pipeline closely to the process connections.

---

#### Note

#### Handling

Lift the flowmeter by the sensor body. Do not lift the flowmeter by the housing.

---

#### Avoid vibrations

- Make sure that any valves or pumps upstream of the sensor do not cavitate and do not send vibrations into the sensor.
- Decouple vibrating pipeline from the flow sensor using flexible tube or couplings.




Figure 4-7 Non-flexible pipes not recommended in vibrating environment




Figure 4-8 Flexible pipes recommended in vibrating environment

### Avoid cross talk

When operating more than one flowmeter in one or multiple interconnected pipelines there is a risk of cross talk.

Prevent cross talk in one of the following ways:

- Mount sensors on separate frames
- Decouple the pipeline using flexible tubes or couplings




Figure 4-9 High risk of cross talk when using non-flexible pipes




Figure 4-10 Low risk of cross talk when using flexible pipes and separate frames

#### 4.2.1.2 Hydrostatic testing

The flowmeter is pressure-tested before delivery to 1.5 times the rated working pressure of the sensor.

- In the case of process connections pressure-rated less than 100 bar, the connection is the limiting component.
- In the case of process connections pressure-rated above 100 bar (stainless steel sensors) or above 160 bar (Hastelloy sensors), the sensor is the limiting component.

In all cases the maximum allowed hydrostatic test pressure (MATP) of the flowmeter is 1.5 times the marked MAWP (PS) at 20 °C.

Pressure test of a completed flow system with piping and other components can be done at pressures no higher than 1.5 times the marked MAWP (PS) at 20 °C of the lowest rated system component.

#### 4.2.1.3 Installing with insulation

Insulation is added to pipes and equipment for two reasons:

- To protect personnel from exposure to hot or cold surfaces, thereby preventing burns and other injuries
- To prevent heat loss into or out of the process, thereby preserving the process temperature and process medium conditions.

In both cases, insulation can have the unexpected effect of shrouding other attached components not intended or designed for the process temperatures. When installing an FCS400 sensor with insulation, observe the following rules:

- Do not cover any part of the transmitter pedestal. The pedestal is designed to separate the process temperature from the ambient around the DSL or transmitter electronics housing.
- Allow free movement of air around the electronics housing to allow temperature equalisation to occur at all times.

#### 4.2.1.4 Pressure guard

The sensor enclosure is supplied with two G $\frac{1}{2}$ " (parallel thread) purge ports. These ports can for example be used for a pressure guard, which can be connected to an automatic shut off valve to stop the flow in case of sensor pipe fracture. Because sensor enclosure is rated Ex[d] for hazardous applications, the purge ports may not be removed from Ex version sensors.

The AISI 304 / EN 1.4301 exterior enclosure is rated to approximately 20 bar static pressure to contain spilt process media in the event of a tube break. However it is not intended to contain high pressure or corrosive fluids and precautions must be taken in applications where vibrating tube failure is probable and may cause damage.

#### Pressure guard selection

Siemens does not supply the components of the pressure guard solution because the arrangement and components are closely related to individual safety and protection practices in each place.

The selection of pressure guard solution is the responsibility of the user, however Siemens recommends the following forms of pressure guard:

- A pressure switch screwed directly or piped into one of the purge ports and connected to an automatic shut-off valve will disable pressurized supply to the meter.
- A relief valve or bursting disc screwed directly or piped to one of the purge ports to carry any spilt fluid to drain after opening. Ensure the drain flow is safely contained away from personnel and other plant or equipment.

The pressure switch and relief valve set point should be 2-3 bar gauge. The pressure switch should be rated to withstand the full process pressure and temperature for a short time without rupture.

### Mounting of pressure guard

All sensors are filled with argon to avoid condensation. Avoid ingress of moisture, liquids or particles into the sensor; it may influence the measurement and in worst case inhibit the measuring function.

Install a pressure guard as follows:

1. Place the sensor in a dry, clean place and leave it to acclimatize.
2. Orient the sensor with the purge ports uppermost.
3. Carefully remove the plug and mount the pressure guard.
4. Replace the soft metal sealing rings with new ones to obtain proper hemetic sealing.
5. Make sure that the pressure guard does NOT touch any of the parts inside the sensor.
6. Check that the pressure guard has been correctly mounted and thoroughly tightened (torque: 80 Nm).

## 4.3 Disassembly

** WARNING****Incorrect disassembly**

The following risks may result from incorrect disassembly:

- Injury through electric shock
- Risk through emerging media when connected to the process
- Risk of explosion in hazardous area


In order to disassemble correctly, observe the following:


- Before starting work, make sure that you have switched off all physical variables such as pressure, temperature, electricity etc. or that they have a harmless value.
- If the device contains hazardous media, it must be emptied prior to disassembly. Make sure that no environmentally hazardous media are released.
- Secure the remaining connections so that no damage can result if the process is started unintentionally.






## 5.1 Basic safety notes


 <b>WARNING</b>
<b>Unsuitable cables, cable glands and/or plugs</b> Risk of explosion in hazardous areas. <ul style="list-style-type: none"><li>• Use only cable glands/plugs that comply with the requirements for the relevant type of protection.</li><li>• Tighten the cable glands in accordance with the torques specified in Technical data (Page 103).</li><li>• Close unused cable inlets for the electrical connections.</li><li>• When replacing cable glands, only use cable glands of the same type.</li><li>• After installation, check that the cables are seated firmly.</li></ul>


 <b>WARNING</b>
<b>Incorrect conduit system</b> Risk of explosion in hazardous areas as result of open cable inlet or incorrect conduit system. <ul style="list-style-type: none"><li>• In the case of a conduit system, mount a spark barrier at a defined distance from the device input. Observe national regulations and the requirements stated in the relevant approvals.</li></ul>


<b>NOTICE</b>
<b>Condensation in the device</b> Damage to device through formation of condensation if the temperature difference between transportation or storage and the mounting location exceeds 20 °C (36 °F). <ul style="list-style-type: none"><li>• Before taking the device into operation, let the device adapt for several hours in the new environment.</li></ul>


<b>NOTICE</b>
<b>Ambient temperature too high</b> Damage to cable sheath. <ul style="list-style-type: none"><li>• At an ambient temperature <math>\geq 60</math> °C (140 °F), use heat-resistant cables suitable for an ambient temperature at least 20 °C (36 °F) higher.</li></ul>

 <b>WARNING</b>
<b>Improper power supply</b>
Risk of explosion in hazardous areas as result of incorrect power supply.
<ul style="list-style-type: none"><li>• Connect the device in accordance with the specified power supply and signal circuits. The relevant specifications can be found in the certificates, in Technical data (Page 103) or on the nameplate.</li></ul>

 <b>WARNING</b>
<b>Lack of equipotential bonding</b>
Risk of explosion through compensating currents or ignition currents through lack of equipotential bonding.
<ul style="list-style-type: none"><li>• Ensure that the device is potentially equalized.</li></ul>
<b>Exception:</b> It may be permissible to omit connection of the equipotential bonding for devices with type of protection "Intrinsic safety Ex i".

 <b>WARNING</b>
<b>Unprotected cable ends</b>
Risk of explosion through unprotected cable ends in hazardous areas.
<ul style="list-style-type: none"><li>• Protect unused cable ends in accordance with IEC/EN 60079-14.</li></ul>

 <b>WARNING</b>
<b>Improper laying of shielded cables</b>
Risk of explosion through compensating currents between hazardous area and the non-hazardous area.
<ul style="list-style-type: none"><li>• Shielded cables that cross into hazardous areas should be grounded only at one end.</li><li>• If grounding is required at both ends, use an equipotential bonding conductor.</li></ul>

 <b>WARNING</b>
<b>Incorrect selection of type of protection</b>
Risk of explosion in areas subject to explosion hazard.
This device is approved for several types of protection.
<ol style="list-style-type: none"><li>1. Decide in favor of one type of protection.</li><li>2. Connect the device in accordance with the selected type of protection.</li><li>3. In order to avoid incorrect use at a later point, make the types of protection that are not used permanently unrecognizable on the nameplate.</li></ol>

---

**Note****Electromagnetic compatibility (EMC)**

You can use this device in industrial environments, households and small businesses.

For metal enclosures there is an increased electromagnetic compatibility compared to high-frequency radiation. This protection can be increased by grounding the enclosure.

---

**See also**

Connecting (Page 41)

---

**Note****Improvement of interference immunity**

- Lay signal cables separate from cables with voltages > 60 V.
  - Use cables with twisted wires.
  - Keep device and cables at a distance from strong electromagnetic fields.
  - Take account of the conditions for communication specified in the Technical data (Page 103).
  - Use shielded cables to guarantee the full specification according to HART/PA/FF/Modbus/EIA-485/Profibus DP.
- 

**Use in hazardous areas**

Before accessing the sensor terminal compartment and application terminal space check that:

- A safe access permission certificate has been issued by plant operations management
- The flow transmitter may not be opened if energized
- All connection leads are potential free

 **WARNING****Hazardous areas**

Observe the type examination certificates or the test certifications applicable in your country if you use transmitters as category 1/2 equipment.


 **WARNING****Commissioning**

Only apply power and commission the device after the device has been properly connected and, if required, closed.


## 5.2 Wiring

### Hazardous area applications

Special requirements apply to the location and interconnection of sensor and transmitter. See Use in hazardous areas (Page 13).

 <b>WARNING</b>
<b>Transmitter enclosure</b> Before opening the terminal box check that: <ul style="list-style-type: none"><li>• No explosion hazard exists</li><li>• All connection leads are potential free</li></ul>

## 5.3 Connecting FC410/FCS400

 <b>WARNING</b>
<b>Improper handling</b> The sensor connected to this device can be operated with high pressure and corrosive media. Therefore improper handling of the device can lead to serious injuries and/or considerable material damage.

The device is optionally provided with a preformed cable terminated with M12 style stainless steel weather-proof plugs.

The cable shield is physically and electrically terminated within the body of the plug.

Take care when handling the cable and passing it through cable ducting. The plug is not subjected to excessive tension (pulling) as the internal connections may be disengaged.

---

#### Note

Never pull the cable by the plug.

---

1. Connect the device using the supplied 4-wire cable with M12 plug.
- 

#### Note

##### Grounding

The sensor cable screen is electrically connected to chassis, only when the M12 plug is correctly tightened.

---

Terminal number	Description	Wire color (Siemens cable)
1	15 V	Orange
2	0 V	Yellow
3	RS-485 / B	White
4	RS-485 / A	Blue

- Only use cables with at least the same degree of protection as the sensor to install the sensor. It is recommended to use cables supplied by Siemens.
- Siemens supplied cables can be ordered with M12 plug on one or both ends or without plug.
- To guarantee the IP67 degree of protection, ensure that both ends of the cables are given equivalent protection from ingress of moisture.
- For further information on Siemens-supplied cables, see Technical data (Page 103).

**! WARNING**

**Cable requirements**

Cables must be suitable for the temperature (at least 70 °C) and be flammability-rated to at least V-2.

**A: Prepare the cable by stripping it at both ends.**




Figure 5-1 Cable end

**B: Connect wires within the sensor terminal compartment**

1. Remove the lock screw and remove the lid.
2. Undo the flexible strap.
3. Disconnect the sensor connection (white plug) from the electronic.
4. Loosen the mounting screw using a TX10 Torx driver and remove the electronic from the housing.
5. Remove the cap and the ferrule from the cable gland and slide onto the cable.
6. Push the cable through the open gland and anchor the cable shield and the wires with the clamp bar.
7. Remove the terminal block from the electronic.

8. Connect the wires to the terminals according to the list below.

Terminal number	Description	Wire color (Siemens cable)
1	15 V	Orange
2	0 V	Yellow
3	RS-485 / B	White
4	RS-485 / A	Blue






Figure 5-2 Sensor terminal compartment



9. Reinstall the electronic including the mounting screw.

10. Connect the sensor connection and the sensor cable.

11. Restore the flexible strap around all wires.



12. Assemble and tighten the cable gland.
13. Remove the O-ring from lid.
14. Reinstall the lid and screw in until the mechanical stop. Wind back the lid by one turn.
15. Mount the O-ring by pulling it over the lid and tighten the lid until you feel friction from the O-ring on both sides. Wind the lid by one quarter of a turn to seal on the O-ring.
16. Reinstall and tighten the lid lock screw.

** WARNING****Unprotected cable ends**

Risk of explosion through unprotected cable ends in hazardous areas.

- Protect unused cable ends in accordance with IEC/EN 60079-14.

### 5.3.1 Setting the EOL termination DIP switches

It is important to terminate the Modbus RS-485 line correctly at the start and end of the bus segment. Impedance mismatch results in reflections on the line which can cause faulty communication transmission.


If the device is at the end of the bus segment, it is recommended to terminate the device. The following table shows the relation between the DIP switch settings and the permissible communication interface set-ups.

---

**Note****End Of Line (EOL) termination**

The FCT010 EOL termination DIP switch is default set to EOL non-active. If the installation requires active termination resistors, the DIP switches should be set to the EOL Active state.


---

** CAUTION****Hazardous areas**

Only change the DIP switches in hazardous areas when the device is deenergized.

**Location of DIP switch**

The DIP switch is located in the electronic as shown below.



**DIP switch settings for communication set-up**

DIP switch Communication set-up	Switch 1	Switch 2	Switch 3	Switch 4
EOL active	On	On	On	On
EOL not active	On	On	Off	Off

**NOTICE**

**Avoid DIP switch settings not mentioned in the table**

DIP switch settings not mentioned in the table preceding are not allowed and may reduce communication interface reliability.



# Commissioning

## 6.1 Basic safety notes

 **WARNING**

**Improper commissioning in hazardous areas**

Device failure or risk of explosion in hazardous areas.

- Do not commission the device until it has been mounted completely and connected in accordance with the information in Installing/mounting (Page 29).
- Before commissioning take the effect on other devices in the system into account.

 **WARNING**

**Commissioning and operation with pending error**

If an error message appears, correct operation in the process is no longer guaranteed.

- Check the gravity of the error.
- Correct the error.
- If the error still exists:
  - Take the device out of operation.
  - Prevent renewed commissioning.

 **DANGER**

**Toxic gases and liquids**

Danger of poisoning when venting the device: if toxic process media are measured, toxic gases and liquids can be released.


- Before venting ensure that there are no toxic gases or liquids in the device, or take the appropriate safety measures.

 **WARNING**

**Loss of explosion protection**

Risk of explosion in hazardous areas if the device is open or not properly closed.

- Close the device as described in Installing/mounting (Page 29).


<p> <b>WARNING</b></p> <p><b>Opening device in energized state</b></p> <p>Risk of explosion in hazardous areas</p> <ul style="list-style-type: none"> <li>• Only open the device in a de-energized state.</li> <li>• Check prior to commissioning that the cover, cover locks, and cable inlets are assembled in accordance with the directives.</li> </ul> <p><b>Exception:</b> Devices having the type of protection "Intrinsic safety Ex i" may also be opened in energized state in hazardous areas.</p>
---

## 6.2 General requirements

Before commissioning it must be checked that:

- The device has been installed and connected in accordance with the guidelines provided in Installing/mounting (Page 29) and Connecting (Page 41).
- Device installed in hazardous areas meets the requirements described in Use in hazardous areas (Page 13).

## 6.3 Remote commissioning with PDM FC410

<p> <b>WARNING</b></p> <p><b>Commissioning and operation with pending error</b></p> <p>If an error message appears, correct operation in the process is no longer guaranteed.</p> <ul style="list-style-type: none"> <li>• Check the gravity of the error.</li> <li>• Correct the error.</li> <li>• If the error still exists: <ul style="list-style-type: none"> <li>– Take the device out of operation.</li> <li>– Prevent renewed commissioning.</li> </ul> </li> </ul>
---

SIMATIC PDM (Process Device Manager) is a general-purpose, manufacturer-independent tool for the configuration, parameter assignment, commissioning, diagnostics and maintenance of intelligent field devices and field components. Follow-up installations and additional information on SIMATIC PDM are available on the Internet at SIMATIC PDM ([www.siemens.com/simatic-pdm](http://www.siemens.com/simatic-pdm)).

SIMATIC PDM monitors the process values, alarms and status signals of the device. It allows you to display, compare, adjust, verify, and simulate process device data; also to set schedules for calibration and maintenance.

For information on, for example, how to install and integrate devices, commission the software, see Operating Manual 'Help for SIMATIC PDM'. The manual is delivered with SIMATIC PDM

software. Once the SIMATIC PDM is installed on your computer you find the manual under: Start > All programs > Siemens Automation > SIMATIC > Documentation. Link at our website: 'Help for SIMATIC PDM' (<https://support.industry.siemens.com/cs/ww/de/view/109482406/en>).

---

**Note****Field device parameters**

- For a list of parameters and additional information, consult section "Parameter assignment FC410 (Page 71)".
  - The field device remains in measurement mode during the time you configure the field device.
- 

### 6.3.1 Functions in SIMATIC PDM

SIMATIC PDM monitors the process values, alarms and status signals of the device. It allows you to display, compare, adjust, verify, and simulate process device data; also to set schedules for calibration and maintenance.

Parameters are identified by name and organized into function groups. See Modbus addressing model (Page 131) for more details.

See Modbus addressing model (Page 131) for parameters that do not appear in the menu structure in SIMATIC PDM.

### 6.3.2 Commissioning steps

In the following it is described how to commission the device with SIMATIC PDM.

The steps are divided into the following sections:

1. Initial setup (Page 51)
2. Adding device to the communication network (Page 53)
3. Configuring a new device (Page 56).
4. Wizard - Quick start with PDM (Page 57)
5. Wizard - Zero point adjustment (Page 62)

### 6.3.3 Initial setup

To ensure that SIMATIC PDM connects properly complete the two processes outlined below:

1. Deactivate buffers
2. Update the Electronic Device Description (EDD)

### Deactivate buffers for RS-485 COM port

This deactivation is required to align SIMATIC PDM with the Modbus modem for Windows® operating systems.


---

**Note**

You can find support for Windows operating systems here: [support.automation.siemens.com](http://support.automation.siemens.com) (<http://support.automation.siemens.com>)

---

1. Click "Start" > "Control Panel" to begin configuration.
2. Click on "Hardware and Sound" > "Device Manager".
3. Open "Ports" folder and double-click the COM Port used by the system to open the "Communications Port Properties" window.
4. Select the "Port Settings" tab and click the "Advanced" button.
5. If the "Use FIFO buffers" check box is deselected, click to select.
6. Set "Receiver Buffer" and "Transmitter Buffer" to Low (1).



7. Click "OK" to close out. Close all screens and then reboot.

### Update the Electronic Device Description (EDD)

You can locate the EDD in the SIMATIC PDM Device Library under "Devices" > "Modbus" > "Sensors" > "Flow" > "Coriolis" > "Siemens AG" > "SITRANS FC". Check the downloads on our website ([www.siemens.com/FC410](http://www.siemens.com/FC410)) to make sure you have the latest version of SIMATIC PDM, the most recent Service Pack (SP) and the most recent hot fix (HF).

#### Installing a new EDD:

1. Download the EDD from our website ([www.siemens.com/FC410](http://www.siemens.com/FC410)) and save the zip file to your computer.
2. Launch the SIMATIC PDM Device Integration Manager.
3. Browse to the zipped EDD file and select it.

### 6.3.4 Adding a device to communication network

Before setting the parameters, it is necessary to configure the transmitter project in PDM.

1. Add the device to SIMATIC Modbus network:

- Select "File" > "New".  
Type in a project name, for example *FC commissioning*.
- Go to "View" and select "Process Device Network" view.
- Right-click on the typed in *Project name* and select "Insert New Object" > "Networks".
- Right-click on "Networks" and "Insert New Object" > "Communication Network".
- Click on "Assign Device Type" and select "Modbus Network".
- Click "OK" two times.  
Your PC is now added to the Modbus Network.
- Right-click on "Modbus Network" and select "Insert New Object" > "Object".
- Click on "Assign Device Type" , and select "Devices" > "Modbus" > "Sensors" > "Flow" > "Coriolis" > "SIEMENS AG" > "SITRANS FC".

- Click "OK" two times.




Figure 6-1 Assigning Modbus device to network

2. Set up the communication parameters for SIMATIC Modbus network:
  - Select "Networks" > "My computer", right-click on "COM Port Interface" and select "Object Properties".

- Select the "Communication" tab and configure the communication parameters. The transmitters default settings are:
  - Transmission rate: 19200 baud
  - Parity: even




Figure 6-2 Set the COM Port

- Click "OK".
3. Set up the COM interface:
    - Select "Modbus Networks".
    - Right-click on the object name "SITRANS FC" and select "Object Properties".

- Select the "Communication" tab and configure the Modbus address.




Figure 6-3 Set Modbus address

- Click "OK".

### 6.3.5 Configuring a new device

#### Note

##### Configuring device via SIMATIC PDM

- Clicking "Cancel" button during an upload from device to SIMATIC PDM will result in *some* parameters being updated.
1. Check that you have the most recent EDD, and if necessary update it. See Updating the Electronic Device Description (EDD) (Page 70).
  2. Launch **SIMATIC Manager** and create a new project for the device.
  3. Open the menu "Device > Operation > Reset > Restore ordered configuration". Select "Yes" button and click "OK" to perform a reset to customer ordered settings.
  4. After the reset is complete click on "Upload to PG/PC..." to upload the parameters.
  5. Configure the device via the quick start wizard. (See Wizard - Quick Start via PDM (Page 57).)



### 6.3.6 Wizard - Quick Start via PDM

The Quick Start wizard provides an easy 5-step procedure that configures the device for a simple application.

Please consult the SIMATIC PDM operating instructions or online help for details on using SIMATIC PDM.

#### Access level control

The parameters are protected against changes by access level control. To gain access follow this procedure:

1. Go to menu "Device" > "Security".
2. Select "User" and enter the PIN code.  
The default user PIN code is 2457.


#### Quick Start

---

**Note**

- The "Quick Start" wizard settings are inter-related and changes apply only after you click on "Apply and Transfer" at the end of step 5 to save settings offline and transfer them to the device.
  - Do not use the "Quick Start" wizard to modify individual parameters.
  - Click on "Back" to return and revise settings or "Cancel" to exit the "Quick Start".
- 

Launch SIMATIC PDM, open the menu "Device" > "Wizard - Quick Start...", and follow steps 1 to 5.



### Step 1 - Identification


---

#### Note

The layout of the dialog boxes shown may vary according to the resolution setting for your computer monitor. The recommended resolution is 1280 x 960.


---

1. Click on "Read Data from Device" to upload Quick Start parameter settings from the device to the PC/PG and ensure SIMATIC PDM is synchronized with the device.
2. Click on "Next" to accept the default values.



## Step 2 - Sensor orientation

Step 2 shows an overview of the various recommended installation orientations depending on the application.



### Step 3 - Sensor connection

The transmitter can be ordered with M12 connection or with terminated cable (for example conduit connections).

**SIEMENS**

Ensure correct sensor connection to the transmitter and reliable termination of individual wires prior to continuing with the wizard.


Sensor cable

M12 connection      Terminal connection

Terminal number	Description	Wire color (Siemens cable)
1	VDC +	Orange
2	VDC -	Yellow
3	B	White
4	A	Blue

## Step 4 - Measurement function


Configure the measurement conditions for the selected process variables. Change "Flow direction" if necessary.



## Step 5 - Summary

Check parameter settings, and click on

- "Back" to return and revise values or
- "Apply" to save settings offline or
- "Apply and Transfer" to save settings offline and transfer them to the device.



The message "Quick Start was successful" will appear. Click on "OK".

**See also**

Configuring a new device (Page 56)

**6.3.7 Wizard - Zero Point Adjustment**

---

**Note**

**Preconditions**

Before a zero point adjustment is initiated, the pipe must be flushed, filled and at an absolute flowrate of zero preferably also at operating pressure and temperature.

---

## Performing a zero point adjustment

1. Flush out the flowmeter until a homogenous flow is established and the tubes are completely filled.






Figure 6-4 Best practice zero point adjustment with a by-pass line and two shut-off devices

2. Establish zero flow for example by closing the shut off-valves.
3. Wait 1 to 2 minutes for the system to settle, and then perform zero point adjustment as described in the following steps.
4. Select "Device" > "Wizard - Zero Point Adjustment..." from the main menu of SIMATIC PDM to perform an automatic zero point adjustment.




6.3 Remote commissioning with PDM FC410

- 5. It is recommended to use the default settings ("Auto"). If necessary, change the "Zero Point Adjustment Settings".



- 6. Click on "Next".
- 7. Click on "Perform".





8. During the process a progress bar is visible.
9. At the end of the zero point adjustment the outcome is displayed as an offset and a standard deviation.

---

**Note**

If you get an error message after the zero point adjustment, refer to Fault codes and corrective actions (Page 92).

---

The system is now ready for normal operation.

### 6.3.8 Changing parameter settings using SIMATIC PDM

---


**Note**

Clicking on "Cancel" during an upload from device to SIMATIC PDM will result in some parameters NOT being updated.

---


Many parameters are accessed via the online menus in SIMATIC PDM, see Parameters accessed via drop-down menus (Page 66) for the others.

1. Launch SIMATIC PDM, connect to the appropriate device and upload data.
2. Adjust parameter values in the parameter value field.
3. Click on "Enter".  
The status fields read "Changed".
4. Open the menu "Device".
5. Click on "Download to device".
6. In menu "File" click "Save" to save settings offline.  
The status fields are cleared.



### 6.3.9 Parameters accessed via drop-down menus

Click on menu "Device" or "View" to open the associated drop-down menus.



### Drop-down menus

Table 6-1 Menu "Device"

Option	Description
Download to device	Download all writable parameters to the device.
Upload to PC/PG	Upload all parameters from the device to the parameter table.
Assign address and TAG	Assign communication address and TAG name.
Value comparison	Compare values between device / project.
Object Properties	Show Properties for device and project.
Calibration log	Create calibration logs for field devices.
Change Log	The change log records which actions have been performed with SIMATIC PDM on devices.
Wizard - Quick Start	Start guide for quick commissioning of the device.
Wizard - Zero Point Adjustment	Start guide for zero point adjustment (automatic and manual).
Totalizer	Show or change totalizer settings.
Maintenance	Show maintenance parameters.

Option	Description
Simulation	Start simulation for testing purposes.
Security	Select or change access level.
Restore ordered configuration	Set all parameters to customer ordered settings.
Communication	Show communication settings.

Table 6-2 Menu "View"

Option	Description
Process values (online dialog)	Show all process values.
Device Diagnostic (online dialog)	Show all diagnostics information (alarms and diagnostics parameters).
Toolbar (online dialog)	Show or hide the toolbar.
Status Bar	Show or hide the status bar.
Update	Update the content of the active window.

### 6.3.10 Process values

1. To compare outputs in real time select "View" > "Process values" to see all process values, totalizers and loop current.
2. Verify that the process values show the expected values.




Figure 6-5 Process variables

### Trend view

Open the menu "View" > "Process values" and click on one of the "Trend view" buttons to monitor the trend of one or all process values available at each tab.



# Operating FC410

## 7.1 Remote operation

For information on Modbus addresses, registers and function codes see appendix Modbus communication FC410 (Page 131).

### 7.1.1 Overview of device configuration software

There are currently two competing technologies for configuring field devices:

- Electronic Device Description Language (EDDL)-based software
- Field Device Tool / Device Type Manager (FDT/DTM)-based software

From a practical point of view, both EDDL and FDT/DTM solutions do the same thing: provide a way of reading and writing configuration parameters to field devices and viewing advanced diagnostics.

---

**Note**

- SIMATIC PDM (an EDDL-based software) configures a field device using the Electronic Device Description (EDD) for that device.
  - PACTware and Fieldcare (FDT-based software) use the DTM for that field device.
- 

In addition, there is a new standard called Field Device Integration (FDI) which is a merger of these two technologies. Many of the major vendors have stated that their configuration software will evolve into being an FDI host. At the time this manual was written, Siemens had announced that SIMATIC PDM will become a FDI host system in the near future.

### 7.1.2 SIMATIC PDM

#### 7.1.2.1 Check SIMATIC PDM version

**Procedure**

1. Go to SIMATIC PDM Download (<http://www.siemens.com/simaticpdm/downloads>).
2. Check the support page to make sure you have:
  - The latest version of SIMATIC PDM
  - The most recent Service Pack (SP)
  - The most recent hot fix (HF)

### 7.1.2.2 Updating the Electronic Device Description (EDD)

#### Procedure

1. Check that the EDD revision match the Firmware revision in the device according to the table in section Product compatibility FC410 (Page 7).
2. Go to the support page Software downloads (<http://www.siemens.com/processinstrumentation/downloads>).
3. Enter the product name in the field "Enter search term...".
4. Download the most current EDD of your device.
5. Save files to your computer in an easily accessed location.
6. Launch SIMATIC PDM – Device Integration Manager.  
From the File menu, click "Read device descriptions from compressed source...".
7. Browse to the zipped EDD file, select and open it.
8. Use the "Integration" function to integrate the EDD into the device catalog. The EDD is now accessible via SIMATIC Manager.

### 7.1.2.3 Set address

Open in SIMATIC PDM the menu Device – Set Address, enter a value for New Address, and click on Assign Address.

# Parameter assignment FC410

## 8.1 Functions

### 8.1.1 Process values

According to standard practice with serial communication the Modbus RTU signal updates primary process values and error status values every 10 ms (100 Hz update rate) synchronous with the DSP update cycle.

#### Process value parameters

Default units for process values can be changed, default values are:

- Mass flow (MassflowValue) [kg/s]
- Volume flow (VolumeflowValue) [m<sup>3</sup>/s]
- Density (Density) [kg/m<sup>3</sup>]
- Medium temperature (MediumTemp) [°C]
- Sensor frame temperature [°C]

## 8.1 Functions

Process value	Modbus register	Units
Mass flow	7400	<ul style="list-style-type: none"><li>• g/s (grams per second)</li><li>• g/min (grams per minute)</li><li>• g/h (grams per hour)</li><li>• <b>kg/s (kilograms per second) (default)</b></li><li>• kg/min (kilograms per minute)</li><li>• kg/h (kilograms per hour)</li><li>• kg/d (kilograms per day)</li><li>• t/min (metric tons per minute)</li><li>• t/h (metric tons per hour)</li><li>• t/d (metric tons per day)</li><li>• ton/min (short tons per minute)</li><li>• ton/h (short tons per hour)</li><li>• ton/d (short tons per day)</li><li>• ton (UK)/h (long tons per hour)</li><li>• ton (UK)/d (long tons per day)</li><li>• lb/s (pounds per second)</li><li>• lb/min (pounds per minute)</li><li>• lb/h (pounds per hour)</li><li>• lb/d (pounds per day)</li><li>• Custom</li></ul>



Process value	Modbus register	Units
Volume flow	7500	<ul style="list-style-type: none"> <li>• l/s (liters per second)</li> <li>• l/min (liters per minute)</li> <li>• l/h (liters per hour)</li> <li>• <b>m<sup>3</sup>/s (cubic meters per second) (default)</b></li> <li>• m<sup>3</sup>/min (cubic meters per minute)</li> <li>• m<sup>3</sup>/h (cubic meters per hour)</li> <li>• m<sup>3</sup>/d (cubic meters per day)</li> <li>• Ml/d (megaliters per day)</li> <li>• gal/s (US gallons per second)</li> <li>• gal/min (US gallons per minute)</li> <li>• gal/h (US gallons per hour)</li> <li>• gal/d (US gallons per day)</li> <li>• bbl-beer/s (beer barrels per second = 31 US gallons)</li> <li>• bbl-beer/min (beer barrels per minute = 31 US gallons)</li> <li>• bbl-beer/h (beer barrels per hour = 31 US gallons)</li> <li>• bbl-beer/d (beer barrels per day = 31 US gallons)</li> <li>• bbl/s (oil barrels per second)</li> <li>• bbl/min (oil barrels per minute)</li> <li>• bbl/h (oil barrels per hour)</li> <li>• bbl/d (oil barrels per day)</li> <li>• ft<sup>3</sup>/s (cubic feet per second)</li> <li>• ft<sup>3</sup>/min (cubic feet per minute)</li> <li>• ft<sup>3</sup>/h (cubic feet per hour)</li> <li>• ft<sup>3</sup>/d (cubic feet per day)</li> <li>• gal/s (UK gallons per second)</li> <li>• gal/min (UK gallons per minute)</li> <li>• gal/h (UK gallons per hour)</li> <li>• gal/d (UK gallons per day)</li> <li>• Mgal/d (US megagallons per day)</li> <li>• Custom</li> </ul>

## 8.1 Functions

Process value	Modbus register	Units
Density	7600	<ul style="list-style-type: none"> <li>• <math>\mu\text{g/l}</math> (micrograms per liter)</li> <li>• <math>\mu\text{g/m}^3</math> (micrograms per cubic meter)</li> <li>• <math>\text{mg/l}</math> (milligrams per liter)</li> <li>• <math>\text{g/ml}</math> (grams per milliliter)</li> <li>• <math>\text{g/cm}^3</math> (grams per cubic centimeter)</li> <li>• <math>\text{g/l}</math> (grams per liter)</li> <li>• <math>\text{kg/l}</math> (kilograms per liter)</li> <li>• <b><math>\text{kg/m}^3</math> (kilograms per cubic meter) (default)</b></li> <li>• <math>\text{lb/in}^3</math> (pounds per cubic inch)</li> <li>• <math>\text{lb/gal}</math> (pounds per US gallon)</li> <li>• <math>\text{lb/ft}^3</math> (pounds per cubic foot)</li> <li>• <math>\text{ton/yd}^3</math> (short tons per cubic yard)</li> <li>• Custom</li> </ul>
Temperature	7700	<ul style="list-style-type: none"> <li>• <b><math>^{\circ}\text{C}</math> (degrees Celsius) (default)</b></li> <li>• <math>^{\circ}\text{F}</math> (degrees Fahrenheit)</li> <li>• <math>^{\circ}\text{R}</math> (degrees Rankine)</li> <li>• K (kelvins)</li> </ul>
Mass totalizer		<ul style="list-style-type: none"> <li>• g (grams)</li> <li>• kg (kilograms)</li> <li>• t (metric tons)</li> <li>• ton (short tons)</li> <li>• ton (UK) (long tons)</li> <li>• oz (ounces avoirdupois)</li> <li>• lb (pounds)</li> <li>• Custom</li> </ul>

See also the description of the Zero point adjustment via SIMATIC PDM (Page 62).

**Note****Preconditions**

Before a zero point adjustment is initiated, the pipe must be flushed, filled and at an absolute flowrate of zero preferably also at operating pressure and temperature.

**Note****Change of parameters during zero point adjustment**

Do not change any other parameter during the zero point adjustment procedure.

**Automatic zero point adjustment**

The device measures and calculates the correct zero point automatically.

The automatic zero point adjustment of the flowmeter is set by the following parameters:

- Duration (Modbus address 2135)
- Start Zero Point Adjustment (Modbus address 2180)

When zero adjust is initiated by selecting **Start Zero Point Adjustment**, the mass flow values are acquired and totalized for the configured period (Duration). The default zero point adjustment period (30 s.) is normally sufficient for a stable zero point measurement.

---

#### Note

##### Extremely low flow quantity

If the flow quantity is extremely small, extremely precise measurement is necessary. In this case, a long zero point adjustment period can be selected for improved zero point adjustment.

---

## Zero point calculation

During zero point adjustment, an average value is automatically calculated using the following formula:

---

#### Zero point offset value

Average of N flow values

$$\bar{x} \equiv \frac{\sum_{i=1}^N x_i}{N}$$

$x_i$  is an instantaneous flow value sampled in the time domain

N = Number of samples during zero point adjustment

---

The offset value must be within the determined **Zero Point Offset Limit** (Modbus address 2140).

#### Note

##### Exceeded zero point offset limit

If the offset value is greater than the configured limit, proceed as follows:

- Check that the tube is completely filled and that the flowrate is absolute zero.
  - Check the validity of the configured zero point offset limit.
  - Repeat the zero point adjustment.
- 

## Zero point standard deviation

After completion of the procedure, the standard deviation is calculated in accordance with the following formula:

---

#### Zero point standard deviation

Standard deviation of N values

$$s \equiv \sqrt{\frac{\sum_{i=1}^N (x_i - \bar{x})^2}{N - 1}}$$


---

## 8.1 Functions

The standard deviation contains important feedback on the homogeneity of the fluid, for example on the presence of bubbles or particles.

The standard deviation must be within the determined **Standard deviation limit** (Modbus address 2138).

---

### Note

#### Exceeded standard deviation limit

If the standard deviation is greater than the configured limit, proceed as follows:

- Check that the tube is completely filled and that the flow rate is absolute zero.
  - Check that the installation is vibration-free.
  - Check the validity of the configure **Standard deviation limit** (Modbus address 2138).
  - Repeat the zero point adjustment.
- 

### Successful automatic zero point adjustment

If the new zero point offset value is valid, it is automatically stored as the new zero point for the sensor. It remains stored in the case of a power failure.

### Manual zero point adjustment

In case an automatic zero point adjustment cannot be performed, it is possible to do a manual zero point adjustment by entering the zero point offset value.

1. Select Modbus address 2132 **Zero Point Adjustment** and set the value to 1 = **Manual Zero Point Adjustment**.
2. Select Modbus address 2133 **Manual Zero Point Offset** and enter the desired offset value.

### 8.1.2 Low flow cut-off

In certain applications, for example dosing applications, no flow signals under a certain flow level are desired. In these applications, the flow signal can be forced to zero when the flow is lower than a predefined flow value (low flow cut-off).

The transmitter provides two parameters for setting the low flow cut-off:

- Mass flow cut-off limit (Modbus address 2125)
- Volume flow cut-off limit (Modbus address 2170)

### 8.1.3 Empty tube monitoring

The empty tube monitoring function uses the process density for detecting an empty tube. Use of this function is recommended for all standard applications.

---

**Note****Gas applications**

Deactivate the empty tube monitoring function.

---

### Empty tube monitoring parameters

Two parameters for setting the empty tube monitoring function are available:

- Empty tube detection (Modbus address 2129)
- Empty tube limit (Modbus address 2127)

The empty tube monitoring is activated via the Empty tube detection parameter. When the empty tube monitoring function is on, the mass flow / volume flow value is forced to zero if the tube is empty.

The tube is defined as empty if the measured density value is lower than the value defined via the Empty tube limit parameter.

---

**Note****Process media density**

Risk of unintentionally forcing flow values to zero if the difference between the Empty tube limit density value and the density of the process media is not sufficient.

- Ensure sufficient difference between the Empty tube limit density value and the process media density.
- 

### 8.1.4 Process noise damping

#### Noise damping function

The dynamic sensitivity of the flow measurement signal to rapid changes in process flows can be reduced by use of the process noise damping function. The function is typically used in environment with:


- Strongly pulsating flow
- Changing pump speeds
- Large pressure variations

### Process noise damping settings

Reduce interfering process noise by increasing the setting of the parameter **Process noise damping** (Modbus address 2130).

- Centrifugal pump (1: low)
- Triplex pump (2)
- Duplex pump (3)
- Simplex pump (4)
- Cam pump (5: high)

The default value is **Duplex pump**. The damping affects all functions and outputs of the sensor.




---

#### Note

##### Increased reaction time

The reaction time of the sensor increases when the process noise is damped.

---

## 8.1.5 Totalizer

### Totalizer function

The device has one totalizer function that can be used to totalize the mass flow process value. Default unit of the totalizer can be changed, see Modbus register 8320.

The totalizer may be paused, resumed or reset:

- Pause (Modbus address 2613): the totalizer holds the last value before the failure occurred
- Resume (Modbus address 2614): the totalizer continues counting the actual measured value
- Reset (Modbus address 2612): the totalizer continues counting based on the last input value (for example mass flow) before the failure occurred.

---


#### Note

The totalizer is reset on power failure.

---

## 8.1.6 Security

All parameters may be viewed but some are protected against changes by access level control. The Security menu makes it possible to gain access to PIN code protected parameters and to change PIN codes.



The access levels are:

- Read only  
Allows no configuration. The user is only able to read the parameter values. No PIN code is required.
- User  
Allows configuration and service of all parameters except calibration parameters. Default PIN code is 2457.

---

### Note

#### Auto Log Off function

The access level will be set to Read only mode if the device is powered off.

---

### 8.1.7 Simulation

Simulation is used for testing purposes, typically for checking that the readings of the control system are correct.

#### Process value simulation

The following process values can be simulated:

- Mass flow (Modbus address 2764)
- Density (Modbus address 2766)
- Medium temperature (Modbus address 2768)
- Sensor frame temperature (Modbus address 2770)
- Volume flow (Modbus address 2772)

The simulation can be activated through SIMATIC PDM in the menu **Device → Simulation → Process Variables**.

### 8.1.8 Float transmission

The Float Byte Order function ensures that the master and slave use the same sequence of the bytes when transmitting float values. This enables the user to configure the transmitter using the configuration tool, SIMATIC PDM, and operate the device with all types of PLCs without reprogramming the PLC. The transmission order is configured by setting the parameter **Byte Order** in the submenu **Device → Communication**.

---

#### Note

The command **Restart Communication** must be executed to activate the new byte order setting.

---

This table shows the different options for setting the transmission method:

Selection	Sequence			
	1st	2nd	3rd	4th
1 - 0 - 3 - 2	Byte 1 (MMMMMMMM)	Byte 0 (MMMMMMMM)	Byte 3 (SEEEEEEE)	Byte 2 (EMMMMMMM)
0 - 1 - 2 - 3	Byte 0 (MMMMMMMM)	Byte 1 (MMMMMMMM)	Byte 2 (EMMMMMMM)	Byte 3 (SEEEEEEE)



Selection	Sequence			
	1st	2nd	3rd	4th
2 - 3 - 0 - 1	Byte 2 (EMMMMMMM)	Byte 3 (SEEEEEEE)	Byte 0 (MMMMMMMM)	Byte 1 (MMMMMMMM)
3 - 2 - 1 - 0 *	Byte 3 (SEEEEEEE)	Byte 2 (EMMMMMMM)	Byte 1 (MMMMMMMM)	Byte 0 (MMMMMMMM)

\* = Factory setting

S = Sign

E = Exponent

M = Mantissa

#### NOTICE

##### Change of float byte order

If the float byte order is changed by use of PDM to anything other than default, all float values shown in PDM are wrong.

## 8.1 Functions

## Service and maintenance

### 9.1 Basic safety notes

---

#### Note

The device is maintenance-free.

---

The device is maintenance-free. However, a periodic inspection according to pertinent directives and regulations must be carried out.

An inspection can include, for example, check of:

- Ambient conditions
- Seal integrity of the process connections, cable entries, and cover
- Reliability of power supply, lightning protection, and grounds

#### WARNING

##### Impermissible repair of explosion protected devices

Risk of explosion in hazardous areas

- Repair must be carried out by Siemens authorized personnel only.

#### WARNING

##### Dust layers above 5 mm

Risk of explosion in hazardous areas.

Device may overheat due to dust build up.

- Remove dust layers in excess of 5 mm.

#### NOTICE

##### Penetration of moisture into the device

Damage to device.

- Make sure when carrying out cleaning and maintenance work that no moisture penetrates the inside of the device.

 **WARNING**

**Leaks in the sample gas path**

Risk of poisoning.

When measuring toxic process media, these can be released or collect in the device if there are leaks in the sample gas path.

- Purge the device as described in Commissioning (Page 49).
- Dispose of the toxic process media displaced by purging in an environmentally friendly manner.

 **WARNING**

**Use of a computer in a hazardous area**

If the interface to the computer is used in the hazardous area, there is a risk of explosion.

- Ensure that the atmosphere is explosion-free (hot work permit).

## 9.2 Recalibration

Siemens offers to recalibrate the sensor.

The following calibration types are offered as standard according to configuration:

- Standard mass flow calibration
- Density calibration
- Customer specified mass flow calibration
- Accredited Siemens ISO/IEC 17025 mass flow calibration

---

**Note**

**SensorFlash**

For sensor recalibration the SensorFlash memory unit must always be returned with the sensor.

---

## 9.3 Cleaning

### Cleaning the enclosure

- Clean the outside of the enclosure with the inscriptions using a cloth moistened with water or a mild detergent.
- Do not use any aggressive cleansing agents or solvents, e.g. acetone. Plastic parts or the painted surface could be damaged. The inscriptions could become unreadable.

** WARNING****Electrostatic charge**

Risk of explosion in hazardous areas if electrostatic charges develop, for example, when cleaning plastic surfaces with a dry cloth.

- Prevent electrostatic charging in hazardous areas.

## 9.4 Maintenance and repair work

** WARNING****Impermissible repair of explosion protected devices**

Risk of explosion in hazardous areas

- Repair must be carried out by Siemens authorized personnel only.

** WARNING****Maintenance during continued operation in a hazardous area**

There is a risk of explosion when carrying out repairs and maintenance on the device in a hazardous area.

- Isolate the device from power.


- or -


- Ensure that the atmosphere is explosion-free (hot work permit).


** WARNING****Impermissible accessories and spare parts**

Risk of explosion in areas subject to explosion hazard.

- Only use original accessories or original spare parts.
- Observe all relevant installation and safety instructions described in the instructions for the device or enclosed with the accessory or spare part.

 <b>WARNING</b>
<b>Enclosure open</b> Risk of explosion in hazardous areas as a result of hot components and/or charged capacitors inside the device. To open the device in a hazardous area: <ol style="list-style-type: none"><li>1. Isolate the device from power.</li><li>2. Visually inspect sensor inlet and outlet.</li></ol> <b>Exception:</b> Devices exclusively having Intrinsic safety (Ex i) may be opened in an energized state in hazardous areas.

 <b>WARNING</b>
<b>Hot, toxic or corrosive process media</b> Risk of injury during maintenance work. When working on the process connection, hot, toxic or corrosive process media could be released. <ul style="list-style-type: none"><li>• As long as the device is under pressure, do not loosen process connections and do not remove any parts that are pressurized.</li><li>• Before opening or removing the device ensure that process media cannot be released.</li></ul>

 <b>WARNING</b>
<b>Improper connection after maintenance</b> Risk of explosion in areas subject to explosion hazard. <ul style="list-style-type: none"><li>• Connect the device correctly after maintenance.</li><li>• Close the device after maintenance work.</li></ul> Refer to Cables and cable entries (Page 107).

The device is maintenance-free. However, a periodic inspection according to pertinent directives and regulations must be carried out.

An inspection can include check of:

- Ambient conditions
- Seal integrity of the process connections, cable entries, and cover screws
- Reliability of power supply, lightning protection, and grounds

<b>NOTICE</b>
Repair and service must be carried out by Siemens authorized personnel only.

**Note**  
Siemens defines flow sensors as non-repairable products.

### 9.4.1 Maintenance information FC410

#### Maintenance information parameters

The basic maintenance information parameters are:

- Current date and time
- Operating time total
- Operating time
- Transmitter Hardware version
- Sensor Hardware version

### 9.4.2 Service information FC410

Service information is information about the condition of the device used for diagnostics and service purposes.

#### Service information parameters

The basic service information parameters are:

- Driver current
- Pickup 1 amplitude
- Pickup 2 amplitude
- Sensor frequency
- Sensor frame temperature
- Medium temperature
- Zero point adjustment Auto/Manual
- Zero point Offset
- Manual Zero Point
- Zero Point Standard deviation

## 9.5 Replacing the device

<p><b>⚠ CAUTION</b></p> <p><b>Corrosive substances</b></p> <p>Risk of chemical burns when replacing the sensor.</p> <p>The sensor in the device contains corrosive substances that result in burns on unprotected skin.</p> <ul style="list-style-type: none"> <li>• Make sure that the sensor enclosure is not damaged when replacing the sensor.</li> <li>• If contact with the corrosive substances occurs, rinse the affected skin immediately with large amount of water to dilute substance.</li> </ul>
---




## 9.6 Spare parts/Accessories

### 9.6.1 Ordering of spare parts

Ensure that your ordering data is not outdated. The latest ordering data is always available on the Internet: SIOS catalog Coriolis (<https://support.industry.siemens.com/cs/products?dtp=Catalog&mfn=ps&pnid=17346&lc=de-DE>)

### 9.6.2 Replaceable components

This table gives an overview of which components can be replaced.

Component	Order number	Photo	Replacable in Ex devices	Hot swappable <sup>1)</sup>
SITRANS FC Bag of loose parts for sensor Contents: Screws, O-rings, cable clamp parts	A5E03549324		<b>Yes</b> Observe hazardous area access protocol	<b>No</b>
SITRANS FCT010 Blind lid in painted aluminum small (Ø85 mm)	A5E03549295		<b>Yes</b> Observe hazardous area access protocol	<b>Yes</b> Observe hazardous area access protocol
Sensor housing with cable entries in metric tread	A5E03549313		<b>No</b>	<b>No</b>



Component	Order number	Photo	Replacable in Ex devices	Hot swappable <sup>1)</sup>
Sensor housing with cables entries in NPT tread	A5E03906080		No	No
SITRANS FCS400 M12 option for sensor housing	A5E03906095		No	No
Frontend cassette Spare part frontend cassette for FCT010 From firmware 2.X	A5E03549191		No	No
Frontend cassette Spare part frontend cassette for FCT010 From firmware 4.0	A5E41526286			

<sup>1)</sup> Components may be replaced while power is on in non-hazardous areas only.

## 9.7 Transportation and storage

To guarantee sufficient protection during transport and storage, observe the following:

- Keep the original packaging for subsequent transportation.
- Devices/replacement parts should be returned in their original packaging.
- If the original packaging is no longer available, ensure that all shipments are properly packaged to provide sufficient protection during transport. Siemens cannot assume liability for any costs associated with transportation damages.

### NOTICE

#### Insufficient protection during storage

The packaging only provides limited protection against moisture and infiltration.

- Provide additional packaging as necessary.

Special conditions for storage and transportation of the device are listed in Technical data (Page 103).

## 9.8 Return procedure

Enclose the bill of lading, return document and decontamination certificate in a clear plastic pouch and attach it firmly to the outside of the packaging.

**Required forms**

- Delivery note
- Return goods delivery note (<http://www.siemens.com/processinstrumentation/returngoodsnote>)  
with the following information:
  - Product (item description)
  - Number of returned devices/replacement parts
  - Reason for returning the item(s)
- Decontamination declaration (<http://www.siemens.com/sc/declarationofdecontamination>)  
With this declaration you warrant "that the device/replacement part has been carefully cleaned and is free of residues. The device/replacement part does not pose a hazard for humans and the environment."  
If the returned device/replacement part has come into contact with poisonous, corrosive, flammable or water-contaminating substances, you must thoroughly clean and decontaminate the device/replacement part before returning it in order to ensure that all hollow areas are free from hazardous substances. Check the item after it has been cleaned. Any devices/replacement parts returned without a decontamination declaration will be cleaned at your expense before further processing.

**9.9 Disposal**

**9.9.1 Special disposal required**

---

**Note**

**Special disposal required**

The device includes components that require special disposal.

- Dispose of the device properly and environmentally through a local waste disposal contractor.
- 



Devices described in this manual should be recycled. They may not be disposed of in the municipal waste disposal services according to the Directive 2012/19/EC on waste electronic and electrical equipment (WEEE).





Devices can be returned to the supplier within the EC, or to a locally approved disposal service for eco-friendly recycling. Observe the specific regulations valid in your country.

Further information about devices containing batteries can be found at: Information about battery / product return (WEEE) (<https://support.industry.siemens.com/cs/document/109479891/>)

## Diagnostics and troubleshooting FC410

### 10.1 Device status symbols





















#### Device status symbols





SIMATIC PDM/PLC		
Symbol	Device status	Priority
	Maintenance alarm	1
<p><b>Cause:</b> Output signal invalid due to fault in the field device or in the peripherals.  <b>Action:</b> Maintenance is required immediately.</p>		
	Manual operation	4
<p><b>Cause:</b> Output signal temporarily invalid (e.g. frozen) due to work being performed on the device.  <b>Action:</b> Disable manual mode via HMI or engineering system.</p>		
	Process value alarm	8
<p><b>Cause:</b> Deviations from permissible ambient or process conditions detected by the device (through self-monitoring, or warnings / faults in the device) indicate that the measured value is unreliable or deviations from the set value in the actuators is most likely greater than anticipated under normal operating conditions. Process or ambient conditions will damage the device or result in unreliable output.  <b>Action:</b> Check ambient temperature or process conditions. If possible, install device at different location.</p>		
	Process value warning	10
<p><b>Cause:</b> Deviations from permissible ambient or process conditions detected by the device (through self-monitoring, or warnings / faults in the device) indicate that the measured value is unreliable or deviations from the set value in the actuators is most likely greater than anticipated under normal operating conditions. Process or ambient conditions can damage the device or result in unreliable output.  <b>Action:</b> Check ambient temperature or process conditions. If possible, install device at different location.</p>		

## 10.2 Fault codes and corrective actions

### 10.2.1 Diagnostics

ID	Icons	Message	Cause/Action
36		Sensor supply volt. out of range	Contact your local Siemens representative.
37		Sensor supply volt. out of range	Contact your local Siemens representative.
38		Temperature measurement fault	Turn off the power, wait 5 seconds and turn on the power again. If the problem persists, contact your local Siemens representative.
39		Temperature measurement fault	Turn off the power, wait 5 seconds and turn on the power again. If the problem persists, contact your local Siemens representative.
40		Temperature measurement fault	Turn off the power, wait 5 seconds and turn on the power again. If the problem persists, contact your local Siemens representative.
41		Temperature measurement fault	Turn off the power, wait 5 seconds and turn on the power again. If the problem persists, contact your local Siemens representative.
42		Flow values not valid	Can be due to problems with measured fluid or hardware malfunction. If the problem persists, contact your local Siemens representative.
43		Flow values not valid	Can be due to problems with measured fluid or hardware malfunction. If the problem persists, contact your local Siemens representative.
44		Flow values not valid	Can be due to problems with measured fluid or hardware malfunction. If the problem persists, contact your local Siemens representative.
45		Flow values not valid	Can be due to problems with measured fluid or hardware malfunction. If the problem persists, contact your local Siemens representative.
46		Invalid calibration data	Contact your local Siemens representative for recalibration.
47		Invalid compensation data	Contact your local Siemens representative.
49		Malfunction in Pickup Amplitude	Contact your local Siemens representative.
50		Malfunction in Pickup Amplitude	Contact your local Siemens representative.
55		Malfunction in sensor driver	Contact your local Siemens representative.
56		Malfunction in sensor driver	Contact your local Siemens representative.

ID	Icons	Message	Cause/Action
57		Malfunction in sensor driver	Contact your local Siemens representative.
58		Unstable driver oscillation	Contact your local Siemens representative.
59		Mass flow out of specification	Reduce the flow. If the problem persists, contact your local Siemens representative.
60		Volume flow out of specification	Reduce the flow. If the problem persists, contact your local Siemens representative.
61		Density out of specification	Contact your local Siemens representative.
62		Fluid temp. below limit	Increase the fluid temperature. If the problem persists, contact your local Siemens representative.
63		Fluid temp. above limit	Reduce the fluid temperature. If the problem persists, contact your local Siemens representative.
64		Frame temp. below limit	Increase fluid temperature and check that ambient temperature is within specified limits. If the problem persists, contact your local Siemens representative.
65		Frame temp. above limit	Reduce fluid temperature and check that ambient temperature is within specified limits. If the problem persists, contact your local Siemens representative.
66		Standard Deviation above limit	Measurement continues with values from last successful zero point adjustment. Improve conditions for automatic zero point adjustment and repeat adjustment.
67		Zero Point Offset above limit	Measurement continues with values from last successful zero point adjustment. Improve conditions for automatic zero point adjustment and repeat adjustment.
68		Zero point adjustment failed	Measurement continues with values from last successful zero point adjustment. Improve conditions for automatic zero point adjustment and repeat adjustment.
69		'Empty Tube Limit' exceeded	Make sure that the sensor is filled with liquid and that the liquid density is within the specified 'Empty Tube Limit'.
70		Too little fluid in tube	Make sure that the sensor is filled with liquid.
71		Parameter storage malfunction	Turn off the power, wait 5 seconds and turn on the power again. If the problem persists, contact your local Siemens representative.
72		Internal error in sensor	Contact your local Siemens representative.
73		Internal error in sensor	Contact your local Siemens representative.
74		Internal error in sensor	Contact your local Siemens representative.
75		Internal error in sensor	Contact your local Siemens representative.
76		Internal error in sensor	Contact your local Siemens representative.

ID	Icons	Message	Cause/Action
77		Internal error in sensor	Contact your local Siemens representative.
78		Unstable measurement condition	Check if air is present in the liquid and that the flowmeter is operated within its specifications.
79		Auto filtering	Check that the flowmeter is operated within its specifications. Check other alarms to rule out HW malfunction.
87		Sensor startup	Unplug and reconnect the sensor cable. If the diagnostic persists after the specified startup time, restart the device. If the problem persists, contact Technical Support.

### 10.2.2 Alarm messages

In the following tables the bits for alarm group 1 and alarm group 2 can be found along with possible causes and directions for corrective action.

#### Alarm group 1 (Modbus address 3012)

Bit	Diagnostic	Action
4 5	Sensor supply volt. out of range	Contact Siemens customer support
6 7 8 9	Temperature measurement fault	Contact Siemens customer support
10 11 12 13	Flow values not valid	Can be due to problems with measured fluid or hardware malfunction. If the failure continues then contact Siemens customer support
14	Invalid calibration data	Contact Siemens customer support for recalibration
15	Invalid compensation data	Contact Siemens customer support
17 18	Malfunction in Pickup Amplitude	Contact Siemens customer support
23 24 25	Malfunction in sensor driver	Contact Siemens customer support
26	Unstable driver oscillation	Contact Siemens customer support
27	Massflow out of specification	Reduce the flow. If the failure continues then contact Siemens customer support
28	Volumeflow out of specification	Reduce the flow. If the failure continues then contact Siemens customer support
29	Density out of specification	Contact Siemens customer support
30	Fluid temp. below limit	Increase the fluid temperature. If the failure continues then contact Siemens customer support
31	Fluid temp. above limit	Reduce the fluid temperature. If the failure continues then contact Siemens customer support

**Alarm group 2 (Modbus address 3014)**

Bit	Diagnostic	Action
0	Frame temp. below limit	Increase fluid temperature and check that ambient temperature is within specified limits. If the failure continues then contact Siemens customer support
1	Frame temp. above limit	Reduce fluid temperature and check that ambient temperature is within specified limits. If the failure continues then contact Siemens customer support
2	<b>Standard Deviation</b> above limit (shown for only 2 seconds)	Measurement continues with values from last successful zero point adjustment. Improve conditions for automatic zero point adjustment and repeat adjustment.
3	<b>Zero Point Offset</b> above limit (shown for only 2 seconds)	Measurement continues with values from last successful zero point adjustment. Improve conditions for automatic zero point adjustment and repeat adjustment.
4	Zero point adjustment failed (shown for only 2 seconds)	Measurement continues with values from last successful zero point adjustment. Improve conditions for automatic zero point adjustment and repeat adjustment.
5	<b>Empty Tube Limit</b> exceeded	Make sure that the sensor is filled with liquid and that the liquid density is within the specified <b>Empty Tube Limit</b>
6	The sensor is partially filled	Make sure that the sensor is filled with liquid
7	Parameter storage malfunction	Turn off the power, wait 5 seconds and turn on the power again. If the failure continues then contact Siemens customer support
8 9 10 11 12 13	Internal error in sensor	Contact Siemens customer support
14	Unstable measurement condition	Check if air is present in the liquid and that the flowmeter is operated within its specifications
15	Auto filtering	Check that the flowmeter is operated within its specifications. Check other alarms to rule out HW malfunction
23	The sensor is stabilizing	Turn off the power, wait 5 seconds and turn on the power again. If the failure continues then contact Siemens customer support.

## 10.3 Operation troubleshooting


### 10.3.1 Updating the firmware

**Note****Firmware update**

FW update is to be done only by authorized and trained service personnel.

10.3 Operation troubleshooting


1. Contact Technical Support (<https://support.industry.siemens.com/cs/my/src?lc=en-WW>) to receive the latest available firmware bundle.
2. Install the SITRANS FC410 service tool (<https://support.industry.siemens.com/cs/ww/en/view/95197152>). Use this tool to download the firmware to the transmitter.
3. Click "Scan network" to connect to your device via the Service tool:



4. Select your device in the "Network scan results" list.



5. Click on "Configure selected device".



6. Go to the tab "FW update".

7. Click "Load FW file".

8. Select firmware bundle.

9. Click "Start FW update".

### 10.3.2 Troubleshooting sensor-related problems

Incorrect and unstable measurements, especially at low flows, are typically a result of an unstable zero point due to:

- Incorrect installation
- Bubbles in the liquid
- Vibrations or cross talk
- Solid particles settling in the liquid

Follow the 4-step guide to troubleshooting:

Step 1          Preliminary application inspection (Page 98)

Step 2          Zero point adjustment (Page 98)

### 10.3 Operation troubleshooting

Step 3 Measurement error calculation (Page 98)

Step 4 Application improvement (Page 99)

The guide enables you to trace the reason for incorrect measurements and to improve the application.

#### 10.3.2.1 Step 1: Inspecting the application

Ensure that:

1. The sensor is installed as described in Installing/mounting (Page 32).
2. The sensor is located in a vibration-free position. Vibrations can disturb the sensor and therefore cause measurement error.

Depending on application, you should furthermore ensure the following:

- Liquid application  
Ensure that the sensor is filled with liquid and liquid only.  
Air or gas bubbles in the liquid cause instability and can result in measurement errors.  
Flush the pipe systems and the sensor for several minutes at maximum flowrate to remove any air bubbles which may be present.

---

#### Note

The liquid must be homogeneous in order to measure with high accuracy. If the liquid contains solid particles of greater density than the liquid, then these solids can settle, especially at low flow rates, which will cause instability in the sensor and lead to measurement errors.

For pastes or process fluids with suspended solids always orient the sensor vertically with flow in upward direction to maintain solids suspension.

---

- Gas application  
Ensure that the gas pressure/temperature conditions contain sufficient superheat to prevent dewing or precipitation. If the gas contains vapor or droplets then these may precipitate, causing instability.

#### 10.3.2.2 Step 2: Performing a zero point adjustment

The second step in the troubleshooting procedure is to zero point adjust the device. For further information on zero point adjustment, see Remote commissioning with PDM FC410 (Page 50).

#### 10.3.2.3 Step 3: Calculating the measurement error

The result of the zero point adjustment will show you if the zero point was set under good and stable conditions.

The lower the obtained value of the parameter **Zero Point Standard Deviation**, the lower is the achievable measuring error. For a well-installed flowmeter, the Zero Point Standard Deviation corresponds to the specified zero point stability for the sensor size, see Performance (Page 103).

The parameter **Zero Point Standard Deviation** is located in the **Maintenance & Diagnostics** menu in the SIMATIC PDM.

- The error curve is plotted from the formula:

$$E = \pm \sqrt{(\text{Cal})^2 + \left(\frac{Z \times 100}{q_m}\right)^2}$$

E = Error [%]

Z = Zero point [kg/h]

qm = Mass flow [kg/h]

Cal. = Calibrated flow accuracy: 0.10




Table 10-1 Reference conditions for flow calibrations (ISO 9104 and DIN/EN 29104)

Flow conditions	Fully developed flow profile
Temperature, medium	20 °C ± 2 °C (68 °F ± 3.6 °F)
Temperature, ambient	20 °C ± 2 °C (68 °F ± 3.6 °F)
Liquid pressure	2 ± 1 bar
Density	0.997 g/cm <sup>3</sup>
Supply voltage	Un ± 1 %
Warming-up time	30 min.
Cable length	5 m between transmitter and sensor

#### 10.3.2.4 Step 4: Improving the application

In the following it is described how to find the causes of a high Zero Point Standard Deviation and how to improve the installation.

##### Setting Low flow cut-off

In order to see if the zero point becomes more stable when making changes / adjustments, the Low mass flow cut-off (MassFlowCutOff) must be set to 0.0%.

When Low flow cut-off has been set, it is possible to see the instability directly from the massflow in the online window (**View** → **Process Variables**)

This information can be used to troubleshoot. For example, tightening the brackets which hold the sensor, or turning off the pump to check if vibrations from the pump are disturbing the sensor, etc.

#### **Incorrect installation of the sensor**

- Has the sensor been correctly installed, that is fastened to the floor / wall or frame with good mounting brackets as shown in the instructions?

Especially for low flowrates, that is flowrates less than 10% of the maximum capacity of the flow meter, it is important that the sensor is correctly and stably installed.

If the sensor is not correctly fixed in place, the zero point of the sensor will change, leading to measuring errors.

Try to tighten up the sensor brackets to see whether the flow instability is reduced.

#### **Vibrations and cross talk**

Vibrations in the pipe system are normally generated by pumps.

Typically, cross talk is generated by two sensors of identical size and positioned in close proximity in the same pipe, or installed on the same rail or frame.

Vibrations / cross talk have a greater or lesser effect upon the zero point stability and therefore also the measurement accuracy.

1. Check whether there are vibrations.  
Turn off the pump and check whether the zero point stability improves, that is if the flowrate fluctuation in kg/h is reduced.  
If the sensor is disturbed by vibration from the pump or by pressure pulsations, the installation should be improved or the pump should be exchanged, for example to another type.
2. Check for cross talk.  
Turn off the power to the other flow meter(s) and wait approximately 2 minutes, so the vibrating tubes in the sensor have stopped vibrating. Then check if the zero point stability has improved, that is that the fluctuation in kg/h has been reduced. If this is the case, the sensors disturb one another and the installation should be improved.

#### **Air in the liquid**

When air is present in the liquid, the zero point becomes unstable, which leads to a poor measurement accuracy.

Checking for air:

- Check the Driver Current (View → Device Diagnostics → Advanced Diagnostic)
- Check if the Driver Current varies more than  $\pm 1$  mA. If this is the case, it is usually due to the presence of air or gas bubbles in the liquid.
- Increase the pressure in the sensor, creating a large back pressure upon the sensor by reducing the opening of the outlet valve or by increasing the pump pressure. Thereby the size of air bubbles inside the sensor will be minimized. If the Driver Current value increases and / or the stability of the Driver Current decreases, it is proof that the liquid contains air or gas bubbles.

**Typical causes of air in the liquid**

- The entry pipe and sensor have not been properly filled with liquid.
- The pump cavitates, the rotary speed of the pump is too high in relation to the supply of liquid to the pump.
- The flow rate in the pipe is too high, so components sitting in front of the flowmeter can cause cavitation.
- If there is a filter installed before the flowmeter, it may be close to blocking, which also can cause cavitation.
- Liquid flashes to vapor bubbles while passing through partially open valves or orifices.
- The piping on the pump suction side, pump gaskets or the pump itself is not tight. Air gets sucked into the system due to a low pressure on the pump suction side.

**Solid particles in the liquid**

If the solid particles in a liquid have a density higher than that of the liquid, they can precipitate inside the sensor and cause instability which leads to a measurement error.

If solid particles are present in the liquid, they must be homogeneously distributed and have similar density as the liquid. Otherwise they can cause relatively large measurement errors.

It is important that the sensor is installed such that solid particles can easily run out of the sensor.

1. Ensure that the sensor is installed vertically with an upwards flow.
2. Check if solid particles are present in the liquid:  
Take a sample of the liquid, fill a glass and see if the solids precipitate.

## 10.4 Diagnosing with PDM

SIMATIC PDM is a suitable tool for diagnosing the device.

You can use SIMATIC PDM to read all available parameters to a table for analyzing offline, view online/actual process values and online/actual diagnostic information.

**Requirements**

The following procedure must be completed before diagnosing:

- Installation of PDM and PDM device driver
- Connection of communications or digital communications interface

Refer to SIMATIC PDM (Page 69).



## Technical data

---

### Note

#### Device specifications

Siemens makes every attempt to ensure the accuracy of these specifications but reserves the right to change them at any time.

---

### 11.1 Power

Table 11-1 Power supply

Description	Specification
Supply voltage [V]	12 - 27 VDC Um: 60 VDC
for Ex d, t	12 - 24 VDC
Reverse polarity protection	Yes
Power consumption	1.1 W

Specification in case of Intrinsic safety power supply: Ui: 20 V, Ii: 484 mA, Pi: 2.3 W, Li: 0.6 uH, Ci: 1.9 nF.

### 11.2 Performance

Table 11-2 Reference conditions

Description	Specification
Process media	Water
Process media temperature	20 °C (68 °F)
Ambient temperature	25 °C (77 °F)
Process media pressure	2 bar (29 psi)
Process media density	0.997 g/cm <sup>3</sup> (62.2 lb/ft <sup>3</sup> )
Reference device orientation	Horizontal installation, tubes down, flow in direction of arrow on casing, see Installing/Mounting (Page 29).

11.2 Performance

Table 11-3 Mass flow accuracy

Specification	Unit	Sensor size		
		DN15	DN25	DN50
Qmin - minimum flowrate	kg/h (lb/min)	20 (0.735)	200 (7.35)	750 (27.6)
Qnom - nominal flowrate	kg/h (lb/min)	3700 (136)	11500 (423)	52000 (1910)
Qmax - maximum flowrate	kg/h (lb/min)	6400 (235)	17700 (650)	70700 (2598)
Max. zero point stability	kg/h	±0.2	±2.0	±7.5
Measuring accuracy	%	±0.1	±0.1	±0.1
Repeatability error	%	±0.05	±0.05	±0.05

Table 11-4 Density accuracy (liquids)

Specification	Unit	Sensor size		
		DN15	DN25	DN50
Density accuracy, standard calibration	kg/m <sup>3</sup>	±5	±5	±5
Density accuracy, extended calibration	kg/m <sup>3</sup>	±0.5	±0.5	±0.5
Density repeatability	kg/m <sup>3</sup>	±0.25	±0.25	±0.25
Density, media pressure effect	(kg/m <sup>3</sup> )/bar	±0.5	±0.25	±0.25
Density, media temperature effect	(kg/m <sup>3</sup> )/°C	±0.1	±0.1	±0.1

Table 11-5 Media temperature accuracy

Specification	Unit	Sensor size		
		DN15	DN25	DN50
Media temperature accuracy	°C	±1	±1	±1
Media temperature repeatability	°C	±0.25	±0.25	±0.25

Table 11-6 Additional error by deviations from reference conditions

Specification	Unit	Sensor size		
		DN15	DN25	DN50
Effect of process pressure	% of actual flowrate per bar	<-0.015	<-0.015	<-0.015
Effect of process pressure at nominal flowrate	(kg/h) per bar	-0.56	-1.73	-7.8
Effect of ambient temperature: Display/Frequency/Pulse/Communication output	%/K actual flowrate	< ±0.003	< ±0.003	< ±0.003
Effect of power supply fluctuations		None		
Effect of media temperature	(kg/h)/°C	±0.0875	±0.175	±1.05



## 11.3 Construction

Table 11-7 Designated use

Description	Specification
Measurement of process media	<ul style="list-style-type: none"> <li>Fluid Group 1 (suitable for dangerous fluids)</li> <li>Aggregate state: Paste/light slurry, liquid and gas</li> </ul>

Table 11-8 Function and system design

Description	Specification
Measuring principle	Coriolis
System architecture	<ul style="list-style-type: none"> <li>Point-to-point (1 Modbus RTU master - 1 transmitter slave)</li> <li>Multidrop (1 Modbus RTU master - up to 32 transmitter slaves per segment. Max 247 slaves)</li> </ul>

The FCS400 7ME4617-... is preconfigured for integration with the SITRANS FCT070.

Table 11-9 Installation torques

Description	Torque (Nm)
Pressure guard fittings	
G 1/4 inch	80
Pedestal lock screw cap	10
Cable gland to housing (Siemens supplied, metric)	10

### Note

#### NPT glands

When using NPT glands, user must take care when packing threads and installing cables that sufficient tightness is obtained to prevent ingress of moisture.

## 11.4 Sensor design

Description	Specification
Dimension and weight	See "Sensor dimensions" (Page 119)
Process connectors	<ul style="list-style-type: none"> <li>• EN1092-1 B1, PN16, PN40, PN63, PN100, PN160*</li> <li>• EN1092-1 D (gasket groove), PN40, PN63, PN100, PN160*</li> <li>• ISO 228-1 G male pipe thread</li> <li>• ASME B1.20.1 NPT male pipe thread</li> <li>• ASME B16.5, CI 150, CI 300, CI 600, CI 900</li> <li>• DIN 11851**</li> <li>• DIN 32676</li> <li>• DIN 11864-1A**, DIN 11864-2C (inch)**, DIN 11864-3A**</li> <li>• ISO 2852**</li> <li>• ISO 2853**</li> <li>• JIS B 2220, 10K, 20K, 40K, 62K</li> </ul>
Electrical connection	<ul style="list-style-type: none"> <li>• M12 connector with 4-wire cable</li> <li>• Standard cable with polymer / brass / stainless steel cable glands (metric or NPT)</li> <li>• Conduit entries (metric or NPT)</li> </ul>
<b>Material</b>	
Measuring tubes	<ul style="list-style-type: none"> <li>• AISI 316L / EN1.4404</li> </ul>
Process connectors	<ul style="list-style-type: none"> <li>• Standard:                             <ul style="list-style-type: none"> <li>– AISI 316L / EN1.4435 or EN1.4404</li> </ul> </li> <li>• Hygienic:                             <ul style="list-style-type: none"> <li>– AISI 316L / EN1.4435</li> </ul> </li> </ul>
Sensor enclosure	AISI 304 / W1.4301
DSL enclosure	Aluminum with corrosion-resistant coating
Measuring tube design	Split flow through 2 parallel tubes with combined cross-section area 50% of the nominal pipe The measuring tubes are bent in a trapezoidal curve
Measuring tube surface roughness	<ul style="list-style-type: none"> <li>• Standard: 1.6 µm</li> <li>• Hygienic: 0.8 µm</li> </ul>
Self-draining design	Yes, when mounted vertically

\*: Pressure ratings max. 100 bar

\*\* : Pressure ratings depend on process connection dimension

## 11.5 Basic electrical requirement for master system

Table 11-10 Power unit

Description	Specification
Protection class	Class I (EN60950)
Galvanic isolation primary/secondary	SELV acc. to EN 60950 and EN 50178 or equivalent
Master/Receiver	Isolation 500 VAC

## 11.6 Cables and cable entries

The following information applies to cables and cable glands supplied as accessories to the device.

Table 11-11 Power and signal cable, basic data

Description	Specification
Number of conductors	4
Square area [mm <sup>2</sup> ]	0.326 (AWG 22/7)
Screen	Common shield for all 4 conductors
Outside color	Gray (RAL 7001)
External diameter [mm]	6.5
Maximum length	600 m (1968 ft.)
Installation environment	Industrial including chemical processing plants
Insulation material	Special polyolefin
Halogen-free	Yes
RoHS compliant	Yes
Torsional strength	<ul style="list-style-type: none"> <li>&gt;3 million cycles at ± 180° on 200 mm</li> <li>Not adapted for garland mounting (festoon)</li> </ul>
Permissible temperature range [°C (°F)]	-40 to +80 (-40 to +176)
Min. bending radius allowed	Single 5 X ø

11.7 Operating conditions

Table 11-12 Cable glands and entries

Description	Specification
Glands	<ul style="list-style-type: none"> <li>• Material                             <ul style="list-style-type: none"> <li>– Nylon<sup>1)</sup></li> <li>– Brass/Ni plated</li> <li>– Stainless steel AISI 316/1.4404</li> </ul> </li> <li>• Cable cross section                             <ul style="list-style-type: none"> <li>– Ø 5 to 10 mm (0.20" to 0.39")</li> </ul> </li> </ul>
Entry	<ul style="list-style-type: none"> <li>• 1 x M20 or 1 X NPT ½" for communication</li> </ul>

<sup>1)</sup>: If operating temperature is below -20 °C (-4 °F), use Brass/Ni plated or stainless steel cable glands.

**Note**

For hygienic applications (3A & EHEDG) the cable glands and blind plugs must be made from corrosion resistant material like nickel brass, stainless steel or plastic. The exposed threads must be minimized when they are tightened up on the cable and they must have a seal (plastic or rubber) under the threads where they screw into the terminal housing or enclosure.

## 11.7 Operating conditions

Table 11-13 Basic conditions

Description	Specification
Ambient temperature (°C[°F]) Operation (Humidity max. 90 %)	-40 to +60 [-40 to +140]
Ambient temperature (°C[°F]) Storage (Humidity max. 90 %)	-40 to +70 [-40 to +158]
Climate class	DIN 60721-3-4
Altitude	Up to 2000 m (6560 ft)
Relative humidity [%]	95
EMC performance	EN/IEC 61326-1 (Industry)

Table 11-14 Cleaning and sterilizing conditions

Description	Specification
Cleaning method	<ul style="list-style-type: none"> <li>• CIP</li> <li>• SIP</li> </ul>

Table 11-15 Process media conditions

Description	Specification
Process media temperature (T <sub>s</sub> ) (min to max) [°C (F)]	
• DN15 - DN50	-50 up to +200 [-58 to 392]
Process media density (min to max) [kg/m <sup>3</sup> (lb/ft <sup>3</sup> )]	1 to 5000 (0.06 to 312)
Process media gauge max pressure [bar (psi)]	100 (1450) st. steel
Pressure drop	See Pressure drop curves (Page 118)
Pressure temperature ratings	See Pressure - temperature ratings (Page 115)

## 11.8 Process variables FC410

Description	Specification
Primary process variables	<ul style="list-style-type: none"> <li>• Mass flow</li> <li>• Density</li> <li>• Medium temperature</li> </ul>
Derived process variable	<ul style="list-style-type: none"> <li>• Volume flow</li> </ul>

## 11.9 Approvals note

### Note

#### Device-specific approvals

Always refer to nameplates on the device for device-specific approvals.

## 11.10 Certificates and approvals

SITRANS FC410/FCS400 flowmeter	
"Intrinsic safety" type of protection	
ATEX	II 1/2 G Ex db ia IIC T* Ga/Gb
Sira 11ATEX 1341 X	II 1/2 G Ex db IIC T* Ga/Gb
	1D Ex ia IIIC T*°C Da/Db
	2D Ex tb IIIC T*°C Db
	Ta = -40°C to +*°C
	* Temperature class (dependent on the maximum process temperature and the maximum ambient temperature, see Special conditions for safe use (Page 14))

11.12 Modbus Communication Specification

SITRANS FC410/FCS400 flowmeter	
cCSAus (Kanada, USA) 2508644	Ex db ia IIC T6-T3 Gb Ex tb IIIC T135°C Db Ex ia IIIC T135°C Da  Class I, II, III, Division 1, Groups A, B, C, D, E, F, G Class I, Zone 1, AEx db ia IIC T6-T3 Gb Zone 21, AEx tb IIIC T135°C Db Zone 20, AEx ia IIIC T135°C Da
Hygienic version	<ul style="list-style-type: none"> <li>• 3A</li> <li>• EHEDG</li> <li>• 1935/2004/EC and 2023/2006/EC (food contact material: stainless steel)</li> </ul>

See also

Certificates (<http://www.siemens.com/processinstrumentation/certificates>)

11.11 SensorFlash

Table 11-16 SensorFlash

Description	Specification
	Micro SD card
Capacity	4 GB
File system support	FAT32 / 8.3
Temperature range	
Operation:	-40 to +85 °C (-40 to 185 °F)
Storage:	-40 to +100 °C (-40 to 212 °F)

11.12 Modbus Communication Specification

Table 11-17 Modbus communication specification

Description	Specification
Device type	Slave
Baud rates	<ul style="list-style-type: none"> <li>• 9600</li> <li>• 19 200 (Factory setting FC410)</li> <li>• 38 400</li> <li>• 57 600</li> <li>• 76 800</li> <li>• 115 200 (Factory setting FCS400/FCT070)</li> </ul>

Description	Specification
Number of stations	Max. 31 per segment without repeaters
Device address range	1 to 247
Protocol	Modbus RTU
Electrical interface	RS-485, 2-wire
Connector type	M12 or cable termination
Supported function codes	<ul style="list-style-type: none"> <li>• 3: read holding registers</li> <li>• 16: write multiple registers</li> <li>• 8: diagnostics</li> </ul>
Broadcast	No <sup>1)</sup>
Maximum cable length [m]	600 meters (@ 115 200 bits/sec)
Standard	Modbus over serial line v 1.0 <sup>2)</sup>
Certification	one
Device Profile	None

<sup>1)</sup>: Standard restriction. The standard requires a LED indicator for visual diagnosis. This device does not support a LED indicator. This device does not react to any Broadcast commands.

<sup>2)</sup>: According to the Specification & Implementation guide v. 1.0 available at the Modbus Organization website

#### Note

##### Storage location

All Modbus settings of the device are stored in a non-volatile memory.

## 11.13 PED

The pressure equipment directive 2014/68/EU applies to the alignment of the statutory orders of the European member states for pressure equipment. Such equipment in the sense of the directive includes vessels, pipelines and accessories with a maximum allowable pressure of more than 0.5 bar above atmospheric. Flowmeters are considered as piping.

A detailed risk analysis of the flowmeter has been performed in accordance with the PED 2014/68/EU. All risks are assessed to be "none" provided that the procedures and standards referenced in these operating instructions are observed.

### Division according to the danger potential

Flowmeters which are categorized as piping are divided into categories according to danger potential (medium, pressure, nominal diameter). The flowmeters fall into the categories I to III or they are manufactured according to Paragraph 3 - Sound Engineering Practice (SEP).

The following criteria are decisive for assessment of the danger potential and are also shown in Diagrams 1 to 4, see Diagrams (Page 111).





Fluid group	Group 1 or 2
<ul style="list-style-type: none"> <li>Aggregate state</li> </ul>	Liquid or gaseous
<ul style="list-style-type: none"> <li>Type of pressurized equipment                             <ul style="list-style-type: none"> <li>– Pipeline</li> </ul> </li> </ul>	Product of pressure and volume (PS * V [barL])

The maximum allowable temperature for the used liquids or gases is the maximum process temperature which can occur, as defined by the user. This must be within the limits defined for the equipment.




### Division of media (liquid/gaseous) into the fluid groups

Fluids are divided according to Article 13 into the following fluid groups:

#### Group 1 fluids

<p><b>Explosive</b> R phrases: for example: 2, 3 (1, 4, 5, 6, 9, 16, 18, 19, 44)</p> 	<p><b>Very toxic</b> R phrases: for example: 26, 27, 28, 39 (32)</p> 
<p><b>Extremely flammable</b> R phrases: for example: 12 (17)</p> 	<p><b>Toxic</b> R phrases: for example: 23, 24, 25 (29, 31)</p> 



<p><b>Highly flammable</b> R phrases: for example: 11, 15, 17 (10, 30)</p> 	<p><b>Oxidizing</b> R phrases: for example: 7, 8, 9 (14, 15, 19)</p> 
<p><b>Flammable</b> R phrases: for example 11 (10)</p> 	

### Group 2 fluids

All fluids not belonging to Group 1.

Also applies to fluids which are for example dangerous to the environment, corrosive, dangerous to health, irritant or carcinogenic (if not highly toxic).

### Conformity assessment

Flowmeters of categories I to III comply with the safety requirements of the directive. They are affixed with the CE mark and an EC declaration of conformity is provided.

The flowmeters are subjected to the conformity assessment procedure - Module H.

Flowmeters according to Article 4 Paragraph 3 are designed and manufactured in accordance with sound engineering practice. PED conformity reference is not affixed to the CE mark.

Diagrams

**Gases of fluid group 1**

- Pipelines according to Article 4 (a) (i) First dash
- Exception: unstable gases belonging to Categories I and II must be included in Category III.




Figure 11-1 Diagram 1

**Gases of fluid group 2**

- Pipelines according to Article 4 (a) (i) Second dash
- Exception: liquids at temperatures > 350 °C belonging to Category II must be included in Category III.




Figure 11-2 Diagram 2

### Liquids of fluid group 1

- Pipelines according to Article 4 (a) (ii) First dash




Figure 11-3 Diagram 3

### Liquids of fluid group 2

- Pipelines according to Article 4 (a) (ii) Second dash




Figure 11-4 Diagram 4

## 11.14 Pressure - temperature ratings

Pressure - temperature ratings are determined by process connection material and applicable standards. The tables below detail the allowed maximum process pressure for sensor variants with stainless steel measuring tubes.

With two major exceptions, the pressure rating of the flow sensors is independent of the process medium temperature. Design rules for flange connections in both the EN1092-1 and ASME B16.5 standards dictate pressure derating with increasing temperature. The charts below show the effect of process medium temperature on the pressure ratings for the flanges within the product program.

11.14 Pressure - temperature ratings

**Note**

**Maximum sensor operating pressure**

The maximum sensor operating pressure is limited to 100 bar.

**11.14.1 Stainless steel sensors**

Table 11-18 EN1092-1 [bar]

PN (bar)	Temperature TS (°C)					
	-50	0	50	100	150	180
16	16.0	16.0	16.0	15.2	13.7	13.1
40	40.0	40.0	40.0	37.9	34.5	32.9
63	63.0	63.0	63.0	59.7	54.3	51.8
100	100.0	100.0	100.0	94.8	86.1	82.1
160	100 (see Note "Maximum sensor operating pressure")					

Table 11-19 ISO228-G and ASME B1.20.1 NPT [bar]

PN (bar)	Temperature TS (°C)					
	-50	0	50	100	150	200
110	100 (see Note "Maximum sensor operating pressure")					

Table 11-20 ASME B16.5 [bar]

Class / Group	Temperature TS (°C)					
	-50	0	50	100	150	200
150 / 2.2	19	19	18.4	16.2	14.8	13.7
300 / 2.2	49.6	49.6	48.1	42.2	38.5	35.7
600 / 2.2	99.3	99.3	96.2	84.4	77.0	71.3
900 / 2.2	100 (see Note "Maximum sensor operating pressure")					

Table 11-21 JIS [bar]

PN (bar)	Temperature TS (°C)					
	-50	0	50	120	150	200
10K	14	14	14	14	13.4	12.4
20K	34	34	34	34	33.1	31.6

PN (bar)	Temperature TS (°C)					
	-50	0	50	120	150	200
40K	68	68	68	68	66.2	63.2
63K	100	100	100	100	100	99

Table 11-22 DIN 11851 [bar]

PN (bar) / DN	Temperature TS (°C)				
	-50	0	50	100	140
25 / 50-100	25	25	25	25	25
40 / 10-40	40	40	40	40	40

Table 11-23 DIN 32676 & ISO 2852 [bar]

PN (bar) / DN	Temperature TS (°C)				
	-50	0	50	100	140
10 / 85-219.1	10	10	10	10	10
16 / 48.3-76.2	16	16	16	16	16
25 / 6.35-42.4	25	25	25	25	25

Table 11-24 ISO 2853 [bar]

PN (bar) / DN	Temperature TS (°C)				
	-50	0	50	100	140
25 / 50-100	25	25	25	25	25
40 / 10-40	40	40	40	40	40

Table 11-25 DIN 11864-1 [bar]

DN	Temperature TS (°C)				
	-50	0	50	100	140
50-80	25	25	25	25	25
15-25	40	40	40	40	40

Table 11-26 DIN 11864-2 [bar]

DN	Temperature TS (°C)				
	-50	0	50	100	140
50-80	16	16	16	16	16
15-25	25	25	25	25	25

11.14 Pressure - temperature ratings

Table 11-27 DIN 11864-3 [bar]

DN	Temperature TS (°C)				
	-50	0	50	100	140
80	16	16	16	16	16
50	25	25	25	25	25
15-25	40	40	40	40	40

Table 11-28 Swagelok SS-12-VCO-3 socket weld with SS-12-VCO-4 nut [bar]

PN (bar)	Temperature TS (°C)					
	-50	0	50	100	150	200
100	100.0	100.0	100.0	100.0	100.0	100.0

**Note**

**Test pressure**

Maximum allowable test pressure (MATP) for the flowmeter and process connection is 1.5 times the nominal pressure up to 150 bar (2176 psi).

**11.14.2 Pressure drop curves**

The pressure drop is dimension-dependent and influenced by process media viscosity and density. Sensors with undersized process connections experience higher pressure drop due to reduction in inlet/outlet dimensions.

**Note**

**Pressure drop information**

Pressure drop information is available on request.

## Dimension drawings

### 12.1 Sensor dimensions




Table 12-1 Basic dimensions

Sensor DN	A in mm (inch)	B in mm (inch)	C in mm (inch)	Weight in kg (lb)
15 (½")	90 (3.54)	280 (11.0)	90 (3.54)	4.6 (10.1)
25 (1")	123 (4.84)	315 (12.4)	90 (3.54)	7.9 (17.4)
50 (2")	187 (7.36)	390 (15.4)	90 (3.54)	25.7 (56.7)

**Note**

The build in length (D) depends on the process connector.

## 12.2 316L stainless steel - standard & hygienic

Table 12-2 Sensor sizes DN15, DN25 and DN50

Sensor	DN15 (½")					DN25 (1")			DN50 (2")	
	DN6 (¼")	DN10 (⅜")	DN15 (½")	DN20 (¾")	DN25 (1")	DN25 (1")	DN32 (1¼")	DN40 (1½")	DN40 (1½")	DN50 (2")
EN1092-1 B1, PN16			265 (10.4)		265 (10.4)	360 (14.2)		365 (14.4)	610 (24.0)	610 (24.0)
EN1092-1 B1, PN40			265 (10.4)		265 (10.4)	360 (14.2)		365 (14.4)	610 (24.0)	610 (24.0)
EN1092-1 B1, PN63			265 (10.4)			360 (14.2)			610 (24.0)	610 (24.0)
EN1092-1 B1, PN100			270 (10.6)		275 (10.8)	360 (14.2)		365 (14.4)	610 (24.0)	610 (24.0)
EN1092-1 B1, PN160			270 (10.6)			360 (14.2)				620 (24.4)
EN1092-1 D, PN40			265 (10.4)			360 (14.2)			610 (24.0)	610 (24.0)
EN1092-1 D, PN63			265 (10.4)			360 (14.2)			610 (24.0)	610 (24.0)
EN1092-1 D, PN100			270 (10.6)			360 (14.2)			610 (24.0)	610 (24.0)
EN1092-1 D, PN160			270 (10.6)			360 (14.2)				620 (24.4)
ANSI B16.5, Class 150			270 (10.6)	270 (10.6)		360 (14.2)		365 (14.4)		620 (24.4)
ANSI B16.5, Class 300			270 (10.6)	270 (10.6)		360 (14.2)		380 (15.0)		620 (24.4)
ANSI B16.5, Class 600			270 (10.6)	285 (11.2)		360 (14.2)		380 (15.0)		620 (24.4)
ANSI B16.5, Class 900			290 (11.4)			385 (15.2)				620 (24.4)
ISO 228-1 G male pipe thread	265 (10.4)		265 (10.4)			365 (14.4)				620 (24.4)
ANSI B1.20.1 NPT male pipe thread	265 (10.4)		270 (10.6)			365 (14.4)				620 (24.4)
DIN 11851 Hygienic screwed <sup>1)</sup>		265 (10.4)	265 (10.4)		270 (10.6)	360 (14.2)	360 (14.2)		610 (24.0)	610 (24.0)
DIN 32676-C Hygienic clamp <sup>1)</sup>			265 (10.4)	265 (10.4)		360 (14.2)		360 (14.2)		610 (24.0)
DIN 11864-1 Aseptic screwed <sup>1)</sup>			265 (10.4)			360 (14.2)			610 (24.0)	610 (24.0)



Sensor	DN15 (½")					DN25 (1")			DN50 (2")	
	DN6 (⅛")	DN10 (⅜")	DN15 (½")	DN20 (¾")	DN25 (1")	DN25 (1")	DN32 (1¼")	DN40 (1½")	DN40 (1½")	DN50 (2")
DIN 11864-2A Aseptic flanged <sup>1)</sup>			265 (10.4)			360 (14.2)			620 (24.4)	610 (24.0)
DIN 11864-3A Aseptic clamp <sup>1)</sup>			265 (10.4)			360 (14.2)			610 (24.0)	610 (24.0)
ISO 2852 Hygienic clamp <sup>1)</sup>					265 (10.4)	360 (14.2)		360 (14.2)	610 (24.0)	610 (24.0)
ISO 2853 Hygienic screwed <sup>1)</sup>					265 (10.4)	360 (14.2)		360 (14.2)	630 (24.8)	610 (24.0)
SMS 1145 Hygienic screwed					265 (10.4)	360 (14.2)			610 (24.0)	610 (24.0)
12-VCO-4 Quick connect			285 (11.2)							
JIS B2220 10K			265 (10.4)			360 (14.2)			620 (24.4)	610 (24.0)
JIS B2220 20K			265 (10.4)			360 (14.2)			620 (24.4)	610 (24.0)
JIS B2220 40K			270 (10.6)			360 (14.2)			620 (24.4)	610 (24.0)
JIS B2220 63K			275 (10.8)			370 (14.6)				620 (24.4)

Dimensions in mm (inch)

<sup>1)</sup> Available with 3A and EHEDG certification.

#### Note

#### 3A

DIN 11851 and ISO 2853 are only 3A-approved if self-centering gaskets are used.

## 12.3 316L stainless steel - NAMUR

Table 12-3 Sensor sizes DN15, DN25 and DN50

Sensor	DN15 (½")					DN25 (1")			DN50 (2")	
	DN6 (⅛")	DN10 (⅜")	DN15 (½")	DN20 (¾")	DN25 (1")	DN25 (1")	DN32 (1¼")	DN40 (1½")	DN40 (1½")	DN50 (2")
EN1092-1 B1, PN40			510 (20.1)		510 (20.1)	600 (23.6)		605 (23.8)	715 (28.1)	715 (28.1)

Dimensions in mm (inch)

## 12.4 316L stainless steel - Hygienic versions

Table 12-4 Sensor sizes DN15, DN25 and DN50

Sensor	DN15 (½")				DN25 (1")			DN50 (2")	
	DN10 (3.8")	DN15 (½")	DN20 (¾")	DN25 (1")	DN25 (1")	DN32 (1¼")	DN40 (1½")	DN40 (1½")	DN50 (2")
DIN 11851 Hygienic screwed	265 (10.4)	265 (10.4)		270 (10.6)	360 (14.2)	360 (14.2)		610 (24.0)	610 (24.0)
DIN 32676-C Hygienic clamp		265 (10.4)	265 (10.4)		360 (14.2)		360 (14.2)		610 (24.0)
DIN 11864-1 Aseptic screwed		265 (10.4)			360 (14.2)			610 (24.0)	610 (24.0)
DIN 11864-2A Aseptic flanged		265 (10.4)			360 (14.2)			620 (24.4)	610 (24.0)
DIN 11864-3A Aseptic clamp		265 (10.4)			360 (14.2)			610 (24.0)	610 (24.0)
ISO 2852 Hygienic clamp				265 (10.4)	360 (14.2)		360 (14.2)	610 (24.0)	610 (24.0)
ISO 2853 Hygienic screwed				265 (10.4)	360 (14.2)		360 (14.2)	630 (24.8)	610 (24.0)
SMS 1145 Hygienic screwed				265 (10.4)	360 (14.2)			610 (24.0)	610 (24.0)

Dimensions in mm (inch)

**Note****3A**

DIN 11851 and ISO 2853 are only 3A-approved if self-centering gaskets are used.

# Product documentation and support

## A.1 Product documentation

Process instrumentation product documentation is available in the following formats:

- Certificates (<http://www.siemens.com/processinstrumentation/certificates>)
- Downloads (firmware, EDDs, software) (<http://www.siemens.com/processinstrumentation/downloads>)
- Catalog and catalog sheets (<http://www.siemens.com/processinstrumentation/catalogs>)
- Manuals (<http://www.siemens.com/processinstrumentation/documentation>)  
You have the option to show, open, save, or configure the manual.
  - "Display": Open the manual in HTML5 format
  - "Configure": Register and configure the documentation specific to your plant
  - "Download": Open or save the manual in PDF format
  - "Download as html5, only PC": Open or save the manual in the HTML5 view on your PC

You can also find manuals with the Mobile app at Industry Online Support (<https://support.industry.siemens.com/cs/ww/en/sc/2067>). Download the app to your mobile device and scan the device QR code.

### Product documentation by serial number

Using the PIA Life Cycle Portal, you can access the serial number-specific product information including technical specifications, spare parts, calibration data, or factory certificates.

#### Entering a serial number

1. Open the PIA Life Cycle Portal (<https://www.pia-portal.automation.siemens.com>).
2. Select the desired language.
3. Enter the serial number of your device. The product documentation relevant for your device is displayed and can be downloaded.

To display factory certificates, if available, log in to the PIA Life Cycle Portal using your login or register.

#### Scanning a QR code

1. Scan the QR code on your device with a mobile device.
2. Click "PIA Portal".

To display factory certificates, if available, log in to the PIA Life Cycle Portal using your login or register.

Certification documents including calibration report are supplied with each sensor included on the SensorFlash. Material, pressure test, and factory conformance certificates are optional at ordering.

---

**Note**

**EAC declaration**

The EAC declaration is available on the SensorFlash SD card delivered with the device.

---

## A.2 Technical support

### Technical support

If this documentation does not completely answer your technical questions, you can enter a Support Request (<http://www.siemens.com/automation/support-request>).

Additional information on our technical support can be found at Technical Support (<http://www.siemens.com/automation/csi/service>).

### Service & support on the Internet

In addition to our technical support, Siemens offers comprehensive online services at Service & Support (<http://www.siemens.com/automation/serviceandsupport>).

### Contact

If you have further questions about the device, contact your local Siemens representative at Personal Contact (<http://www.automation.siemens.com/partner>).

To find the contact for your product, go to "all products and branches" and select "Products & Services > Industrial automation > Process instrumentation".

Contact address for business unit:

Siemens AG  
Digital Industries  
Process Automation  
Östliche Rheinbrückenstr. 50  
76187 Karlsruhe, Germany

## Technical reference


### B.1 Theory of operation

#### The Coriolis principle of measurement

The flow measurement is based on the Coriolis law of motion. Particles moving in a rotating / oscillating system will resist imposed oscillations in a manner consistent with their mass and velocity (momentum).

The SITRANS F C sensors are energized by an electromagnetic driver circuit which oscillates the pipes at their resonant frequency. Two pickups are placed symmetrically on either side of the driver to provide position signals for digital processing.

When the media flows through the sensor, Coriolis force will act on the measuring tubes and cause deflection which can be measured as a phase shift between Pickup 1 and Pickup 2. The phase shift is proportional to the mass flowrate.



The frequency (or period) of the vibration is a direct function of the process media density.

The frequency and amplitude of the driver is regulated to ensure a stable output from the 2 pickups. The temperature of the sensor tubes is measured to provide accurate compensation for changes in the material stiffness. As a result the process media temperature is also accurately measured.

The flow proportional phase signal from the pickups, the temperature measurement and the driver frequency enable calculation and reporting of mass, density, volume, and temperature.

### Digital signal processing (DSP)

The analog to digital conversion takes place in an ultra low noise sigma delta converter with high signal resolution. With fast digital signal processing mass flow and density values are calculated using a patented DFT technology (Discrete Fourier Transformation). The combination of this patented DFT technology and the fast DSP enables short response time (< 10 ms) to changes in the measured values.

The built-in noise filter is configurable and can be used for improving the performance of the flowmeter, in case the installation and application conditions are not ideal. Typical process noise such as gas bubbles (two-phase-flow) can be reduced through the filter functions.

## B.2 Sensor dimension dependent default settings

### B.2.1 Mass flow

#### FCS400

Sensor size	Default value kg/s
<b>Upper alarm limit and Upper warning limit</b>	
DN 15	2.209
DN 25	6.136
DN 50	24.54
<b>Lower alarm limit and Lower warning limit</b>	
DN 15	-2.209
DN 25	-6.136
DN 50	-24.54

Sensor size	Default value kg/s	Default value kg/h
<b>Low flow cut-off</b>		
DN 15	0.0103	37.08
DN 25	0.0319	114.84
DN 50	0.1444	519.84

## B.2.2 Volume flow

### FCS400

Sensor size	Default value m <sup>3</sup> /s
<b>Upper alarm limit and Upper warning limit</b>	
DN 15	0.0225
DN 25	0.0626
DN 50	0.250
<b>Lower alarm limit and Lower warning limit</b>	
DN 15	-0.0225
DN 25	-0.0626
DN 50	-0.250

Sensor size	Default value m <sup>3</sup> /s	Default value m <sup>3</sup> /h
<b>Low flow cut-off</b>		
DN 15	0.000010278	0.037
DN 25	0.000031944	0.115
DN 50	0.000144444	0.52

## B.2.3 Standard volume flow

### FCS400

Sensor size	Default value m <sup>3</sup> /s
<b>Upper alarm limit and Upper warning limit</b>	
DN 15	0.0225
DN 25	0.0626
DN 50	0.250
<b>Lower alarm limit and Lower warning limit</b>	
DN 15	-0.0225
DN 25	-0.0626
DN 50	-0.250

Sensor size	Default value m <sup>3</sup> /s	Default value m <sup>3</sup> /h
<b>Low flow cut-off</b>		
DN 15	0.000010278	0.037
DN 25	0.000031944	0.115
DN 50	0.000144444	0.52

## B.2.4 Fraction

### FCS400

Sensor size	Unit	Default value
<b>Upper alarm limit and Upper warning limit</b>		
DN 15	Mass flow kg/s	2.209
	Volume flow m <sup>3</sup> /s	0.0225
DN 25	Mass flow kg/s	6.136
	Volume flow m <sup>3</sup> /s	0.0626
DN 50	Mass flow kg/s	24.54
	Volume flow m <sup>3</sup> /s	0.250
<b>Lower alarm limit and Lower warning limit</b>		
DN 15	Mass flow kg/s	-2.209
	Volume flow m <sup>3</sup> /s	-0.0225
DN 25	Mass flow kg/s	-6.136
	Volume flow m <sup>3</sup> /s	-0.0626
DN 50	Mass flow kg/s	-24.54
	Volume flow m <sup>3</sup> /s	-0.250

## B.2.5 Zero point adjustment

### FCS400

Sensor size	Default value kg/s	Default value kg/h
<b>Standard deviation limit</b>		
DN 15	0.0004	1.44
DN 25	0.004	14.4
DN 50	0.015	54

Sensor size	Default value kg/s	Default value kg/h
<b>Zero offset limit</b>		
DN 15	0.0103	37.08
DN 25	0.0319	114.84
DN 50	0.1444	519.84

Sensor size	Default value kg/s	Default value kg/h
<b>Low flow cut-off</b>		
DN 15	0.0103	37.08



Sensor size	Default value kg/s	Default value kg/h
DN 25	0.0319	114.84
DN 50	0.1444	519.84

### B.3 Exception handling

There is a defined set of exception codes to be returned by slaves in the event of problems. All exceptions are signalled in the response from the slave by adding 80 hex to the function code of the request and following this byte by an exception code.

Table B-1 Exception codes

Exception code (dec)	Exception text	Description
01	Illegal function	The function code received in the query is not an allowable action for the slave
02	Illegal data address	The data address received in the query is not an allowable address for the slave.
03	Illegal data value	A value contained in the query data field is not an allowable value for the addressed location. This may indicate a fault in the structure of the remainder of a complex request, such that the implied length is incorrect or the number of registers is too high.
04	Slave device failure	The request is for some other reason not acceptable. It may e.g. indicate that the data value to write is evaluated to be beyond limits.

### B.4 Float definition

Stuffing of multi-byte numbers into multiple Modbus RTU registers differs among Modbus devices. "Big Endian" and "Little Endian" describe the order or sequence in which multi-byte data is stored in memory. This device uses (IEEE 741) a "Big-Endian" representation for addresses and data items as default. This means that when a numerical quantity larger than a single byte is transmitted, the MOST significant byte is sent first.

Float transmission order can be changed as described in Float transmission (Page 80).

Following example describes the Big-Endian representing of float IEEE741.

Value (decimal)	IEEE FP B MSB LSB	Register N		Register N + 1	
		high	low	high	low
100.0	42C80000h	42h	C8h	00h	00h
55.32	425D47AEh	42h	5Dh	47h	AEh
2.0	40000000h	40h	00h	00h	00h
1.0	3F800000h	3Fh	80h	00h	00h
-1.0	BF800000h	bFh	80h	00h	00h

B.4 Float definition

**Read absolute massflow (4.03001)**

Query: 01,03,0B,B8,00,02,46,0A

Response: 01,03,04,40,C3,52,93,62,C8

Absolute mass- 6.10383 kg/s  
flow =

# Modbus communication FC410

## C.1 Modbus addressing model

The device allows read/write access to the following standard Modbus RTU data holding register blocks:

- Holding registers (ref. 4x address range)

The minimum value of a writable **holding register** can be read by adding 10000 to the Modbus address of the register.

The maximum value of a writable **holding register** can be read by adding 20000 to the Modbus address of the register.

The default value of a writable **holding register** can be read by adding 30000 to the Modbus address of the register.

## C.2 Modbus function codes

This device supports following function codes: 3, 8 and 16.

Function codes 3 and 16 are used for accessing registers, max. 16 registers per read/write request is accepted.

Function code 8 is used for reading Modbus communication diagnostic information.

Below the various function code are described.

### Function code 3 (Read holding registers)

#### General exceptions:

- Requesting less than 1 or more than 16 registers => Exception 3 (Illegal data value)
- Requesting invalid start address or start address with invalid quantity => Exception 2 (Illegal data address)

#### Application exceptions:

- Application errors; min/max limit of parameter exceeded; or parameter write-protected => Exception 4 (Slave device error)

#### Holes/register alignment:

- The read command always returns data if no exception is given.
- Holes in the holding register map return value zero in all bytes. E.g. reading 2 registers starting at 4:0004 above will result in 2 bytes of "float B" followed by 2 zeroes.

**Function code 3 example****Query**

Slave address	1 byte
Function	1 byte
Starting Address Hi	1 byte
Starting Address Lo	1 byte
Quantity of Registers Hi	1 byte
Quantity of Registers Lo	1 byte
CRC	2 bytes

**Response**

Slave address	1 byte
Function	1 byte
Byte count	1 byte
Register Value Hi	1 byte
Register Value Lo	1 byte
:	:
Register Value Hi	1 byte
Register Value Lo	1 byte
CRC	2 bytes

**Example: Read absolute massflow (address 3000)****Query:** 1,3,11,184,0,2,70,10

Slave address = 1 (0x01)

Function = 3 (0x03)

Starting Address Hi, Lo = 11, 184 (0x0B,0xB8)

Quantity of Registers Hi , Lo = 0, 2 (0x00,0x02)

CRC = 70,10 (0x46, 0x0A)

Starting address 0x0BB8 = 3000

Quantity of registers = 0x0002 = 2

**Response:** 1,3,4,64,195,82,139,98,200

Slave address = 1 (0x01)

Function = 3 (0x03)

Byte Count = 4 (0x04)

Register 1 - Register Value Hi, Lo = 64, 195 (0x40, 0xC3)

Register 2 - Register Value Hi, Lo = 82, 139 (0x52, 0x93)

CRC = 98,200 (0x62, 0xC8)

Absolute mass flow = 0x40C35293 = 6.10383 kg/sec

## Function code 16 (Write multiple registers)

### General exceptions

- Writing less than 1 or more than 16 registers => Exception 3 (Illegal data value)
- If ByteCount is not exactly 2 times NoOfRegisters => Exception 3 (Illegal data value)
- Requesting invalid start address or start address with invalid quantity => Exception 2 (Illegal data address)

### Application exceptions:

- Application errors; min/max limit of parameter exceeded; or parameter write-protected => Exception 4 (Slave device error)
- Application errors include writing to ReadOnly holding registers

### Holes/register alignment:

- If start-address is not the start of a mapped holding register => Exception 2 (Illegal data address)
- Writing to holes is allowed (ie ignored - and no exception occurs) - except for the condition described above
- If the end address is only part of a mapped holding register item (e.g. one half of a float value), the action depends on the data type. Writing parts of all data types => Exception 4 (Slave device error)

## Function code 16 example

### Query

Slave address	1 byte
Function	1 byte
Starting Address Hi	1 byte
Starting Address Lo	1 byte
Quantity of Registers Hi	1 byte
Quantity of Registers Lo	1 byte
Byte Count	1 byte
Registers Value Hi	1 byte
Registers Value Lo	1 byte
:	:
Registers Value Hi	1 byte
Registers Value Lo	1 byte
CRC	2 bytes

### Response

Slave address	1 byte
Function	1 byte
Starting Address Hi	1 byte

C.2 Modbus function codes

Starting Address Lo	1 byte
Quantity of Registers Hi	1 byte
Quantity of Registers Lo	1 byte
CRC	2 bytes

**Example: Set baud rate to 115200 baud (address 529)**

**Query:** 1,16,2,17,0,1,2,0,5,70,210

Slave address = 1 (0x01)  
 Function = 16 (0x10)  
 Starting Address Hi, Lo = 2, 17 (0x02,0x11)  
 Quantity of Registers Hi, Lo = 0, 1 (0x00,0x01)  
 Byte Count = 2 (0x02)  
 Registers Value Hi, Lo = 0, 5 (0x00,0x05)  
 CRC = 70,10 (0x46, 0x0A)

Starting address 0x0211 = 529  
 Number of registers = 0x0001 = 1  
 Data 0x0005 = (115200 = value 5)

**Response:** 1,16,2,17,0,1,80,116

Slave address = 1 (0x01)  
 Function = 16 (0x10)  
 Starting Address Hi, Lo = 2, 17 (0x02,0x11)  
 Quantity of Registers Hi, Lo = 0, 1 (0x00,0x01)  
 CRC = 80,116 (0x50, 0x74)

**Function code 8 (Diagnostics)**

Modbus function code 8 provides a series of tests for checking the communication system between a client (Master) device and a server (Slave).

The following diagnostics functions are supported:

Sub-function code (Dec)	Name	Description
00	Return Query Data	The data passed in the request data field is to be returned (looped back) in the response.
10	Clear Counters and Diagnostic Register	Clears all counters and the diagnostic register. Counters are also cleared upon power-up.
11	Return Bus Message Count	The response data field returns the quantity of messages that the remote device has detected on the communications system since its last restart, clear counters execution, or power-up.
12	Return Bus Communication Error Count	The response data field returns the quantity of CRC errors encountered by the remote device since its last restart, clear counters execution, or power-up.

Sub-function code (Dec)	Name	Description
13	Return Bus Exception Error Count	The response data field returns the quantity of MODBUS exception responses returned by the remote device since its last restart, clear counters execution, or power-up.
14	Return Slave Message Count	The response data field returns the quantity of messages broadcast or addressed to the remote device that the remote device has processed since its last restart, clear counters execution, or power-up.
15	Return Slave No Response Count	The response data field returns the quantity of messages addressed to the remote device for which it has returned no response (neither a normal response nor an exception response), since its last restart, clear counters execution, or power-up.
16	Return Slave NAK Count	The response data field returns the quantity of messages addressed to the remote device for which it returned a Negative Acknowledge (NAK) exception response, since its last restart, clear counters execution, or power-up.
17	Return Slave Busy Count	The response data field returns the quantity of messages addressed to the remote device for which it returned a Slave Device Busy exception response, since its last restart, clear counters execution, or power-up.
18	Return Bus Character Overrun Count	The response data field returns the quantity of messages addressed to the remote device that it could not handle due to a character overrun condition, since its last restart, clear counters execution, or power-up.
20	Clear Overrun Counter and Flag	Clears the overrun error counter and resets the error flag.

## Function code 8 example

### Query

Slave address	1 byte
Function	1 byte
Sub-function Hi	1 byte
Sub-function Lo	1 byte
Data Hi	1 byte
Data Lo	1 byte
:	:
Data Hi	1 byte
Data Lo	1 byte
CRC	2 bytes

### Response

Slave address	1 byte
Function	1 byte

C.3 Changing Modbus communication settings

Sub-function Hi	1 byte
Sub-function Lo	1 byte
Data Hi	1 byte
Data Lo	1 byte
:	:
Data Hi	1 byte
Data Lo	1 byte
CRC	2 bytes

**Example: Read Return Slave Message Count (address 529)**

**Query:** 1,8,0,14,0,0,129,200

Slave address = 1 (0x01)  
 Function = 8 (0x08)  
 Sub-function Hi, Lo = 0, 14 (0x00,0x0E)  
 Data Hi, Lo = 0, 0 (0x00,0x00)  
 CRC = 129,200 (0x81, 0xC8)

Sub-function 0x000E = 14 = Read Return Slave Message Count

**Response:** 1,8,0,14,0,97,64,32

Slave address = 1 (0x01)  
 Function = 8 (0x08)  
 Sub-function Hi, Lo = 0, 14 (0x00,0x0E)  
 Data Hi, Lo = 0, 97 (0x00,0x65)  
 CRC = 64,32 (0x41, 0xE3)

Read Return Slave Message Count = 0x0065 = 97 message received

### C.3 Changing Modbus communication settings

Changing communication parameters, for example **Baud Rate, Modbus Parity Framing or Bus Address** effects the Modbus communication as follows:

- The new settings have effect only after a reset, either by restarting the device or writing the value 1 to Modbus address 600 **Restart communication**.
- The new settings will not have effect until the Modbus driver has responded to any ongoing Modbus request.

<b>NOTICE</b>
<b>Setting addresses in a multidrop network</b>
It is recommended NOT to use the default address in a multi-drop network. When setting device addresses, make sure that each device has a unique address. Replication of addresses may cause abnormal behavior of the entire serial bus and make the master unable to communicate with all slaves on the bus.



## C.4 Modbus holding registers tables

In the following the Modbus RTU holding registers available for the device are described.

---

**Note**

All Write parameters require password access.

---

Table C-1 Process values

Modbus address	Data type / Size [bytes]	Parameter	Description	Default value [unit]	Value range	Access level
3000	float / 4	Mass flow	Measured mass flow	- [kg/s]	-	Read Only
3002	float / 4	Volume flow	Measured volume flow	- [m <sup>3</sup> /s]	-	Read Only
3004	float / 4	Density	Measured density	- [kg/m <sup>3</sup> ]	-	Read Only
3010	float / 4	Media temperature	Measured temperature of the process media	- [°C]	-	Read Only
3023	float / 4	Frame Temperature	Measured temperature of the sensor frame <sup>(1)</sup>	- [°C]	-	Read Only

(1) Only available if the sensor has frame temperature measurement

C.4 Modbus holding registers tables

Table C-2 Units for Process values and totalizer

Modbus address	Data type / Size [bytes]	Parameter	Description	Default value [unit]	Value range	Access level
7400	unsigned / 2	Mass flow unit	Select unit for mass flow process value	73: kilograms per second [Kg/s]	70: grams per second 71: grams per min 72: grams per hour 73: kilograms per second 74: kilograms per minute 75: kilograms per hour 76: kilograms per day 77: metric tons per minute 78: metric tons per hour 79: metric tons per day 80: pounds per second 81: pounds per minute 82: pounds per hour 83: pounds per day 84: short tons per minute 85: short tons per hour 86: short tons per day 87: long ton per hour 88: long ton per day 253: customized unit	Read / Write

Modbus address	Data type / Size [bytes]	Parameter	Description	Default value [unit]	Value range	Access level
7500	unsigned / 2	Volume flow unit	Select unit for volume flow process value	28: cubic meters per second [m <sup>3</sup> /s]	15: cubic feet per minute 16: US gallons per minute 17: liters per minute 18: imperial gallons per minute 19: cubic meters per hour 22: US gallons per second 23: million US gallons per day 24: liters per second 25: million liters per day 26: cubic feet per second 27: cubic feet per day 28: cubic meters per second 29: cubic meters per day 30: imperial gallons per hour 31: imperial gallons per day 130: cubic feet per hour 131: cubic meters per minute 132: barrels (= 42 US gallons) per second 133: barrels (= 42 US gallons) per minute	Read / Write

C.4 Modbus holding registers tables

Modbus address	Data type / Size [bytes]	Parameter	Description	Default value [unit]	Value range	Access level
					134: barrels (= 42 US gallons) per hour 135: barrels (= 42 US gallons) per day 136: US gallons per hour 137: imperial gallons per second 138: liters per hour 170: beer barrel per second 171: beer barrel per minute 172: beer barrel per hour 173: beer barrel per day 235: US gallons per day 253: custom volume flow unit	

Modbus address	Data type / Size [bytes]	Parameter	Description	Default value [unit]	Value range	Access level
7600	unsigned / 2	Density unit	Select unit for density process value	92: kilograms per cubic meter [kg/m <sup>3</sup> ]	91: grams per cubic centimeters 92: kilograms per cubic meter 94: pounds per cubic foot 95: grams per milliliter 96: kilograms per liter 97: grams per liter 98: pounds per cubic inch 93: pounds per gallon 99: short tons per cubic yard 146: micrograms per liter 147: micrograms per cubic meter 170: milligrams per liter 253: custom mass flow unit	Read / Write
7700	unsigned / 2	Temperature unit	Select unit for temperature process value	32: °C	32: °C 33: °F 34: °R 35: K	Read / Write
8320	unsigned / 2	Mass totalizer units	Select unit for mass totalizer value	61: kilograms [kg]	60: grams 61: kilograms 62: metric tons 63: pounds 64: short tons 65: long tons 125: ounces 253: customized unit	Read / Write

## C.4 Modbus holding registers tables

Modbus address	Data type / Size [bytes]	Parameter	Description	Default value [unit]	Value range	Access level
8456	Float / 4	Custom unit factor mass flow value	Custom unit for mass flow value, only active if customized unit is selected  Calculation is based on [kg/s]	1	0 to 60000000	Read / Write
7516	Float / 4	Custom unit factor volume flow value	Custom unit for volume flow value, only active if customized unit is selected  Calculation is based on [m <sup>3</sup> /s]	1	0 to 1000	Read / Write
8462	Float / 4	Custom unit factor density value	Custom unit for density value, only active if customized unit is selected  Calculation is based on [kg/m <sup>3</sup> ]	1	0 to 60000	Read / Write
8474	Float / 4	Custom unit factor mass totalizer	Custom unit for mass totalizer, only active if customized unit is selected  Calculation is based on [kg]	1	0 to 1000000	Read / Write

Table C-3 Identification

Modbus address	Data type / Size (bytes)	Parameter	Description	Default value (unit)	Value range	Access level
4000	String / 20	Manufacturer	Device manufacturer	Siemens	-	Read Only
4020	String / 10	Sensor Firmware Revision	Sensor firmware version	-	-	Read Only
4025	String / 16	SensorType	Sensor type. Also shown on the device nameplate	-	-	Read Only
4033	String / 20	Sensor Serial Number	Unique sensor serial number. Also shown on the device nameplate	-	-	Read Only
4095	String / 10	Sensor Hardware Revision	Sensor hardware version	-	-	Read Only
4100	String / 10	Sensor Frontend Type	Sensor hardware variant	-	-	Read Only
4121	String / 20	Sensor Order Number	Sensor order number part 1 (MLFB). Also shown on the device nameplate	-	-	Read Only
4131	String / 32	Sensor Order Number	Sensor order number part 2 (MLFB). Also shown on the device nameplate	-	-	Read Only

Modbus address	Data type / Size (bytes)	Parameter	Description	Default value (unit)	Value range	Access level
4147	String / 32	Sensor Order Number	Sensor order number part 3 (MLFB). Also shown on the device nameplate	-	-	Read Only
4164	String / 32	Long TAG	Enter a unique TAG name for the device (up to 32 characters)			
4180	String / 16	Descriptor	Enter a unique description for the measurement point (up to 16 characters)			
4188	String / 16	Startup Date	Enter the installation date of the device			

Table C-4 Operating conditions

Modbus address	Data type / Size [bytes]	Parameter	Description	Default value [unit]	Value range	Access level
2100	Unsigned / 2	Flow Direction	Define positive and negative flow direction. Default positive flow direction is indicated by the arrow on the sensor. Possible selections: <ul style="list-style-type: none"> <li>0: Negative: The flow is measured '+' in default negative direction and '-' in default positive direction.</li> <li>1: Positive: The flow is measured '+' in default positive direction and '-' in default negative direction</li> </ul>	1	0 to 1	Read / Write
2130	Unsigned / 2	Process Noise Damp- ing	Select process noise damp- ing level: 0: 55 ms filtering (Centrifugal Pump) 1: 110 ms filtering (Triplex Pump) 2: 220 ms filtering (Duplex Pump) 3: 400 ms filtering (Simplex Pump) 4: 800 ms filtering (Cam Pump)	2	0 Low to 4 High	Read / Write

## C.4 Modbus holding registers tables

Table C-5 Mass flow

Modbus address	Data type / Size [bytes]	Parameter	Description	Default value [unit]	Value range	Access level
2125	Float / 4	Low Mass flow Cut-Off	Set mass flow limit for low flow cut-off. Below this limit mass flow output is forced to zero. If Low Flow Cut-Off is set to 0, the cut-off functionality is disabled. <b>Notice:</b> It is recommended to set a lower value for gas applications.	Sensor size specific [kg/s] <sup>1)</sup>	0 to 1023	Read / Write
2426	Float / 4	Mass flow Correction Factor	Specify correction factor for use in the mass flow calculation	1	-1.999 to +1.999	Read / Write

<sup>1)</sup>: See Sensor dimension dependent default settings (Page 126)

Table C-6 Volume flow

Modbus address	Data type / Size [bytes]	Parameter	Description	Default value [unit]	Value range	Access level
2170	Float / 4	Low Volume flow Cut Off	Define the numerical volume flow value below which the volume flow output is forced to zero.	Sensor size specific [m <sup>3</sup> /s] <sup>1)</sup>	0 to 0.177	Read / Write

<sup>1)</sup>: See Sensor dimension dependent default settings (Page 126)

Table C-7 Density

Modbus address	Data type / Size [bytes]	Parameter	Description	Default value [unit]	Value range	Access level
2127	Float / 4	Empty Tube Limit	Define threshold value of empty tube	500 [kg/m <sup>3</sup> ]	-14 000 to +14 000	Read / Write
2129	Unsigned / 2	Empty Tube Detection	Set automatic detection of Empty Tube On/Off  0 = off (Empty tube is off). 1 = on (a density value below Empty Tube Limit triggers an alarm. All flow rate values are forced to zero %).	0	0 to 1	Read / Write



Modbus address	Data type / Size [bytes]	Parameter	Description	Default value [unit]	Value range	Access level
2442	Float / 4	Density Correction Factor	Set density compensation value (gain) in order to make a density correction (scale factor).  To increase the displayed density value with +0.5 %, set the density factor to 1.005.  The displayed density value will now be 0.5 % higher than before	1	-1.999 to +1.999	Read / Write
2444	Float / 4	Density Correction Offset	Set density compensation value (offset) in order to make an offset on the measured density.  To make the flowmeter show + 2 kg/m <sup>3</sup> , change the density offset to 2.000 kg/m <sup>3</sup> in the 'Sensor' menu	0 [kg/m <sup>3</sup> ]	-1 400 to +1 400	Read / Write

Table C-8 Totalizer

Modbus address	Data type / Size [bytes]	Parameter	Description	Default value [unit]	Value range	Access level
2609	unsigned / 2	Totalizer State	Totalizer state <ul style="list-style-type: none"> <li>• 0 = paused</li> <li>• 1 = running</li> </ul>	1	0 to 1	Read only
2610	float / 4	Totalizer Value	The totalized MASS value in kg	0 [kg]	Min. -1.70E+38 Max. 1.70E+38	Read Only
3018	Unsigned / 4	Totalizer fixed point part	The totalized MASS value in kg. Most significant word of the totalizer (MSW).  The format of the totalizer is a TotalType. The TotalType represent a fixed point value in the MSW 32 bit and a fractional part in the LSW 32 bit.  Example: 2.03 would be represented as fixed point part = 2 and fractional part = 30000000	0 [kg]	Min -2147483648 Max 2247483647	Read Only

## C.4 Modbus holding registers tables

Modbus address	Data type / Size [bytes]	Parameter	Description	Default value [unit]	Value range	Access level
3020	Unsigned / 4	Totalizer fractional part	The totalized MASS value in kg. Least significant word of the totalizer (LSW). The format of the totalizer is a TotalType. The TotalType represent a fixed point value in the MSW 32 bit and a fractional part in the LSW 32 bit. Example: 2.03 would be represented as fixed point part = 2 and fractional part = 30000000 Note: The data type is signed32	0 [kg]	Min -999999999 Max 999999999	Read Only
2612	unsigned / 2	Reset totalizer	Reset totalizer Value	-	Enter 1 to reset	Read / Write
2613	unsigned / 2	Pause totalizer	Pause totalizer Totalizer can only be paused when running	-	Enter 1 to pause	Read / Write
2614	unsigned / 2	Resume totalizer	Resume totalizer Totalizer can only be resumed when paused	-	Enter 1 to pause	Read / Write

Table C-9 Access level

Modbus address	Data type / Size [bytes]	Parameter	Description	Default value [unit]	Value range	Access level
404	Unsigned / 2	Access level	Access level status	-	32 (logged in) 4 (logged out)	Read Only
412	Unsigned / 2	User password	Password to enable writing commands	-	2457 (enable user password) 0 (disable user password)	Read / Write

Table C-10 Maintenance

Modbus address	Data type / Size [bytes]	Parameter	Description	Default value [unit]	Value range	Access level
700	Unsigned / 2	Set To Default	Reset all parameters to factory settings	-	Enter 1 to reset	Write
2700	Unsigned / 4	Operating Time Total	Total operating time since first power up	0 [h]	-	Read Only
2702	Unsigned / 4	Operating Time	Operating time since last power up	0 [h]	-	Read Only
4088	String / 14	Firmware Time Stamp	Firmware time stamp specifies the date and time when the sensor firmware was built	-	-	Read Only
4105	String / 32	Sensor PCBA Serial Number	Serial number of the sensor electronic	-	-	Read only

Table C-11 Device diagnostics

Modbus address	Data type / Size [bytes]	Parameter	Description	Default value [unit]	Value range	Access level
2756	Float / 4	Driver Current	Actual sensor driver current. The actual driver current is viscosity and sensor size dependent	- [A]	0 to 0.124	Read Only
2758	Float / 4	Pick-up Amplitude 1	Actual pick-up 1 amplitude	- [V]	0 to 0 9999	Read Only
2760	Float / 4	Pick-up Amplitude 2	Actual pick-up 2 amplitude	- [V]	0 to 0 9999	Read Only
2762	Float / 4	Sensor Frequency	Actual sensor frequency	- [Hz]	0 to 1 023	Read Only
3032	Float / 4	PCB Temperature	Actual sensor electronic temperature	- [C°]	-50 to 200	Read Only

Table C-12 Aerated flow

Modbus address	Data type / Size [bytes]	Parameter	Description	Default value [unit]	Value range	Access level
2200	Unsigned / 2	Aerated Flow Alarm Limit	Alarm limit calculated in per cent of accepted bad measurements.	80 [%]	0 to 99	Read / Write
2201	Unsigned / 2	Aerated Flow Warning Limit	Warning limit calculated in per cent of accepted bad measurements	0 [%]	0 to 99	Read / Write
2202	Unsigned / 2	Measurement Sample Time	The time period over which the actual percentage of bad measurements is calculated	5 [s]	1 to 10	Read / Write

## C.4 Modbus holding registers tables

Modbus address	Data type / Size [bytes]	Parameter	Description	Default value [unit]	Value range	Access level
2203	Unsigned / 2	Aerated Flow Filter	Aerated flow filter 0: Disabled 1: Enabled 2: Auto Auto means that filtering starts automatically when aerated flow is measured.	2	0 to 2	Read / Write
2204	Unsigned / 2	Filter Time Constant	PV Filter Time Constant 0: 0.5 seconds 1: 1 second 2: 2 seconds 3: 5 seconds 4: 10 seconds 5: 20 seconds 6: 30 seconds 7: User Defined Value	4	0 to 7	Read / Write
2205	Float / 4	Filter Start Hysteresis	The filter is active when the hysteresis value is exceeded. Aerated Flow Filter must be set to Auto	0.015 [V]	0 to 0.124	Read / Write
2207	Unsigned / 2	Minimum Filtering Time	The filtering time is reset each time hysteresis band is exceeded	10 [ms cycles]	0 to 65535	Read / Write
2214	Unsigned / 2	Pickup Amplitude Filter	Enable/disable pickup amplitude filter. 0 = Disable 1 = Enable	1	0 to 1	Read / Write
2215	Unsigned / 2	Bad Measurement Count	Number of bad measurements counted during the last period	0	0 - 65535	Read Only
2216	Unsigned / 2	Filter Iteration	Set the number of times to repeat the same filter. Increasing the number will increase the damping. Active only if Filter Time Constant is set to 7.	3	1 to 5	Read / Write
2217	Unsigned / 2	Bandwidth Factor	Increase the Bandwidth Factor to reduce the LP (low pass) bandwidth filtering. Active only if Filter Time Constant is set to 7.	2	0 to 4	Read / Write
2218	Unsigned / 2	Filter Pole Shift	Configure the bandwidth and damping in the stop band. A high number will give a small bandwidth and an increased damping in the stop band. Active only if Filter Time Constant is set to 7.	2	1 to 5	Read / Write

Table C-13 Zero point adjustment

Modbus address	Data type / Size [bytes]	Parameter	Description	Default value [unit]	Value range	Access level
2132	Unsigned / 2	Zero Point Adjustment	Select zero-point adjustment method. Automatic zero point adjustment is recommended. <ul style="list-style-type: none"> <li>0 = Auto</li> <li>1 = Manual</li> </ul>	0	0 to 1	Read / Write
2133	Float / 4	Manual Zero Point Offset	Enter agreed zero point offset value for manual zero point adjustment mode.	0 [kg/s]	0 to 1023	Read / Write
2135	Unsigned / 2	Zero Point Duration	Define duration of zero point adjustment.	30 [s]	1 to 999	Read / Write
2136	Float / 4	Standard Deviation	Standard deviation during auto zero point adjustment	0 [kg/s]	-1023 to +1023	Read only
2138	Float / 4	Standard Deviation Limit	Set limit for zero point adjustment <b>Standard Deviation</b> value. If the <b>Standard Deviation</b> exceeds the <b>Standard Deviation Limit</b> , the auto zero point adjustment is aborted.	Sensor size specific [kg/s] <sup>1)</sup>	0 to +1023	Read / Write
2140	Float / 4	Zero Point Offset Limit	Set limit for zero point offset. If the zero point offset exceeds the zero point offset limit, the zero point offset cannot be stored	Sensor size specific [kg/s] <sup>1)</sup>	-1023 to +1023	Read / Write
2142	Float / 4	Zero Point Offset Value	Default zero point offset based on factory calibration of sensor. A Zero point offset compensates for sensor variations due to process conditions.	0 [kg/s]	-1023 to +1023	Read only
2144	Unsigned / 2	Zero Point Adjust Progress	Shows the progress of the currently running Zero Point adjustment in percentage	0 [%]	0 to 100	Read Only

C.4 Modbus holding registers tables

Modbus address	Data type / Size [bytes]	Parameter	Description	Default value [unit]	Value range	Access level
2145	Unsigned / 2	Zero Point Adjust Status	<p>Status of the last zero point adjustment performed Every high bit ('1') represents an error occurred in the last zero point adjustment performed.</p> <p>No high bits equals ok. Bit 0 = Zero sigma limit exceeded Bit 1 = Zero offset limit exceeded Bit 2 = Quality of zero point conditions</p>	-	<ul style="list-style-type: none"> <li>• 1</li> <li>• 2</li> <li>• 4</li> </ul>	Read Only
2180	Unsigned / 2	Start Zero Point Adjustment	<p>Start automatic zero point adjustment.</p> <p>The automatic zero point adjustment determines the application specific zero point offset automatically.</p> <p>Possible selections:</p> <ul style="list-style-type: none"> <li>• 0: Idle</li> <li>• 1: Running</li> <li>• 2: Start</li> </ul>	0	0 to 2	Read / Write

<sup>1)</sup>: See Sensor dimension dependent default settings (Page 126)

Table C-14 Modbus

Modbus address	Data type / Size [bytes]	Parameter	Description	Default value [unit]	Value range	Access level
527	Unsigned / 2	Float byte order	<p>The float byte order used in Modbus messages.</p> <p>Selection 0: Byte order: 1-0-3-2 Selection 1: Byte order: 0-1-2-3 Selection 2: Byte order: 2-3-0-1 Selection 3: Byte order: 3-2-1-0</p> <p>The first mentioned byte is the first byte sent. Byte 3 corresponds to the left-most byte (MSB) of a 32 bit float in big endian format, byte 0 corresponds to the right-most byte (LSB).</p>	3	0 to 3	Read / Write
528	Unsigned / 2	Modbus Address	Set Modbus Device Address	1	1 to 247	Read / Write

Modbus address	Data type / Size [bytes]	Parameter	Description	Default value [unit]	Value range	Access level
529	Unsigned / 2	Baudrate	Set communication baudrate. Following baud rates are available: <ul style="list-style-type: none"> <li>• 0 = 9600</li> <li>• 1 = 19200 (Default)</li> <li>• 2 = 115200</li> <li>• 4 = 38400</li> <li>• 5 = 57600</li> <li>• 6 = 76800</li> </ul>	1	0 to 5	Read / Write
530	Unsigned / 2	Modbus Parity Framing	RS-485 parity and framing 8 databits are always used  0 = even parity, 1 stopbit 1 = odd parity, 1 stopbit 2 = no parity, 2 stopbits	0	0 to 2	Read / Write
600	Unsigned / 2	Restart communication	Restart Modbus communication Write: <ul style="list-style-type: none"> <li>• 0 = No effect</li> <li>• 1 = Restart</li> </ul> Read: <ul style="list-style-type: none"> <li>• Always 0</li> </ul>	-	0 to 1	Write

Table C-15 Sensor

Modbus address	Data type / Size [bytes]	Parameter	Description	Default value [unit]	Value range	Access level
2113	Float / 4	Minimum Frame Temperature	Lower limit of the frame temperature	-50 [°C]		Read only
2115	Float / 4	Maximum Frame Temperature	Lower limit of the frame temperature	200 [°C]		Read only
4043	String / 16	Sensor size	Nominal sensor diameter (DN)	-	-	Read only
4051	String / 32	Hazardous area approval	Hazardous area approval of the sensor	-	-	Read only
4078	String / 20	Wetted materials	Sensor enclosure material	-	-	Read Only

C.4 Modbus holding registers tables

Table C-16 Volume flow calibration

Modbus address	Data type / Size [bytes]	Parameter	Description	Default value [unit]	Value range	Access level
2103	Float / 4	Maximum Volume flow Capacity	Maximum volume flow measurement capacity of the sensor	Sensor size specific [m <sup>3</sup> /s] <sup>1)</sup>	0 to 0.177	Read only

<sup>1)</sup>: See Sensor dimension dependent default settings (Page 126).

Table C-17 Mass flow calibration

Modbus address	Data type / Size [bytes]	Parameter	Description	Default value [unit]	Value range	Access level
2101	Float / 4	Maximum Mass flow Capacity	Maximum mass flow measurement capacity of the sensor	Sensor size specific [kg/s] <sup>1)</sup>	0 to 1023	Read only
2402	Float / 4	Calibration Factor	Factory-set sensor-specific calibration factor. The calibration factor is shown on the sensor name-plate	-	Min: 5.00E+07 Max: 4.29E+09	Read only

<sup>1)</sup>: See Sensor dimension dependent default settings (Page 126).

Table C-18 Density calibration

Modbus address	Data type / Size [bytes]	Parameter	Description	Default value [unit]	Value range	Access level
2428	Float / 4	Density Calibration Offset	Specify an offset in the density flow calculation	-	-14 000 to +14 000	Read only
2430	Float / 4	Density Calibration Factor	Specify gain factor in the density flow calculation	-	-2147483583 to 2147483583	Read only
2432	Float / 4	Dens. Comp. Tube Temp.	Specifies a tube temperature coefficient in the density calculation	-	-0.001953 to +0.001953	Read only
2434	Float / 4	Dens. Comp. Frame Temp.	Specifies a frame temperature coefficient in the density calculation	-	-0.001953 to +0.001953	Read only



Table C-19 Simulation

Modbus address	Data type / Size [bytes]	Parameter	Description	Default value [unit]	Value range	Access level
2764	Float / 4	Mass flow Simulation Value	Set mass flow simulation value. The mass flow will be set to this value on all outputs, if <b>Simulation Mass Flow</b> is enabled	0 [kg/s]	-1023 to +1023	Read / Write
2766	Float / 4	Density Simulation Value	Set density simulation value. The density will be set to this value on all outputs, if <b>Simulation Density</b> is enabled	1000 [kg/m <sup>3</sup> ]	-20000 to +20000	Read / Write
2768	Float / 4	Media Temperature Simulation Value	Set media temperature simulation value. The media temperature will be set to this value on all outputs if <b>Simulation media Temperature</b> is enabled	0 [°C]	-50 to +200	Read / Write
2770	Float / 4	Frame Temperature Simulation Value	Set frame temperature simulation value. The frame temperature will be set to this value on all outputs if <b>Simulation Frame Temperature</b> is enabled	0 [°C]	-50 to +200	Read / Write
2772	Float / 4	Volume flow Simulation Value	Set volume flow simulation value. The volume flow will be set to this value on all outputs, if <b>Simulation Volume Flow</b> is enabled	m <sup>3</sup> /s	-65 to +65	Read / Write
2780	Unsigned / 2	Enable Simulation	Activate simulation. Select one of the following values: <ul style="list-style-type: none"> <li>• Bit 0: Mass flow</li> <li>• Bit 1: Density</li> <li>• Bit 2: Volume flow</li> <li>• Bit 3: Media temperature</li> <li>• Bit 4: Frame temperature</li> </ul>	0	0 to 63	Read / Write

C.4 Modbus holding registers tables

Table C-20 Alarms

Modbus address	Data type / Size [bytes]	Parameter	Description	Default value [unit]	Value range	Access level
3012	Unsigned / 4	Alarm Group 1	<p>The following bit is set in case of active alarm:</p> <ul style="list-style-type: none"> <li>• Bit 4: Power Supply Malfunction</li> <li>• Bit 6: Temperature Circuit Malfunction</li> <li>• Bit 10: Measurement Out Of Range</li> <li>• Bit 14: Calibration Malfunction</li> <li>• Bit 15: Compensation Out Of Range</li> <li>• Bit 17: Pickup Malfunction</li> <li>• Bit 23: Driver Malfunction</li> <li>• Bit 26: Measurement Out Of Range</li> <li>• Bit 27: Mass Flow Max Limit Exceeded</li> <li>• Bit 28: Volume Flow Max Limit Exceeded</li> <li>• Bit 29: Density Max Limit Exceeded</li> <li>• Bit 30: Min Tube Temp Exceeded</li> <li>• Bit 31: Max Tube Temp Exceeded</li> </ul>	-	-	Read Only

Modbus address	Data type / Size [bytes]	Parameter	Description	Default value [unit]	Value range	Access level
3014	Unsigned / 4	Alarm Group 2	The following bit is set in case of active alarm: <ul style="list-style-type: none"> <li>• Bit 0: Min Frame Temp Exceeded</li> <li>• Bit 1: Max Frame Temp Exceeded</li> <li>• Bit 2: Zero Sigma Limit Exceeded</li> <li>• Bit 3: Zero Offset Limit Exceeded</li> <li>• Bit 4: Quality Of Zero Point Conditions</li> <li>• Bit 5: Empty Pipe</li> <li>• Bit 6: Sensor Partially Filled</li> <li>• Bit 7: Storage Malfunction</li> <li>• Bit 8: System Internal</li> <li>• Bit 14: Unstable Measurement Conditions</li> <li>• Bit 15: Auto-filtering enabled</li> <li>• Bit 23: Sensor Startup</li> </ul>	-	-	Read Only

C.4 Modbus holding registers tables

Table C-21 Quality code for process values

Modbus address	Data type / Size [bytes]	Parameter	Description	Default value [unit]	Value range	Access level
3014	Unsigned / 4	Alarm Group 2	Quality code of a measured value	Process values for quality codes Media temperature Density Volume flow Mass flow Quality code for each process value consist of 2 bits: Bit 24/25: Media temperature Bit 26/27: Density Bit 28/29: Volume flow Bit 30/31: Mass flow	11 Good 01 Reserved 10 Simulation 00 Bad	Read Only

# Index

## A

- Accuracy
  - Density, 104
  - Mass flow, 104
  - Media temperature, 104
- Applications, 27
- Approval information nameplate
  - Sensor, 26

## C

- Cable requirements, 45
- Cable specifications, 107
- Catalog
  - catalog sheets, 123
- Certificates, 11, 123
- Certificates and approvals, 109, 110
- Characteristics
  - Density calibration, 152
  - Mass flow calibration, 152
  - Sensor, 151
  - Volume flow calibration, 152
- Cleaning, 84
- Commissioning
  - Steps, 51
- Communication
  - Modbus, 150
- Communication parameters
  - Setup, 54
- Coriolis
  - Measurement principle, 125
- Cross talk, 36, 100
- Customer Support, (Refer to Technical support)

## D

- Design, 21
  - Sensor, 106
- Designated use, 105
- Device
  - identification, 22
- Diagnosing
  - with SIMATIC PDM, 101
- Diagnostics, 92
- Dimensions and weight, 119
- Disassembly, 39

- Disposal, 90
- Document history, 7
- Documentation
  - Edition, 7
- Downloads, 123

## E

- Electrical connection
  - Cable requirements, 45
  - In hazardous area, 44
- Empty tube monitoring, 77
- Exception codes, 129

## F

- Flow direction, 33

## G

- General information nameplate, 22
  - Sensor, 23

## H

- Handling, 35
- Hazardous area
  - Electrical connection, 44
  - Laws and directives, 11
  - Qualified personnel, 13
- Hazardous locations
  - Approvals, 14
- Hot swappable, 89
- Hotline, (Refer to Support request)

## I

- Icons, (see Symbol)
- Identification
  - Sensor, 142
- Installation
  - Gas, 33
  - Incorrect, 100
  - Inlet / Outlet conditions, 32
  - Liquid, 33
  - Location in the system, 32
  - Mounting of sensor, 35

- Orienting the sensor, 34
- Safety instructions, 32
- Upstream / Downstream, 32

Installation torques, 105

Internet

- Modbus Organisation, 20

## L

Laws and directives

- Disassembly, 11
- Personel, 11

Low flow cut-off, 76, 99

## M

Maintenance, 83, 86

- device status symbols, 91

Maintenance and Diagnostics

- Access level, 146, 156
- Aerated flow, 147
- Device diagnostics, 147
- Maintenance, 147
- Zero point adjustment, 149

Manuals, 123

Mass flow cut-off limit, 76

Modbus

- Features, 19
- Frame, 20
- Network, 53
- Organisation Website, 20
- Technical data, 110
- Technology, 19

Modbus holding registers

- Alarms, 154
- Characteristics, 151
- Communication, 150
- Identification, 142
- Maintenance & Diagnostics, 146, 156
- Process values, 137
- Setup, 143
- Simulation, 153
- Totalizer, 145

Modifications

- correct usage, 11
- improper, 11

Mounting, (See Installation)

## N

Nameplates

- Approval information, 26
- General information, 22, 23
- Specific information, 25

## P

PDM

- Commissioning steps, 51

Performance, 103

Power supply, 103, 107

Pressure

- Safety instructions, 32

Process noise damping, 77

Process values, 71, 137

Process variables, 109

## Q

Qualified personnel, 13

## R

Rated operating conditions, 108

Recalibration, 84

Reference conditions, 103

Repair, 86

Return procedure, 89

## S

Safety

- Sensor installation, 32

Scope of delivery, 9

Sensor dimension dependent default settings

- Fraction, 128
- Mass flow, 126
- Standard volume flow, 127
- Volume flow, 127
- Zero point adjustment, 128

Sensor orientation, (See Installation)

SensorFlash, 110

Service, 86, 124

Service and support

- Internet, 124

Service information, 87

**Setup**

- Density, 144
- Mass flow, 144
- Operating conditions, 143
- Volume flow, 144

Signal processing, 126

**SIMATIC PDM**

- Zero point adjustment, 63

Simulation, 80, 153

Specific information nameplate

- Sensor, 25

Support, 124

Support request, 124

**Symbol**

- configuration, 91
- device status, 91
- diagnostics, 91
- maintenance, 91
- operating mode, 91
- process value, 91

Symbols, (Refer to warning symbols)

System design, 105

System integration, 19

**T**

Technical data, 103, 105, 110

Technical support, 124

- partner, 124
- personal contact, 124

Termination DIP switches, 47

Test certificates, 11

Totalizer, 145

**U**

Unicast communication mode, 20

Units for Process values and totalizer, 138

**V**

Vibrations, 35, 100

Volume flow cut-off limit, 76

**W**

Warning symbols, 11

Warranty, 10

**Z**

Zero point adjustment, 74

Automatic, 74

Manual, 76

via SIMATIC PDM, 63

